



**RF**

**GC. No: 41.202.21**



**MDF**

**GC. No: 41.202.20**

**M A X O L**

**A  
GLEN DIMPLEX  
COMPANY**

# **Microturbo 40H**

## **INSTALLATION AND SERVICING INSTRUCTIONS**

Leave these instructions  
with the user.

Wall Mounted, Room Sealed,  
Fanned Flue, Gas Boiler.

This appliance is for use  
with Natural gas only.

# CONTENTS



Section	Page No.
1 Introduction	2
2 Safety and General Information	3
2.1 General Safety	3
2.2 Water System	3
2.3 Sealed System Requirements	4
2.4 Air Supply Requirements	5
2.5 Gas Supply	5
2.6 Electrical Supply	6
2.7 Technical Data	6
3 Air Inlet, Flue Exit Location	8
4 Packaging	9
4.1 RF Rear Flueing Model	9
4.2 MDF Side/Top/Base Flueing Model	9
4.2.1 1m Extension Kit	10
4.2.2 90° Bend Kit	10
4.2.3 135° Bend Kit	10
4.3 Optional Extras	10
5 Installation of MDF Model	11
5.1 Siting the boiler & routing the flue	11
5.1.1 Design requirements for routing the flue	12
5.2 Base/Side/Top flueing arrangements (MDF)	13
5.2.1 Installing the Flue Box	13
5.2.2 Installing the Flue Pipes	13
5.2.3 Assembling the Flue Pipes	14
5.2.4 Connecting the flues to the flue box	16
5.2.4.1 Elbows	17
5.2.5 Additional requirements for the installation of the Microturbo MDF in a kitchen cabinet	18
5.2.5.1 Installing the flue pipes & box (kitchen cabinet only)	18
5.3 Fixing the boiler to the Flue Box — (MDF)	19
Installation of Rear Flue Model (RF)	20
5.4 Prepare the boiler	20
5.5 Wall Mounting Template	20
5.6 Fixing the Flue Terminals	21
5.7 Wall Mounting the Boiler	21
6 Water Connections	22
7 Gas Connection	22
8 Electrical Connection	23
9 Commissioning the Boiler	28
10 Fitting the Case	29
11 General Checks	29
Fault Finding Chart - MDF	30
Fault Finding Chart - RF	31
Servicing Instructions	32
1.0 Routine Annual Servicing	32
2.0 Component Exchange	35
2.1 Control Tray removal (MDF)	35
2.1.1 Control Box	36
2.1.2 Pump Overrun Thermostat	36
2.1.3 Boiler Thermostat	37
2.1.4 Appliances Switches	37
2.1.5 Indicator Lights	37
2.1.6 Pressure Switch (RF only)	37
2.2.1 Double Solenoid Valve (MDF only)	38
2.2.2 Double Solenoid Valve (RF only)	39
2.3 Injector	39
2.4 Overheat Thermostat	40
2.5 Spark Electrode and Flame Sensing Probe	40
2.6 Burner	41
2.7 Insulation Panels	41
2.8 Fan	42
2.9 Heat Exchanger	42
Short List of Parts	43

# 1 Introduction

The Maxol Microturbo 40H is a wall mounted, room sealed, fan flued, central heating boiler designed for ease of installation, with a range of flueing options. The casing is attractively styled and the boiler incorporates the latest in gas appliance technology.

## 1.1 Features

- Output — 11.7 kW (40,000 Btu/h) suitable for most heating and domestic hot water requirements.
- Size — 300w × 460h × 280d MDF (215d RF). Compact size enables it to be easily fitted into a kitchen unit.
- Automatic control — Specially designed electronic controls with electronic ignition (no pilot), boiler thermostat and neon display all mounted behind an attractive plinth.
- Suitable for fully pumped sealed and open vented systems — Overheat thermostat and pump overrun fitted as standard. (Not suitable for gravity systems).
- 2 pipe unbalanced flueing system. The pipes may be connected at the top, base or sides of the appliance and in any direction up to 9 metres (straight) or 6 metres and 2 bends using two 51mm diameter pipes and unobtrusive flue terminals, — MDF and from 180mm to 610mm through a rear wall — RF.
- Latest pre-mixed burner technology gives low Nitrous Oxide values — meets all proposed EC requirements and helps reduce acid gas emissions and environmental damage.  $\text{NO}_x$  — 29ppm.
- Light weight 15.5kg (34 lb) — High efficiency copper heat exchanger.
- This appliance meets all the essential requirements of the Gas Directive and carries the CE mark.  
It is also British Gas Service listed.



## 2 Safety and General Information

### 2.1 General Safety

● Gas Safety Regulations (Installation & Use) 1984, (as amended). — The installation of this appliance must be carried out by a competent C.O.R.G.I. registered person in accordance with the above regulation, Local Building Regulations, Building Standards (Scotland) Regulations, current I.E.E. regulations on wiring, BS 7671, the Bye laws of the Local Water Undertaking, Health & Safety Document No. 635 "The Electricity at work regs. 1989".

● It should also be in accordance with the relevant recommendations of the following British Standard Codes of Practice:

BS 5440 Pt.1 — Flues (for gas appliances under 60 kW).

BS 5440 Pt.2 — Ventilation (for gas appliances under 60 kW).

BS 5449 — Forced circulation — hot water systems.

BS 5546 — Installation of gas hot water supplies for domestic purposes.

BS 6798 — Installation of gas hot water boilers for gas appliances under 60 kW.

BS 6891 — Low pressure installation pipes.

BS 7593 — Code of Practice for the treatment of water in CH systems.


#### Thermostat Settings

Min (Posn. 1) — 59°C

Max (Posn. 5) — 82°C

The recommended flow through the boiler is 16 l/min minimum.

MAXOL MICROTURBO 40H  
WATER PRESSURE LOSS



### 2.2 Water System

a. **Maximum head** — 30 metres (100 ft.) — with open vent.

b. **Minimum head** — 1 metre (3 ft.) (Static).



c. The hot water cylinder must be of the indirect type.

d. Suitable for fully pumped systems only.

e. **System design temperature** — approx. 11°C temperature rise across the boiler under any conditions of use.

f. **Systems with flow & return pipes dropping to floor level** — The boiler is fitted with an overheat thermostat, but adequate provision must be incorporated to ensure air is vented from the system by an open vent or automatic air vents at the highest positions on the flow and return pipes.

- g. **Bypass** — A bypass must be fitted in 15 mm pipe with a valve (not adjustable by the user). Adjust the valve setting to obtain a temperature rise across the boiler of approximately 11°C. This is performed with the system fully heated, starting with the valve almost fully closed with the pump at its optimum speed. The valve is progressively opened to achieve the required temperature rise.
- h. **Pump position** — The pump should be sited in the flow for open vented systems. Isolating valves should be fitted as close to the pump as possible. Pump manufacturers installation requirements must be followed. A suitable pump would be the Grundfos UPS 15/60 or other high head pump.
- i. **Flow and Return Connections** — These are suitable for 22 mm copper pipework with compression fittings integral with the appliance. The **flow** is the left hand connection and the **return** is the right hand connection. Both flow and return connections are situated at the top rear of the appliance within the boiler casing.
- j. **System Cleaning and Inhibiting**— Before commissioning the appliance it is **essential** to clean all installations in accordance with the procedure set out in BS 7593. This involves the application of a cleanser, circulating it around the whole system for the specified time and flushing to drain. It is important to select a cleanser appropriate to the situation, ie. for a new installation, or for an existing system where the boiler is being replaced. In the case of boiler replacement it is good practice to clean the system prior to the installation of the new boiler. It is recommended that an inhibitor is added to protect the system. Product should be added in accordance with the manufacturer's instructions at the time of the final fill. We recommend products manufactured by: Sentinel Division, Grace Dearborn Ltd., Widnes, Cheshire WA8 8UD. Tel: 051-495 1861 Fax: 051-420 5447



**OPEN VENTED SYSTEM**

**SCHEMATIC DIAGRAM ONLY**  
A close coupled or combined feed and vent pipe arrangement should be connected as in the above schematic.


## 2.3 Sealed System Requirements

The system must comply with the following British Standards and any local Building Regulations which may apply. BS 6700, BS 6798, BS 5449, BS 7074: Part 1.


The maximum boiler flow temperature is 82°C (180°F).

The installation should be designed in accordance with the schematic diagram and the following points must be adhered to:


- a. A safety valve shall be fitted on the flow as close to the boiler as possible. No valve or restriction may be placed between the boiler and the valve. The valve must be piped to drain so that any discharge will not cause a hazard to the user, electrical components or wiring. The safety valve must be set to operate at 3 bar. The safety valve shall conform to BS 6759



### FILLING AND MAKE UP DIAGRAM



Non-automatic filling and make-up



Automatic filling and make-up

- b. An expansion vessel conforming to BS 4814 shall be fitted and positioned as in the schematic diagram. The method of sizing the expansion vessel can be found in BS 5449: Part 1 or BS 7074: Part 1 as appropriate. The required basic parameters are water content of the system and the operating pressure. For example with a vessel charge and initial system pressure of 1.0 bar a total system water content of 100 l a vessel volume of 10.9 l will be required. For any system a more accurate calculation of vessel size detailed in BS 7074: Part 1 section 7.2.
- c. A pressure gauge shall be fitted in the system preferably in the flow on the suction side of the pump. The gauge, must be capable of measuring 0 to 4 bar and be fitted with an adjustable pointer.
- d. An air separator should be fitted on the flow and if the pump is on the flow, the separator should be fitted on the inlet side.
- e. Any method of top up must comply with local water bylaws (see filling and make up diagram).
- f. Air vents should be fitted at any point where air is likely to collect.
- g. Filling methods must comply with local water bylaws. The methods are outlined in filling and make up diagrams.
- h. An indirect cylinder must be used suitable for operation at a pressure of 3.35 bar.


## 2.4 Air Supply Requirements

If the appliance is mounted in a compartment/cupboard which conforms to the minimum service clearances (see page 7), no purpose made ventilation is required.

## 2.5 Gas Supply


Installation pipes should be fitted in accordance with BS 6891. Pipework from the meter to the appliance must be of adequate size. Pipes of a size smaller than the appliance inlet gas connection should not be used.

The complete installation including the meter must be tested for soundness and purged as described in the above code. The gas connector to the appliance is Rc 1/2 (1/2 in. BSP) and is situated at the rear of the base at the left hand side.



## 2.6 Electrical Supply

- a. Wiring external to the appliance must be installed in accordance with current I.E.E. Wiring Regulations and any Local Regulations which apply.
- b. The supply cable must be PVC insulated 3-core 0.75 mm (24/0.2 mm) to BS 6500 Table 16.
- c. Power consumption of the appliance is 55 W (max.). The supply must be 240V  $\sim$  50Hz and through an unswitched shuttered socket outlet and 3A fused 3-pin plug. Both complying with the requirements of BS 1363. Alternatively a 3A fused double pole isolating switch may be used, having a minimum contact separation of 3 mm in all poles, servicing only the appliance and system controls.
- d. Any means for disconnecting the appliance from the electricity supply must have a contact separation of at least 3 mm in all poles.
- e. The boiler may be installed in any room or internal space, although particular attention is drawn to the requirements of the current I.E.E. Wiring Regulations, and in Scotland, the electrical provisions of the Building Regulations in Scotland, with respect to the installation of the boiler in a room or internal space containing a bath or shower. Where a room-sealed appliance is installed in a room containing a bath or shower, any electrical switch or appliance control, utilising electricity should be so situated that it cannot be touched by a person using the bath or shower.
- f. Wiring connection is made through the grommets at the rear of the base at the right hand side.
- g. This appliance must be earthed using the terminals supplied.




## 2.7 Technical Data



### HEAT INPUT & OUTPUTS

- a. MDF - 300mm Flue
  - Nominal heat input = 14.51kW
  - Nominal heat output = 11.72kW
  - Burner press (hot) = 4.3mb  $\pm$  0.5mb
- b. MDF — Max Flue Length
  - Nominal heat input = 14.51kW
  - Nominal heat output = 11.72kW
  - Burner press (hot) = 4.3mb  $\pm$  0.5mb
  - Injector — 6  $\times$  1.7mm dia. — Stamped M-40

### MDF MODEL







- c. RF — All Flue Length  
 Nominal heat input = 14.51kW  
 Nominal heat output = 11.72kW  
 Burner press (hot) = 10.3mb ± 0.5mb  
 Mean heat output = 40,000 Btu/h — R.F./M.D.F
- d. Time for 100l of gas = 4min 20secs  
 Time for 1ft<sup>3</sup> of gas = 74 secs  
 CV = 38MJ/cubic metre  
 Mean gas rate = 1.4m<sup>3</sup>/hr.
- e. Flue duct diameters MDF = 50mm  
 RF = 45mm  
 Projection through the wall = 25mm
- f. Injector — 6 × 1.4mm dia. — Stamped 40.
- g. Core drill diameter required for flues - 65mm MDF  
 - 52mm RF
- h. Weight — 15.5 kg (34 lb)  
 Water capacity — 0.4 l (0.09 gal.)  
 Static Head — Min. 1m (3ft)  
 — Max. 30m (100ft)
- i. **Thermostat Settings**  
 Min (Posn. 1) — 59°C  
 Max (Posn. 5) — 82°C  
 The recommended flow through the boiler is 16 l/min minimum.
- j. **Minimum Clearance Required for Servicing.**  
 Top — 50mm (2in)  
 Base — 25mm (1in)  
 Sides — 50mm (2in) \*  
 Front — 600mm (24in)  
 5mm (0.21in) - behind openable cupboard door.
- k. **Additional Minimum Clearance Required for Flueing.(MDF)**  
 This clearance depends on the direction of the incoming flue pipes.  
 N.B. If the appliance is to be fitted in a kitchen cabinet see section 5.2.5.

Flue pipes from:	Min. dist. to wall or surface
LHS	250mm between RHS & wall
RHS	150mm between LHS & wall
Top	300mm between Top & Ceiling
Bottom	400mm between Bottom & floor

\* N.B. The minimum flue length with the MDF is 300mm. This must be taken into consideration when installing the appliance with wall thickness of less than 250mm as the minimum side clearance of 50mm required for servicing will increase correspondingly. e.g. Wall thickness — 100mm — min. clearance is 200mm.

- l. The data badge is located on the inside of the case and has the information shown opposite.
- m. This boiler requires external controls to work at its optimum and prevent wasteful cycling at the boiler thermostat. Maxol recommend a timer control with separate room and cylinder thermostats. The boiler is suitable for use with thermal storage systems also.
- n. Average flue temperatures of the combustion products = 130°C above ambient temperature.
- p. The maximum vertical flue length on the MDF is 1.5 metres to the first 90° bend.

**MAXOL**  
**MICROTURBO 40H MDF (MULTI-DIRECTIONAL FLUE)**  
**FANNED FLUED CENTRAL HEATING BOILER**  
**BURCO DEAN APPLIANCES LIMITED**  
 Part No: 58407 Issue D.

GAS INLET PRESSURE: 20mbar.		BURNER PRESSURE: 4.3mbar ± 0.5mbar.	
ELECTRICAL DATA: 230V~ 50Hz. NOMINAL INPUT: 14.5kW. NOMINAL OUTPUT: 11.7kW.			
FUSED AT 3A.		INJECTOR: 6 x 1.7mm DIA. HEX. — 40M.	
GC No: 41.202.20		MAXIMUM HEAD: 30m MINIMUM HEAD: 1m	
SERIAL No: 197-		NATURAL GAS ONLY	
This appliance is NOT adjustable for heat input.			
Manufactured by: Burco Dean Appliances Ltd., Burnley, Lancashire. BB12 6AL.			
CE	86/AP/054 0086	<b>GBIE</b>	GAS TYPE CAT. I <sub>2H</sub> FLUE TYPE CAT. C <sub>12</sub>


**MAXOL**  
**MICROTURBO 40H RF (REAR FLUE)**  
**FANNED FLUED CENTRAL HEATING BOILER**  
**BURCO DEAN APPLIANCES LIMITED**  
 Part No: 58406 Issue D.

GAS INLET PRESSURE: 20mbar.		BURNER PRESSURE: 10.3mbar ± 0.5mbar.	
ELECTRICAL DATA: 230V~ 50Hz. NOMINAL INPUT: 14.5kW. NOMINAL OUTPUT: 11.7kW.			
FUSED AT 3A.		INJECTOR: 6 x 1.4mm DIA. HEX. — 40.	
GC No: 41.202.21		MAXIMUM HEAD: 30m MINIMUM HEAD: 1m	
SERIAL No: 196-		NATURAL GAS ONLY	
This appliance is NOT adjustable for heat input.			
Manufactured by: Burco Dean Appliances Ltd., Burnley, Lancashire. BB12 6AL.			
CE	86/AP/054 0086	<b>GBIE</b>	GAS TYPE CAT. I <sub>2H</sub> FLUE TYPE CAT. C <sub>12</sub>



### 3 Air Inlet/Flue Exit Terminal Location


- a. The air inlet and flue exit terminals must be installed according to the recommendations of BS 5440 Part 1 and be installed sufficiently close to each other on the same wall to be located in sensibly similar wind conditions.
- b. The terminals must be positioned on the outside of the building and must allow the free passage of air across them at all times.
- c. Avoid positions where the terminals are adjacent to projections; particularly under a balcony or immediately adjacent to a drain pipe.
- d. The position of the outlet terminal must ensure that products of combustion produced from the boiler cannot enter the building or any adjacent building through windows, doors or any other means.
- e. Acceptable flue terminal positions are indicated in the diagram.
- f. Both terminals must be positioned on the same wall.
- g. The minimum distance between centres of the terminals (MDF only) is 150mm. There is no maximum distance.
- h. If the boiler is fitted into a timber framed building — consult British Gas publication "Guide for Gas Installations in Timber Framed Housing DM2" or your local Gas Region.
- i. Where the lowest part of either flue terminal is fitted less than 2 metres (6.6 ft.) above ground, a balcony, or above a flat roof to which there is access then the flue terminal/terminals must be protected by a terminal guard, available from Maxol. Ensure the terminal guard is fitted centrally.
- j. The terminal guard is supplied with three fixing screws & rawlplugs. Fit the guard centrally over the flue pipe and secure with the plugs and screws provided.  
**N.B.** With the minimum flue outlet/inlet distance of 150mm the flue terminal guards will touch if both are fitted.
- k. The outlet flue terminal will produce a plume of water vapour and also moisture droplets. This should be considered when positioning the flue terminal eg. over a door. This is a normal feature of a high efficiency appliance.



Terminal Position	Minimum distance
A : Directly below an openable window or other opening e.g. an air brick.	300mm
B : Below gutters, soil pipes or drain pipes	75mm
C : Below eaves	200mm
D : Below balconies	200mm
E : From vertical drain pipes and soil pipes	75mm
F : From internal or external corners	75mm
G : Above ground or balcony level	300mm
H : From a surface facing a terminal	600mm
I : From a terminal facing a terminal	1200mm
J : Vertically from a terminal on the same wall	1500mm
K : Horizontally from a terminal on the same wall	300mm

## 4 Packaging


The boiler is available in two forms:



### 4.1 RF Rear Flueing Model

178mm (7in) — 381mm (15in) the standard carton includes:

- (i) Boiler
- (ii) Flue Terminals — 2 off 381mm (15")
- (iii) Installation & Servicing Instructions
- (iv) Users Instructions
- (v) Plastic Bag Assembly



### 4.2 MDF Side/Top/Base Flue Model

— Packaged in one carton with extra flue extension kits available if required including:

- (i) Boiler
- (ii) Rear flue box
- (iii) Installation & Servicing Instructions
- (iv) Users Instructions
- (v) Plastic Bag Assembly
- (vi) Flue Terminals — 2 off 381mm (15")
- (vii) Inlet elbow
- (viii) Exhaust elbow
- (ix) 0.5mm flue pipe — 2 off (socketed)

---

## **Flue Kit Cartons Available for MDF Model:**

---


---

### **4.2.1 1m (3'3") Extension Kit**

---

including:

- (i) Flue pipe (socketed) — 2 off
- (ii) Plastic Bag Assembly — 1 off




---

### **4.2.2 90° Bend Kit**

---

including:

- (i) 90° bend (socketed) — 2 off
- (ii) Plastic Bag Assembly — 1 off




---

### **4.2.3 135° Bend Kit**

---

including:

- (i) 135° bend (socketed) — 2 off
- (ii) Plastic Bag Assembly — 1 off





---

## **4.3 Other Optional Extras**


---

- (i) Wall mounting clips — 2 off
- (ii) Protective flue ducting — (1m) length
- (iii) Protective flue duct bend,  
— left, right or back — 1 off
- (iv) Ceiling mounting kit — 1 off

## 5 Installation of MDF Model *For RF see section 5.4*



MAX. FLUE WITH NO BENDS & 8  
OPTIONAL EXTRA 1m FLUE PIPE KITS  
PLUS 1 × 0.5m FLUE PIPE KIT.



MAX. FLUE WITH 1 BEND — 7  
OPTIONAL EXTRA 1m FLUE PIPE  
KITS PLUS A 90° BEND KIT.

### 5.1 Siting the boiler & routing the flue

Any flue length can be installed up to a maximum of 9m straight flue pipe.

For each bend (either 90° or 135°) added you must reduce the overall flue length by 1.5m.

eg. Max Flue Length	No. of Bends
9m	0
7.5m	1
6m	2
4.5m	3
3m	4


The boiler supplied allows you to flue up to 0.5m plus the flue terminal length of 381mm. The maximum flue length possible using the boiler as supplied will depend on the direction of flue entry — see sect. 5.2.4.

Note the minimum flue length possible is 300mm from flue terminal to boiler case.

Some flueing examples are shown opposite.

**NB NOISE** — This appliance utilises a high pressure fan.

This should be considered when siting the boiler, e.g. in a bedroom.



MAX. FLUE WITH 2 BENDS:  
— 5 OPTIONAL EXTRA  
1m FLUE PIPE KITS  
— 1 × 0.5m FLUE PIPE KIT  
— 2 × 90° BEND KITS.

## 5.1.1 Design requirements for routing the flue





- (1) Both flue pipes must enter the appliance in the same direction. The flues must terminate in a horizontal position and on the same wall of the building.
- (2) The minimum distance between inlet and outlet flues is 150mm between centres at the outlet of the wall.
- (3) If the inlet and outlet pipes are required to be different length a ratio of 2:1 should be used as a maximum. ie. 2m inlet 4m outlet or vice versa, but it is recommended that the flue lengths are kept to similar lengths if at all possible.

The illustrations give some examples of flue installation:  
**NB** — When routing the flues around an external corner it is necessary to chase into the wall using a chisel etc. to allow the bends to follow the centre lines for the fixing clips. 20mm will be sufficient for the flue only. If protective ducting is used 60mm is necessary.

- (4) It is recommended that on longer flueing installations a sketch is made of the flue runs as a guide to cutting the pipes.
- (5) The exhaust flue pipe must not be closer than 25mm (1in) to combustible material. Additional clearance must be provided when passing the flue through timber walls.

Detailed recommendations on protection of combustible materials are given in BS 5440: Part 1. (Specifically sect. 8.2.3). Where the outlet flue is to be routed along or adjacent to a combustible wall a ducting kit is available to protect the wall. The kit is available in 1m lengths and also a 90° bend.

- (6) The exhaust flue pipe must be routed so that it cannot be touched by the user. If this is unavoidable a ducting kit is available from Maxol to protect the flue pipe.
- (7) Remember both flue pipes must enter the appliance in the same direction.
- (8) Remember the flues must terminate in a horizontal position and on the same wall of the building.
- (9) Installations with long flue runs may give rise to a build up of condensation in the outlet flue pipe. This must not be allowed to run back into the boiler. When installing long flue runs angle the flue AWAY from the boiler using a 25mm drop for every 4m horizontal run.
- (10) The maximum vertical flue run is 1.5 metres to the first 90° bend.



## 5.2 Base/Side/Top flueing arrangements (MDF)


### 5.2.1 Installing the Flue Box

— For a kitchen cupboard installation see sect. 5.2.5.

- (i) The flue box template must be positioned at a minimum dimension from any wall or surface depending on the direction of incoming flue pipes — see below.

Flue pipes from:	Minimum distance from edge of template to wall or surface
LHS	250mm between RHS & wall
RHS	150mm between LHS & wall
Top	400mm between bottom & floor
Bottom	300mm between top & ceiling

- (ii) Position and fix the template provided for fixing the flue box, drill and plug where marked using the plugs and screws provided in the plastic bag. Ensure the template is horizontal and on a flat sound wall. Note that the flue pipes should terminate at the positions shown on the template.



### 5.2.2 Installing the Flue pipes

- (i) Remember the minimum distance between inlet and outlet flues is 150mm (6in) in any direction at the outlet of wall — between centres.
- (ii) The vertical distance between the side flue connections on the boiler is 270.4mm. The horizontal distance between Base/Top connections is 95mm.
- (iii) There is no maximum distance required between the flue terminals.
- (iv) After deciding where the flues will terminate drill the two flue openings using a core drill if possible. Ensure no breakout or if possible make good externally.  
CORE DRILL DIAMETER 65mm.

- If the flues exit close to a corner it may be easier to:
- (a) drill a pilot hole from inside the property and carry out the core drill operation from outside.
- or
- (b) use a masonry chisel to make the flue openings and make good afterwards.

Ensure that during the cutting operation the masonry produced does not cause any damage to property or injury to persons.

- (v) Fix the pipe support clips along the pipe routes or fit the optional protective ducting (see separate instructions). Ensure that any bends are securely held at each end by the clips provided.

**NB.** No. 6 wood screws and plugs are supplied for fixing the clips.


---

### 5.2.3 *Assembling the Flue Pipes*


---

#### IMPORTANT

- The flue pipes must be assembled with plain end of pipe (or bend) nearest the appliance and the female socket end furthest from the appliance.
  - Always adjust the length of pipes by cutting the plain end. Remove any burrs both inside and out.
  - Keep the flue pipes clean and free of oil or grease or swarf.
- (i) **ALWAYS START AT THE WALL.** Take the two lengths of flue pipe that have the flue terminal inserts and lipseals (in boiler pack). Measure the wall thickness. Then measure from the lip seal at the end nearest the outlet, and mark the wall thickness onto the pipe minus 10mm. Minimum flue length is 300mm (12in) from appliance to external wall. Check minimum service clearances laid out in Section 3 — Technical Data. Do not cut at this stage unless the flue run requires only one length of flue pipe, — then mark and cut the ducts so that they terminate at the appropriate position on the template, as in 5.2.4. If more than one length of flue pipe is required continue.
- (ii) Fit the two wall mounting fixing clips approx. 300mm (12in) or less from the wall in line with the inlet and outlet pipe runs. Feed the tie straps through the brackets.








- (iii) Push the tubes through the support clips into the wall up to the mark. Visually check that the pipes have protruded through the wall by 25mm and that the lip seal is located in the wall around its circumference. If there are any gaps present make good at this stage externally.

Join the tie straps around the pipes and pull tight so that the straps prevent any movement of the flue pipes. Any excess may be cut off.

- (iv) Smear a film of silicone sealant (approx. 0.5mm thick) onto the male end of the pipes (approx. 40mm along). For safe use of the silicone rubber solution see Sect. 5.2.4.1.

Repeat this operation with every male pipe end, (except the final pieces of flue pipe) as the flue pipe runs are assembled.

- (v) Cut the next lengths of flue pipe or elbows for inlet and outlet, (if required) and slide into the support clips with the female end towards the wall.
- (vi) Push the flue pipes firmly together ENSURING the pipes do not protrude further through the wall.
- (vii) Continue this procedure until the flue runs are complete except for the last length to the flue box.
- (viii) Remember on long horizontal flue runs to angle the outlet flue AWAY from the boiler so any condensate will run out from the boiler.



## 5.2.4 Connecting the flues to the flue box

Depending on the directions of the flue entry the following are the dimensions for flue length from elbow to case. (See diagrams).


Add on the dimensions from the diagrams below to the last flue lengths before cutting and fixing (depending on the incoming flue directions).

At this stage you should have the template fixed to the wall and both flue runs completed and terminating at the positions marked on the template as required.

### Top Entry

Inlet (upper connection) — 15mm


Outlet (lower connection) — 285mm



### Bottom Entry

Inlet — 395mm


Outlet — 125mm



### Left Hand Side Entry

Inlet — 135mm


Outlet — 230mm



### Right Hand Side Entry

Inlet — 115mm

Outlet — 20mm



---

## 5.2.4.1 Elbows

---

Ensure you have the correct elbows in your kit.


### Using the silicone rubber solution

- (1) Wear gloves and/or goggles where there is a risk of accidental contact.
- (2) Store below 30°C and use in a well ventilated area.
- (3) If any silicone is spilt wipe any excess up with a soft cloth and allow to cure. Then scrape up any excess.

- (i) Smear a film of silicone (approx. 0.5mm thick) onto the ends of the pipes, (approx. 20mm along).
- (ii) Remove the template.
- (iii) Take the flue box, take the elbows and align the elbows to their required orientation with the two fixing screws. Inlet elbow at the TOP, outlet elbow at the BOTTOM.

NOTE — the elbows cannot be fitted incorrectly.

- (iv) Carefully knock out the two plates where the flues will be entering the box and discard. This is best achieved by tapping the disc with a hammer away from the joining tabs then twist loose with finger and thumb.
- (v) Slide the flue box over the flue pipes and locate the flue pipes fully into the elbows ensuring a good seal. Secure the flue box to the wall using the screws provided. The elbows may be viewed through the front box to ensure correct location.




## 5.2.5 Additional requirements for the installation of the Microturbo MDF in a kitchen cabinet

The Microturbo MDF has been specifically designed to fit into a kitchen wall cabinet which must be at least 535mm high (internally) and 400mm wide (internally). The boiler must be fixed to the rear wall and not the back panel of the unit. (See diagram).


If the flues are to be routed along the top of the kitchen unit a minimum distance of 320mm is required between the ceiling and the unit top.

The flue outlet pipe must be kept a minimum distance of 25mm from any combustible surface.



### 5.2.5.1 Installing the Flue Pipes & Box — KITCHEN CABINET ONLY


As there may be insufficient room to enable the flue box to be installed as in the previous text, it may be easier to introduce the last flue lengths into the elbows/flue box assembly before fixing the flue box to the wall. In this case leave sufficient room to enable these flue lengths to fit into the flues fitted previously. These requirements must be taken into consideration before finalising the flue positions. The flue box must be positioned in the cabinet to cover the minimum clearances required for servicing — Sect. 3.




---

### 5.3 Fixing the boiler to the Flue Box — MDF


---



- (i) Remove the boiler plinth, and remove two screws (1) to remove the boiler case. — The case is hinged at the top. Pull forward at the base and lift off.



- (ii) Remove the two screws securing the tray (2) and the plug in connector (3).  
(iii) Unscrew the phial clipscrew and remove the clip (5) pull out both thermostat phials.  
(iv) Pull out the spark ignitor lead from the control box (6).  
(v) Remove tray.





- (vi) Pick up the boiler and line up with the two studs on the flue box. Push the boiler into position checking that the inlet and outlet pipes enter the elbows and make a seal. Secure with the two pillar nuts and two screws provided in the boiler plastic bag assembly.

# Installation of Rear Flue Model (RF)

This model has the option of rear flueing only. The flues can be run from 180mm (7in) to 380mm (15in) as supplied with a maximum length of 610mm (24in).


## 5.4 Prepare the boiler

- (i) Remove the boiler plinth, and remove two screws (1) to remove the boiler case. — The case is hinged at the top. Pull forward at the base and lift off.
- (ii) Unscrew the two tray captive screws a quarter turn each (2). Pull the tray forward. Remove the spark ignitor (6) and plug in connector (3).
- (iii) Unscrew the phial clip screw and remove the clip (5). Remove both phials.
- (iv) Pull off the two pressure sensing tubes (7).
- (v) Remove tray.



## 5.5 Wall Mounting Template

- (i) Tape the template into position taking into account the minimum installation requirements detailed in section 3. Ensure the template is square.
- (ii) Drill and plug the fixing holes in the positions marked using the plugs provided in the fixing kit.
- (iii) Cut the two flue holes (preferably using a 52mm — 2in core drill) in the positions marked. Ensure both faces are clean and free from breakout — make good if necessary.
- (iv) Remove template.






---

## 5.6 Fixing the Flue Terminals

---

- (i) Two lengths of flue pipe are provided of lengths 381mm (15in) with flue terminals at one end.
- (ii) Measure the wall thickness and mark it onto the flue pipes **W**.
- (iii) Cut the flue pipes and remove the burrs both inside and outside. **CUT AT OPPOSITE END TO THE FLUE TERMINAL**. Ensure any swarf is removed.
- (iv) Smear a film of silicone sealant (approx. 0.5mm thick) onto the ends of the pipes (approx. 40mm along).
- (v) Push the plain ends of the pipes into the two connections at the rear of the boiler. Drill through the sides of the socket with a 2.8mm drill and secure the pipes with the two No.6 screws provided.



---

## 5.7 Wall Mounting the Boiler

---

- (i) Offer the boiler and flue pipes assembly to the wall and push the flues and flue seals through until the boiler meets the wall. Secure with the four screws provided in the plastic bag assy.
- (ii) Visually check that the flue terminals project 25mm on the outside wall.



---

## 6 Water Connections


---

---

### *The Flow and Return Connections*

---

These are suitable for 22mm copper pipework with compression fittings integral with the heater (Note: as despatched the ends are blanked with plastic or metal discs. These must be removed by unscrewing the nuts and substituted with the olives supplied in the ancillary components (Plastic bag.) The flow is the L.H. connection and both are situated at the top rear of the case.




---

## 7 Gas Connection

---


The gas connection to the appliance is Rc  $\frac{1}{2}$  ( $\frac{1}{2}$  in B.S.P.) and is situated at the rear left hand side of the base.

The Neva cock is supplied separately in the fitting kit.




# 8 Electrical Connection

- (i) Route the incoming cables to the bottom, rear, right-hand side through the grommets provided.
- (ii) Connect the electricity supply cable, pump cable and any external control cable to the terminal block and clamps.



WIRING DIAGRAM - MAXOL MICROTURBO 50/40HMDF



WIRING LEGEND:


R	- RED	Y	- YELLOW
PN	- PINK	BK	- BLACK
OR	- ORANGE	BR	- BROWN
BL	- BLUE	W	- WHITE
GRY	- GREY	GY	- GREEN/YELLOW

ELECTRICAL DATA - 240V ~ 50Hz - 55W - 3A FUSED.

WARNING - DISCONNECT MAINS POWER SUPPLY BEFORE ATTEMPTING ELECTRICAL MAINTENANCE.



WIRING DIAGRAM - MAXOL MICROTURBCU 40HRE



WIRING LEGEND:

- R - RED
- PN - PINK
- OR - ORANGE
- BL - BLUE
- GY - GREY
- P - PURPLE
- Y - YELLOW
- BK - BLACK
- BR - BROWN
- W - WHITE
- GY - GREEN
- R/W - RED/WHITE


ELECTRICAL DATA - 240V ~ 50Hz - 55W - 3A FUSED.


WARNING - DISCONNECT MAINS POWER SUPPLY BEFORE ATTEMPTING ELECTRICAL MAINTENANCE.

# FUNCTIONAL FLOW DIAGRAM MAXOL MICROTURBO 40HRF

## LEGEND

- W - WHITE
- BL - BLUE
- BK - BLACK
- BR - BROWN
- R - RED
- O - ORANGE
- PN - PINK
- GRY - GREY
- G/Y - GREEN/YELLOW
- P - PURPLE
- R/W - RED/WHITE





### Notes

- (a) The incoming mains supply cable is connected to the terminals L - live (Brown wire), N - neutral (Blue wire),  $\perp$  - earth (Green/Yellow wire).
  - (b) No controls must be connected directly in the supply line to the terminal marked L.
  - (c) The length of the conductors between the cord anchorage and the terminals must be such that the current carrying conductors become taut before the earth conductor (i.e. the earth wire must be slightly longer than, both live and neutral when connecting into the terminal block).
  - (d) The pump must be connected to the terminal block at terminals (pump live), (pump neutral) and (pump earth) to allow the overrun thermostat to be operative. All wiring for the pump must be suitable for 240V.
  - (e) If external controls are used remove link wire, and connect the switched live to terminal, and earth to  $\perp$  as in the diagram; — ensure all cables are secured.
- (iii) Refit the controls tray and secure using two screws (2) as in section 5.3 MDF, section 5.4 RF.
  - (iv) Join together the plug in connector (3).
  - (v) Connect the spark ignitor lead (red sleeve) to the control box (6).
  - (vi) Replace thermostat phials & retaining clip.
  - (vii) Fault Finding — see pages 30 and 31 for fault finding charts.



On completion of an installation service/fault finding task which has required the breaking and making of electrical connections complete the following electrical safety checks with a suitable meter.

- A - Earth Continuity
- B - Polarity
- C - Resistance to earth must be replaced.
- D - Short Circuit.

**NOTE** — The pump overrun switches on pump L.

## 9 Commissioning the Boiler

- (a) Ensure the system is filled with water.
- (b) Check that all drain cocks are closed and any valves in the flow and return are open.
- (c) Remove the screw on the burner pressure test point on the injector elbow assy. and connect a pressure gauge.
- (d) Turn ON the electricity mains supply. Red lockout light may be illuminated. Press reset switch to restart.
- (e) Switch the boiler mains ON/OFF switch to ON. Ensure that all external controls are calling for heat.
- (f) The boiler mains switch should illuminate and the fan will start running. After a few seconds the solenoid valve will open and the intermittent spark will commence until the main burner ignites.
- (g) Once the main burner is lit the amber neon (burner on) will illuminate.
- (h) If for any reason the main burner fails to light the amber neon will extinguish and the red lockout neon will illuminate. To restart wait 20 sec., press and release the reset button. The appliance will restart from (f). See fault finding chart if this does not happen. If the appliance still fails to ignite contact the manufacturer for advice.
- (i) Test for gas soundness around all the boiler gas carrying components.
- (j) After 10 minutes the burner pressure can be checked. The boiler is factory set to the required input and CANNOT BE ADJUSTED. — The governor is factory sealed, do not break the seal.



### HEAT INPUT & OUTPUTS


1. MDF - 300mm Flue
    - Nominal heat input = 14.51kW
    - Nominal heat output = 11.72kW
    - Burner press (hot) = 4.3mb  $\pm$  0.5mb
  2. MDF — Max Flue Length
    - Nominal heat input = 14.51kW
    - Nominal heat output = 11.72kW
    - Burner press (hot) = 4.3mb  $\pm$  0.5mb
    - Mean heat output = 40,000 Btu/h.
    - The burner pressure changes with flue length but should be between the ranges above depending on flue length.
  3. RF — All Flue Length
    - Nominal heat input = 14.51kW
    - Nominal heat output = 11.72kW
    - Mean heat output = 40,000 Btu/h.
    - Burner press (hot) = 10.3mb  $\pm$  0.5mb
    - Time for 100l of gas = 4min 20secs
    - Time for 1ft<sup>3</sup> of gas = 74 secs
- (k) Temporarily switch off, remove the pressure gauge and retighten test point screw. Re-light and check for gas soundness at test point screw.
  - (l) Turn OFF boiler ON/OFF switch.



---

## 10 Fitting the Case

---



- (a) Lift the boiler case up to the boiler and hang the case on the top back rail at an angle.
- (b) Position the case at the bottom and secure with the two screws provided.
- (c) Push back the plinth onto the guide rails.


---

## 11 General Checks

---


- (a) With the water system hot check all water connections for soundness, rectifying where necessary.
- (b) Add the appropriate cleanser (see 2.2 j) in accordance with the manufacturer's instructions.  
Turn off gas, water and electricity supplies and drain down completely to flush the system. A drain cock is fitted on the return pipe.
- (c) Refill the system including a corrosion inhibitor (see 2.2 j) in accordance with the manufacturer's instructions, and vent.
- (d) Balance the system and correctly set the bypass for the correct design temperature rise (11°C temperature rise across the boiler under any conditions of use).
- (e) Set the boiler thermostat to the systems required setting. Normally position 4 will suffice for a conventional system.
- (f) Handing over — Instruct the user in the operation of the boiler and any system controls that are relevant. Hand over both the Users and Installation and Service Instructions and stress the necessity of regular annual servicing.

START



# FAULT FINDING CHART MAXOL MICROTURBO 40H MDF

START



FAULT FINDING CHART  
 MAXOL MICROTURBO  
 40H RF

---

# Service Instructions

---

To ensure safe, efficient operation of the appliance, it is necessary to carry out routine servicing at regular intervals. The frequency of servicing will depend upon the particular installation conditions and the use to which the boiler is put, but in general, once a year should be adequate.

**IMPORTANT:** Before commencing any servicing or exchange of components always turn off the gas supply and isolate the electricity supply. After completing any service work always check for gas soundness. Ensure the appliance is cold.

---

## 1.0 Routine Annual Servicing

---

---

### 1.1 Remove the case Fig. 1

---

- (i) Remove the boiler plinth.
- (ii) Remove two screws (1), hinge forward the case and lift off.
- (iii) Put the case in a safe position.

A combustion sampling point has been provided on the front cover **bottom** section. Remove the hex. screw to access. See Fig. 2.




Fig. 1

---

### 1.2 Remove combustion chamber cover Fig. 2

---

- (i) Remove the 7 brass wing nuts securing the front cover. (1)
- (ii) Carefully remove the front cover and check the insulation panel (2) and also the fibre sealing gasket. (3) — replace if necessary.




Fig. 2

---

### 1.3 Cleaning the combustion chamber Fig. 3

---




Fig. 3

- (i) Check the LH, RH side and rear (1,2 & 3) insulation panels — replace if necessary.
- (ii) Check the upper insulation panels (4) — replace if necessary.
- (iii) Inspect and clean the burner (5) — lightly brush away any debris with a soft brush and ensure that all ports are free from obstruction.
- (iv) Inspect and clean the heat exchanger (6) from above and below using a soft brush to remove any debris.
- (v) Slide out the baffle (7) and inspect and clean, ensuring that the mesh is clear from obstruction.
- (vi) Inspect the fan rotor (8) and fan seal (9) and clean with a soft brush if necessary.
- (vii) Replace the baffle (7) sliding it between the combustion chamber base and the four screws (10).

---

### 1.4 Check the Spark & Sensing Positions Fig. 4

---

Ensure that the dimensions stated in Fig. 4 are still in tolerance, if necessary re-position carefully the probes taking care not to damage the ceramic insulation.

It may be necessary to remove the spark electrode to set the gap — see section 2.5.





Fig. 4

FRONT VIEW



PLAN VIEW

---

## 1.5 *Replace the combustion chamber cover*

---

- (i) Carefully locate the door on the seven studs and push back to the combustion chamber taking care not to damage the threads.
- (ii) Re-locate the seven wing nuts and tighten fully. Check that the door is sealed completely around the combustion chamber front.

---

## 1.6 *Check and Clean the Injector Fig. 5*

---

- (i) Disconnect the feed pipe from the injector block (1).
- (ii) Remove the two screws securing the injector block to the mixing box (2).
- (iii) Remove the injector block assembly and check the injector. Clean or replace if necessary.
- (iv) Re-assemble in reverse order ensuring the rubber gasket (3) provides a good seal.




Fig. 5

---

## 2.0 Component Exchange

---

### 2.1 Control Tray removal Fig. 6

---

The following components are mounted on a slide out tray:

- (1) Control box.
- (2) Pump overrun thermostat.
- (3) Boiler thermostat.
- (4) Appliance switches.
- (5) Amber neon and Red l.e.d. indicator lights.
- (6) Pressure switch and pressure switch bracket (RF Models only).




Fig. 6

To remove the tray: Figs 7 & 8

- (i) Unscrew the two tray captive screws a quarter turn each (2). Pull the tray forward.
- (ii) Remove the spark ignitor from the control box (6).
- (iii) Remove the plug in connector (3).
- (iv) Unscrew the phial clip screw and remove the clip (5) pull out both thermostat phials.
- (v) Slide out the tray with the thermostat phial and move to a convenient place.
- (vi) After completion of task re-assemble the tray in reverse order.

**NOTE**

A pressure switch is fitted on RF models only. After removing the thermostat clip and phials (5) pull off the red and white sensing tubes (7). The tray can now be removed.




Fig. 7



### 2.1.1 Control Box Fig. 9

- (i) Remove the plug in connector (2).
- (ii) Remove the earth and flame sensing spade connectors (1).
- (iii) Remove the two hex. pillar nuts (3).
- (iv) Remove the box.
- (v) Replace in reverse order.




Fig. 9

### 2.1.2 Pump Overrun Thermostat Fig.10

- (i) Disconnect leads 2, 3, 4.
- (ii) Unscrew from tray, (screws on tray base).
- (iii) Replace thermostat & re-connect leads in correct order:-  
4 - ~~white/red~~  
*brown*, 2 - ~~brown~~  
*white/red*, 3 - yellow.




Fig. 10

---

### 2.1.3 Boiler Thermostat Fig. 10A

---

- (i) Pull off the thermostat knob (4).
- (ii) Remove the two screws (5) securing the thermostat body.
- (iii) Re-assemble in reverse order ensuring the phial tube is not kinked.

---

### 2.1.4 Appliance Switches Fig. 10A

---

- (i) Press out the switch assembly and note the position of the leads.
- (ii) Remove the leads and replace the switch in the correct orientation.
- (iii) Re-assemble in the reverse order using the wiring diagram if necessary to re-locate the wiring correctly.

---

### 2.1.5 Indicator Lights Fig.10A

---

- (i) Push out the indicator assembly.
- (ii) Remove the tags — noting position of the wires.
- (iii) Replace the indicator ensuring correct polarity (plastic pip to the top).
- (iv) Replace the tags ensuring correct polarity.
- (v) Push back the indicator.

---

### 2.1.6 Pressure Switch Fig.10A — RF Only.

---

- (i) Remove the three wires from the switch:  
NC — Red/White  
C — Purple  
NO — Black
- (ii) Remove the two fixing screws (2) at either top or side.
- (iii) Remove the pressure switch and disconnect the red & white sensing tubes.
- (iv) Refit sensing tubes to new switch Red - + and White - - .
- (v) Reassemble in reverse order.




Fig. 10A

## 2.2.1 Double Solenoid Valve MDF only — Fig. 11

- (i) Remove the control tray assembly as detailed in section 2.1
- (ii) Disconnect the nuts fixing the sensing pipes to the combustion chamber. These are on the inlet mixing box and at the flue collector.
- (iii) Disconnect the inlet connection at the Neva cock.
- (iv) Disconnect the burner feed pipe from the valve top (1).
- (v) Remove the wiring tags (3) noting their positions.
- (vi) Remove the two fixing screws holding the bracket to the boiler.
- (vii) Remove the valve and sensing pipes complete.
- (viii) Remove the valve mounting bracket two screws.
- (ix) Remove the sensing pipes by unscrewing the fixing nuts (2).
- (x) Replace in the reverse order.
- (xi) Remove the burner pressure test point and fit a manometer. Fig 12 (3).
- (xii) Follow the commissioning procedure (sect. 9 (a) to (h) ) — once the amber neon illuminates set the burner pressure as on the data badge. The burner pressure is adjusted as follows:
  - 1) Remove governor cap and make sure the gas valve governor is screwed fully in. Replace governor cap to seal. Fig. 11 (5)
  - 2) Set offset screw clockwise to decrease, anticlockwise to **increase** to 6.0mbar + 0 – 0.1mbar Fig. 11 (4).
  - 3) Remove the gas valve governor cap and set the valve governor clockwise to increase, anticlockwise to **decrease** to 6.2mbar + / – 0.1mbar Fig 11. (5).
  - 4) Replace governor cap. The burner pressure should be within the manufacturer's tolerance stated on the data badge. If not contact the manufacturer.
- (xiii) Check for gas soundness at this stage.
- (xiv) Turn off the mains on/off switch. Remove the pressure gauge and re-tighten test point screw.
- (xv) Place the thread sealing solution provided on the offset screw and replace.
- (xvi) Re-light and test for gas soundness at the test point screw.




Fig. 11

*Inlet appliance*

---

## 2.2.2 Double Solenoid Valve RF only — Fig. 11A

---




Fig. 11 A

- (i) Remove the control tray assembly as detailed in section 2.1
- (ii) Disconnect the inlet connection (1) at the Neva cock.
- (iii) Remove the two hexagonal headed screws (2) to free the inlet pipe.
- (iv) Remove the wiring tags and earth screw noting their positions.
- (v) Remove the two screws.
- (vi) Pull the solenoid valve forward from its base and remove from the bracket at the top (4). Note the two grub screws used for location.
- (vii) Unscrew the four screws (5) and remove the inlet pipe and 'O' ring.
- (viii) Replace in the reverse order. Ensure the hexagonal head screws are replaced in the correct orientation.
- (ix) Remove the burner pressure test point and fit a manometer. Fig 12 (3).
- (x) Follow the commissioning procedure (sect. 9 (a) to (h) ) — once the amber neon illuminates set the burner pressure as on the data badge. The burner pressure is adjusted by removing the governor sealing screw and rotating the governor screw  
— Burner pressure =  $10.3 \text{ mb} \pm 0.5 \text{ mb}$
- (xi) Check for gas soundness at this stage.
- (xii) Turn off the mains on/off switch. Remove the pressure gauge and re-tighten test point screw.
- (xiii) Place the thread sealing solution provided on the governor sealing screw and replace.
- (xiv) Re-light and test for gas soundness at the test point screw.




Fig. 12

---

## 2.3 Injector Fig. 12

---

- (i) Disconnect the feed pipe from the injector block (1).
- (ii) Remove the two screws securing the injector block to the mixing box (2).
- (iii) Remove the injector block assembly and replace it in the reverse order.

---

## 2.4 Overheat Thermostat

### Fig. 13

---

- (i) Remove the two tags (1).
- (ii) Remove two screws (2).
- (iii) Replace overheat thermostat.
- (iv) Re-assemble in the reverse order.


---

## 2.5 Spark Electrode and Flame Sensing Probe Fig. 13

---

- (i) Remove the seven wing nuts securing the combustion chamber front cover and carefully remove taking care not to damage the fibre seal. Fig. 2.
- (ii) Remove the wire tags on each probe. (3)
- (iii) Remove the two screws securing each probe. (4)
- (iv) Remove the probes taking care not to damage the insulation.
- (v) Re-assemble in reverse order and then re-set the positions as in Fig. 4.

Fig. 13



---

## 2.6 Burner Fig. 14

---

- (i) Remove the seven wing nuts securing the combustion chamber front cover and carefully remove taking care not to damage the fibre seal. Fig. 2.
- (ii) Remove the top insulation panels (1). Remove the spark probes (section 2.5).
- (iii) Remove the six nuts on combustion chamber top (2). RF only remove white sensing tube.
- (iv) Pull the burner down carefully and pull out taking care not to damage the top fibre seal.
- (v) Re-assemble in reverse order and reset the probe positions as in Fig. 4.

---

## 2.7 Insulation Panels

---

- (i) Remove the probes as in section 2.5.
- (ii) Remove the burner as in section 2.6.
- (iii) Pull out the left hand and right hand side insulation panels noting the cut outs at the back.
- (iv) Pull out the rear panel.
- (v) Unscrew the nut and washer on the front door and remove the door panel and fibre seal.
- (vi) Re-assemble in reverse order taking care to align front door panels correctly and also to locate the rear panel correctly (cut out locations to the bottom).




Fig. 14

---

## 2.8 Fan Fig. 15

---

- (i) Remove the seven wing nuts securing the combustion chamber front cover and carefully remove taking care not to damage the fibre seal. Fig 2.
- (ii) Slide out the baffle (1) from between the four screws (2) and combustion chamber base.
- (iii) Remove controls tray as detailed in section 2.1.
- (iv) Remove the wiring tags including the earth lead from the fan.
- (v) Remove the four screws (2) from combustion chamber sides.
- (vi) Pull the fan assembly out of the inlet and outlet seals and remove.
- (vii) Remove the two screws holding the fan mounting bracket and transfer to the replacement fan.
- (viii) Pull off the fan outlet reducer and transfer to the replacement fan.
- (ix) Re-assemble in the reverse order.

---

## 2.9 Heat Exchanger Fig. 15

---

- (i) Remove gas valve sensing pipes. Section 2.2.1 / 2.
- (ii) Remove Overheat Thermostat. Section 2.4.
- (iii) Remove Spark Electrode and Flame Sensing Probe. Section 2.5.
- (iv) Remove Burner. Section 2.6.
- (v) Remove Insulation Panels. Section 2.7.
- (vi) Remove Fan. Section 2.8
- (vii) Disconnect the nut (3) from the inlet pipe to the injector assembly.
- (viii) Remove the two hexheaded screws from the gas valve top (2) and remove the inlet pipe Fig.11.
- (ix) Drain the water system and disconnect at the flow and return union connections.
- (x) Disconnect the two locknuts from the heat exchanger brackets and remove.
- (xi) Remove the four combustion chamber retaining screws and remove the heat exchanger assembly.
- (xii) Remove the six screws (5) on the fan seal clamp and transfer the seal and clamp to the replacement heat exchanger assembly.
- (xiii) Re-assemble in reverse order.
- (xiv) Check for water soundness.





Fig. 15



Short List of Parts for Maxol Microturbo 40H — RF/MDF

Key No.	Part No.	GC No.	Description	Qty.
12	58100	379 444	Thermostat RANCO	1
15	58102	379 446	Control Box — Honeywell — (MDF)	1
15A	58398		Control Box — Honeywell — (RF)	1
17	58260	379 447	Re-set Switch — Eaton	1
18	56874	378 339	Neon Switch — Eaton	1
21	57219	378 340	Neon Orange — ARCO.	1
22	58264	379 449	Neon Red — ARCO.	1
27	58104	294 071	Gas Valve — SIT — (MDF)	1
14	58495		Gas Valve — Honeywell	1
43	57431	370 274	Fan — E.B.M. — including 'O' Ring.	1
69	58544		Injector Elbow Assembly (MDF)	1
69A	57036	370 292	Injector Elbow Assembly (RF)	1
70	57039	370 293	Injector Elbow Gasket	1
86	57516	378 349	Overheat Thermostat	1
13	58101	379 445	Pump Overrun Stat — RANCO	1
11	57974	378 775	Pressure Switch — Honeywell — (RF)	1



M A X O L

microturbo

Burco Maxol

A member of the Glen Dimplex Group

Rose Grove, Burnley, Lancashire BB12 6AL. Telephone: (01282) 427241. Telex: 63275 BDAL. Fax No. 01282 8312

Maxol maintain a policy of continuous product improvement and reserve the right to change this specification without notice. The statutory rights of the consumer are not affected.

Bitech No. 8/17325/0 Maxol Part No. 58507 Issue D.