



# MINORCA KC - KR - KRB 24

INSTALLATION, USE AND MAINTENANCE



**fondital**  
BE INNOVATIVE

**EN**

Translation of the  
original instructions (in  
Italian)

IST 03 C 971 - 01

Dear Sirs,

thank You for choosing and buying one of our products. Please read these instructions carefully in order to properly install, operate, and maintain the product.



**WARNING**

---

- **We inform users that:**
  - **Boilers shall be installed by an authorised company under the requirements set forth by the prevailing rules, in full compliance with the prevailing regulations and standards.**
  - **Anyone entrusting installation to an unqualified installer will be subject to administrative sanctions.**
  - **Boilers must be maintained by qualified personnel only, under the requirements set forth by the prevailing rules.**
- 

**We hereby inform you that certain models, versions and/or accessories relevant to the products this manual refers to, might not be available in some countries.**

**Therefore, it is recommended to contact the manufacturer or the importer in order to get the necessary information about the actual availability of such models, versions and/or accessories.**

**The manufacturer reserves the right to modify the products and/or its components as deemed necessary, in any moment and without prior notice.**

**This instruction manual is available in two languages, Italian and English, without prejudice to the prevalence of Italian language in case of differences in translation and/or dispute on construction of the text.**

## General notes for installing and maintenance technicians, and users

This instruction manual is an integral and essential part of the product. It shall be supplied by the installer to the user who shall keep it carefully to consult it whenever necessary.

This document shall be supplied together with the equipment in case the latter is sold or transferred to others.



### DANGER

---

**This equipment has been manufactured to be connected to a room heating system and to a DHW distribution system.  
Any other use shall be considered unsuitable and dangerous for people, animals, and/or property.**

---

The equipment shall be installed in compliance with the prevailing standards and in accordance with the manufacturer's instructions specified in this manual: the manufacturer will not be held responsible for injuries to people and animals and/or damages to property resulting from an incorrect installation.

Damage and/or injury caused by incorrect installation or use and/or damage and/or injury due to non-observance of the manufacturer's instructions shall release the manufacturer from any and all contractual and extra-contractual liability.

Before installing the boiler, check that the technical data correspond to the requirements for its correct use in the system.

Check that the boiler is intact and it has not been damaged during transport and handling. Do not install equipment which is clearly damaged and/or faulty.

Do not obstruct the air intake openings.

Only original accessories or optional kits (including the electric ones) are to be installed.

Properly dispose of the packaging as all the materials can be recycled. The packaging must therefore be sent to specific waste management sites.

After removing the packaging, make sure that its elements (clips, plastic bags, foam polystyrene etc.) are not left within the reach of children as they are potential hazard sources.

In the event of failure and/or faulty functioning, switch off the boiler. Do not attempt to make repairs: contact qualified technicians.

Original parts must be used for all repairs to the boiler.

Non-observance of the above requirements may affect the safety of the boilers and endanger people, animals and/or property.



### WARNING

---

**The boiler must be serviced periodically as indicated in the relevant section of this manual.  
Appropriate boiler maintenance ensures efficient operation, environment preservation, and safety for people, animals and objects.  
Incorrect and irregular maintenance can be a source of danger for people, animals and property.**

---

The user is strongly advised to have the system serviced and repaired by qualified personnel, satisfying all prevailing law requirements, and trained to properly carry out these operations.

In the event of long periods of inactivity of the boiler, disconnect it from the electrical power mains and close the gas cock. **The electronic antifreeze function will not be operative with the device disconnected from the electric power supply and gas cock closed.**

Should there be a risk of freezing, add antifreeze: it is not advisable to drain the system as this may result in damage; use specific anti-freeze products suitable for multi-metal heating systems.



**DANGER**

---

**With gas fired boilers, take the following measures if you smell gas:**

- **Do not turn on or off electric switches and do not turn on electric appliances.**
- **Do not ignite flames and do not smoke.**
- **Close the main gas cock.**
- **Open doors and windows.**
- **Contact a Service Centre, a qualified installer or the gas supply company.**

**Never use a flame to locate a gas leak.**

**The boiler is designed for installation in the countries indicated on the technical data plate: installation in any other country may be a source of danger for people, animals and/or property.**

**The manufacturer will bear no contractual and tortious liability for failure to comply with all the instructions above.**

---

|           |  |           |
|-----------|--|-----------|
| <b>1.</b> | <b><i>Instructions for the user</i></b> .....  | <b>8</b>  |
| 1.1       | <i>Control panel</i> .....   | 8         |
| 1.2       | <i>Interpreting boiler status from display indications</i> .....                             | 10        |
| 1.3       | <i>Boiler operation</i> .....  | 11        |
| 1.4       | <i>Boiler shut-down</i> .....  | 14        |
| 1.5       | <i>Maintenance</i> .....   | 17        |
| 1.6       | <i>Notes for the user</i> .....  | 17        |
| <b>2.</b> | <b><i>Technical features and dimensions</i></b> .....  | <b>18</b> |
| 2.1       | <i>Technical features</i> .....  | 18        |
| 2.2       | <i>Dimensions</i> .....  | 20        |
| 2.3       | <i>Boiler layouts</i> .....  | 22        |
| 2.4       | <i>Operating data</i> .....  | 25        |
| 2.5       | <i>General characteristics</i> .....   | 25        |
| <b>3.</b> | <b><i>Instructions for the installer</i></b> .....   | <b>27</b> |
| 3.1       | <i>Installation standards</i> .....  | 27        |
| 3.2       | <i>Choosing where to install the boiler</i> .....  | 27        |
| 3.3       | <i>Positioning the boiler</i> .....  | 27        |
| 3.4       | <i>Installing the boiler</i> .....   | 29        |
| 3.5       | <i>Boiler room ventilation</i> .....   | 29        |
| 3.6       | <i>Air intake and flue gas venting system</i> .....  | 30        |
| 3.7       | <i>Checking combustion efficiency</i> .....  | 34        |
| 3.8       | <i>Connection to gas mains</i> .....   | 35        |
| 3.9       | <i>Hydraulic connections</i> .....   | 35        |
| 3.10      | <i>Connection to electrical mains</i> .....  | 37        |
| 3.11      | <i>Connection to ambient thermostat (optional)</i> .....                                     | 37        |
| 3.12      | <i>Installation of the ambient probe (optional)</i> .....                                    | 37        |
| 3.13      | <i>Installation and operation with Open Therm Remote Control (optional)</i> .....            | 38        |
| 3.14      | <i>Selecting the operating range in heating mode</i> .....                                   | 38        |
| 3.15      | <i>Installation of the (optional) external probe and sliding temperature operation</i> ..... | 39        |
| 3.16      | <i>TSP parameters</i> .....  | 41        |
| 3.17      | <i>Filling the system</i> .....  | 45        |
| 3.18      | <i>Starting up the boiler</i> .....  | 46        |
| 3.19      | <i>Available head</i> .....  | 46        |
| 3.20      | <i>Wiring diagrams</i> .....   | 47        |
| 3.21      | <i>Adaptation to other gas types and burner adjustment</i> .....                             | 53        |
| <b>4.</b> | <b><i>Testing the boiler</i></b> .....   | <b>55</b> |
| 4.1       | <i>Preliminary checks</i> .....  | 55        |
| 4.2       | <i>Switching on and switching off</i> .....  | 55        |
| <b>5.</b> | <b><i>Maintenance</i></b> .....  | <b>56</b> |
| 5.1       | <i>Maintenance schedule</i> .....  | 56        |
| 5.2       | <i>Combustion analysis</i> .....   | 56        |
| <b>6.</b> | <b><i>Decommissioning, disassembly and disposal</i></b> .....                                | <b>57</b> |
| <b>7.</b> | <b><i>Malfunctions, possible causes and solutions</i></b> .....                              | <b>58</b> |
| 7.1       | <i>Troubleshooting</i> .....   | 58        |

|   |    |
|---|----|
| Fig. 1 Control panel .....                            | 8  |
| Fig. 2 Filler cock .....                              | 15 |
| Fig. 3 Dimensions KC/KR .....                         | 20 |
| Fig. 4 Dimensions KRB .....                           | 21 |
| Fig. 5 Model KR wiring diagram .....                  | 22 |
| Fig. 6 Model KC wiring diagram .....                  | 23 |
| Fig. 7 Model KRB wiring diagram .....                 | 24 |
| Fig. 8 Paper template .....                           | 28 |
| Fig. 9 Installation examples .....                    | 30 |
| Fig. 10 Type C13 - C33 coaxial ducts .....            | 32 |
| Fig. 11 Type C12 - C33 coaxial pipes dimensione ..... | 32 |
| Fig. 12 Split pipe kit 0KITSDOP00 .....               | 33 |
| Fig. 13 Dimensions for split pipes .....              | 33 |
| Fig. 14 Plugs position .....                          | 34 |
| Fig. 15 Hole position .....                           | 34 |
| Fig. 16 Connection to gas mains .....                 | 35 |
| Fig. 17 Condensate drain .....                        | 36 |
| Fig. 18 Thermoregulation curves .....                 | 40 |
| Fig. 19 Available head .....                          | 46 |
| Fig. 20 Wiring diagram KC .....                       | 47 |
| Fig. 21 Wiring diagram KR .....                       | 49 |
| Fig. 22 Wiring diagram KRB .....                      | 51 |
| Fig. 23 Gas diaphragm replacement .....               | 53 |
| Fig. 25 Adjusting CO2 value .....                     | 54 |

|   |    |
|---|----|
| Tab. 1 Adjustment specifications KC-KR-KRB 24 .....   | 25 |
| Tab. 2 General specifications KC .....  | 25 |
| Tab. 3 General specifications KR/KRB .....  | 26 |
| Tab. 4 KC-KR-KRB 24 combustion data .....   | 26 |
| Tab. 5 Boiler re-ignition temperature .....   | 38 |
| Tab. 6 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - I .....   | 41 |
| Tab. 7 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - II .....  | 42 |
| Tab. 8 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - III ..... | 43 |
| Tab. 9 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - IV .....  | 44 |
| Tab. 10 Relationship between "Temperature and Nominal resistance" for temperature probes .....              | 52 |
| Tab. 11 Flue CO2 content .....  | 54 |
| Tab. 12 Gas diaphragm diameter (mm) .....   | 54 |

## 1. Instructions for the user

### 1.1 Control panel




Fig. 1 Control panel

- A. DHW setting (+/- **DHW**).
- B. Operating status selection and parameter confirmation.
- C. Alarm reset and back to the starting page during parameter selection.
- D. CH water temperature (+/- **CH**) and parameter settings.
- E. LCD display.
- F. Heating system water pressure gauge.




| <b>Ref.</b> | <b>Description</b>                                   | <b>Steady on</b>   | <b>Flashing</b>   |
|-------------|--|--|---|
| 1           | Alphanumeric indicator                               | Temperature, parameter values and fault indication.                                    | Not used.   |
| 2           | Parameter indicator                                  | Indication of "parameter" inside the parameter menu.                                   | Not used.   |
| 3           | Flame lighting indicator                             | Lit flame indication.  | Not used.   |
| 4           | Central heating indicator                            | CH function activated.   | Display of CH temperature set-point or function in progress.      |
| 5           | RESET indicator                                      | It is possible to reset the boiler.  | Not used.   |
| 6           | Parameter editing indicator                          | During parameter editing, the wrench symbol stays on until the set datum is confirmed. | When edited parameter value is confirmed.                         |
| 7           | Flue cleaning function indicator (for the installer) | Flue cleaning function in progress.  | Indicates that you are accessing the flue cleaning function.      |
| 8           | DHW indicator  | DHW function activated.  | Display of DHW temperature set-point or DHW function in progress. |

## 1.2 Interpreting boiler status from display indications

### 1.2.1 Normal operation

Boiler in STANDBY mode



Boiler in SUMMER mode  
No active function  
Flow temperature displayed



Boiler in WINTER mode  
No active function  
Flow temperature displayed



Boiler in CENTRAL HEATING ONLY mode  
No active function  
Flow temperature displayed




Boiler in SUMMER mode  
Domestic hot water withdrawal  
DHW temperature displayed



Boiler in WINTER mode  
Domestic hot water withdrawal  
DHW temperature displayed



Boiler in WINTER mode  
CH function active  
Flow temperature displayed



Boiler in CENTRAL HEATING ONLY mode  
CH function active  
Flow temperature displayed



### 1.2.2 Malfunction

To identify any malfunctions, refer to paragraph *Troubleshooting* on page 58.

## 1.3 Boiler operation

### 1.3.1 Switching on



#### DANGER

---

**It is presumed that the boiler has been installed by a qualified installer, it has been commissioned and is ready to operate correctly.**

---

- Open the gas shut-off cock.
- Turn the master switch installed ahead of the boiler to ON.
- The display turns on and indicates the function currently active (see *Interpreting boiler status from display indications* on page 10).
- Select the boiler operating mode: OFF/SUMMER/WINTER/CH ONLY (see *Selecting the operating mode* on page 11).
- Set desired CH temperature (see *CH function* on page 11).
- Set desired DHW temperature (see *DHW function* on page 12).
- Set the desired room temperature on the ambient thermostat inside the home (if installed).
- If an ambient temperature probe or an external probe is available, set the desired ambient temperature.



#### WARNING

---

**After a prolonged period with the boiler not in use, and with LPG fired boilers in particular, some starting difficulty may be encountered.**

**Before starting the boiler switch on another gas powered device (e.g. kitchen range).**

**Beware that even by following this procedure, the boiler might still experience some starting difficulties and shut down once or twice. Press the "RESET" button to restore boiler operation.**

---

### 1.3.2 Selecting the operating mode

To select the boiler operation mode press **B** Operating mode selection.

Whenever button is pressed, the following modes are enabled in sequence: "SUMMER", "WINTER", "CH ONLY", "OFF".

"SUMMER" operating status

When the "SUMMER" mode is enabled, only the DHW production function is active.

"WINTER" operating status

When the "WINTER" mode is enabled, both DHW and CH functions are active.

"CH ONLY" operating status

When the "CH ONLY" mode is enabled, only the heating water production function is active.

"OFF" operating status

When the "OFF" mode is enabled, no function is active.

### 1.3.3 CH function


To set the heating water temperature, press +/- **CH** buttons.

Heating temperature adjustment range depends on the selected operating range.:

- standard range: from 20°C to 78°C (pressing **CH +/-**);
- reduced range: from 20°C to 45°C (pressing **CH +/-**).


Operation range selection is to be implemented by a installer or a qualified Service Centre (see par. *Selecting the operating range in heating mode* on page 38).

During temperature setting, the  symbol flashes on the screen and the CH current temperature setting is displayed.

When the central heating system requests heat from the boiler, the LCD displays the  symbol (blinking) and the current heating flow water temperature.

The waiting time between one boiler ignition and the following one, used to prevent boiler frequent turning on and off, ranges between 0 and 30 minutes (default value: 4 min.), and can be edited with the **P11** parameter.

Should water temperature in the system fall below set minimum value, between 20°C and 78°C (default value 40°C for standard range, 20°C for reduced range) to be edited with the **P27** parameter, the waiting time is reset and the boiler re-ignites.

The burner ON symbol  shows while the burner is operating.


### 1.3.4 DHW function

The DHW production function is enabled on the KC model and on the KR/KRB models with external water heater (optional).

DHW production function is enabled in one of the following operating modes: SUMMER or WINTER.

Such function has always priority over CH water supply.

To set the domestic hot water temperature, press **DHW +/-** buttons.

During temperature setting, the  symbol flashes on the screen and the DHW current temperature setting is displayed.

When the system requests domestic hot water, the display shows the  symbol (blinking) and the current domestic hot water temperature.

The burner ON symbol  shows while the burner is operating.

#### Model KC

For KC model, DHW temperature may be set within a range from +35 °C to +57 °C.



#### WARNING

---

**A flow limiter is installed within the boiler, which limits DHW output flow rate.**

**This limit is set to 13 litres per minute.**

---

#### Models KR/KRB

On KR/KRB models with external water heater (optional) and water heater temperature probe (optional, supplied by the manufacturer; included in the standard supply for KRB model), temperature range is between 35 °C and 65 °C.

On KR/KRB models with external water heater (optional) and water heater probe (optional, supplied by the manufacturer), every 15 days the anti-legionella function will be enabled, consisting in raising the water heater temperature to 65°C for 30 minutes independent of other settings.

### 1.3.5 Freeze protection function

This boiler is fitted with a freeze protection system, which works when the following functions are activated: OFF/SUMMER/WINTER/CH ONLY.



#### DANGER

---

**The freeze protection function only protects the boiler, not the whole heating system.**

---

The central heating system can be effectively protected against icing by using specific anti-freeze products that are suitable for multi-metal systems.



#### WARNING

---

**Do not use anti-freeze products for car engines, and check the effectiveness of the product used over time.**

---

In case burner cannot be ignited due to the lack of gas, the freeze protection functions are anyway enabled through the circulation pumps.

#### 1.3.5.1 Flow freeze protection function

When the heating water temperature sensor detects a water temperature of +5 °C, the boiler switches on and stays on at its minimum heat output until the temperature reaches +30 °C or 15 minutes have elapsed.

The pump continues to operate even if the boiler shuts down.

#### 1.3.5.2 Plate heat exchanger freeze protection (only model KC)

When the DHW temperature sensor detects a water temperature of +5°C, the boiler switches on and stays on at its minimum heat output until the DHW temperature reaches +10°C or 15 minutes have elapsed (the deviating valve is in the DHW position).

During the DHW freeze protection operation the temperature detected by the flow probe is constantly checked, and in case it reaches +60 °C the burner is switched off.

The burner is switched on again if the operation request in anti-freeze mode is still present and the flow temperature is below +60°C.

The pump continues to operate even if the boiler shuts down.

### 1.3.5.3 Water heater freeze protection function (for models KR/KRB with external water heater).

On KR/KRB models with external water cylinder (optional) with NTC probe (10 k $\Omega$  @  $\beta=3435$ ; refer to water cylinder technical specifications), the frost protection function also protects the water heater.

When water heater probe detects a water temperature of +5 °C, the boiler switches on and stays on at its minimum heat output until the temperature of the water heater water reaches +10 °C or 15 minutes have elapsed.

The pump continues to operate even if the boiler shuts down.

During the water heater anti-freeze operation the temperature detected by the flow probe is constantly checked, and in case it reaches +60°C the burner is switched off.

The burner is switched on again if the operation request in anti-freeze mode is still present and the flow temperature is below +60°C.

### 1.3.5.4 Ambient probe freeze protection function

If the ambient probe detects a temperature below +5° C, a heating request to heat the probe-controlled room is launched.

The heating function ends when the probe ambient temperature reading reaches +6° C.

### 1.3.6 Anti-seize function

If the boiler remains inactive and connected to the power mains, the circulation pump and the deviating valve will be shortly enabled every 24 hours so as to avoid any shut-down.

The same applies to the relay which can be freely programmed whenever this latter is used to power a recirculation pump or a deviating valve.

### 1.3.7 Timed post-circulation function

After each central heating, DHW or freeze protection request, the pump continues to be powered for 30 seconds.

If a new central heating, DHW or freeze protection request is received during this period, the post-circulation function is cancelled in order to fulfil the request.

### 1.3.8 Timed post-ventilation function

After each central heating, DHW or freeze protection request, the fan continues to work for 10 seconds.

If a new operating request is received during this period, the post-ventilation function is cancelled in order to fulfil the request.

### 1.3.9 Operation with ambient probe (optional)

Boiler can be connected to an ambient probe (optional - not compulsory, supplied by the manufacturer).

When the ambient temperature is known, the boiler automatically adjusts the heating water temperature by increasing it when the ambient temperature decreases and decreasing it when the ambient temperature is close to the set one.

Heating water temperature varies based on a programme written inside boiler electronic microprocessor.

When working with a connected ambient probe, the +/- CH buttons are no longer used to set heating water temperature, but to change the desired ambient temperature.

During temperature setting, the °C icon and the value being set are shown on the display.

As soon as button is released, icon will continue flashing for approx. 3 seconds, and set value will flash as well.

After this time, value is stored and display standard operation will be restored.

To connect the ambient probe refer to *Installation of the ambient probe (optional)* on page 37



## WARNING

---

**Only original ambient probes supplied by the manufacturer must be used.**

**The use of non-original ambient probes, not supplied by the manufacturer, may affect the operation of the ambient probe itself and of the boiler.**

---

### 1.3.10 Operation with external probe (optional)

Boiler can be connected to a probe measuring the external temperature (optional - not compulsory, supplied by the manufacturer).

Once the external temperature value is known, the boiler will automatically adjust the heating water temperature: increasing it as the external temperature decreases and decreasing it as the external temperature increases. This will both improve room comfort and reduce fuel consumption. Standard and reduced range max. temperature values will nevertheless be respected.

This boiler operating mode is called "sliding temperature operation".

Heating water temperature varies based on a programme written inside boiler electronic microprocessor.

When working with an external probe, the **CH +/-** buttons are no longer used to set heating water temperature, but to edit fictitious ambient temperature, namely the desired theoretical temperature.

During temperature setting, the °C symbol and the value being set are shown on the display.

For optimal curve adjustment, a position close to +20 °C is recommended.

For further details on "cruising temperature operation", refer to paragraph *Installation of the (optional) external probe and sliding temperature operation* on page 39.



#### WARNING

---

**Only original external temperature probes supplied by the manufacturer must be used.**

**The use of non-original external probes, not supplied by the manufacturer, may affect the operation of the external probe itself and of the boiler.**

---

### 1.3.11 Operation with (optional) remote control

The boiler can also be connected to a Remote Control (optional - not compulsory, supplied by the manufacturer) so as to manage several boiler parameters, such as:

- boiler status selection.
- ambient temperature selection.
- CH system water temperature selection.
- DHW temperature selection.
- CH system and (optional) external water heater activation time programming
- boiler diagnostics display.
- boiler reset and other parameters.

To connect the Remote Control, see *Installation and operation with Open Therm Remote Control (optional)* on page 38.



#### WARNING

---

**Only use original Remote Control Units supplied by the manufacturer.**

**The use of non-original remote controls, not supplied by the manufacturer, may affect Remote Control and boiler operation.**

---

## 1.4 Boiler shut-down

The boiler shuts down automatically if a malfunction occurs.

To determine the possible causes of malfunction (see *Troubleshooting* on page 58).

Below is a list of shut-down types and the procedure to follow in each case.

### 1.4.1 Burner shut-down

Fault code **E01** is displayed flashing on the display in the event of burner shut-down due to missing flame.

If this happens, proceed as follows:

- check that the gas cock is open and light a kitchen gas ring for example to check the gas supply;
- once having checked if the fuel is available, press the **Reset** button to restore burner operation: if, after two starting attempts, the boiler still fails to start and enters the shut-down mode again, contact a service centre or qualified personnel for maintenance.



#### WARNING

---

**If the burner shuts down frequently, there is a recurring malfunction, so contact a service centre or a qualified service engineer.**

---

#### 1.4.2 Shut-down due to overheating

Fault code **E02** is shown on the LCD display in the event of flow water temperature overheating. Contact a service centre or a qualified service engineer to carry out the maintenance.

#### 1.4.3 Shut-down due to incorrect air/flue gas system draught

The boiler is equipped with a safety device for flue gas exhaustion check.

Should an air/flue gas system malfunction occur, the control device will shut-down the boiler by interrupting the gas supply to the boiler and the LCD will display the **E03** code.

In this case, contact a Service Centre or a qualified service engineer to carry out the maintenance.

#### 1.4.4 Shut-down due to low water pressure

Fault code **E04** is displayed on the LCD display in the event of shut-down triggered by the water pressure switch.

Fill the system by working on filler cock (A) (see Fig. 2 Filler cock).

Water pressure must be 1÷1.3 bars while the boiler is cold.

In order to restore water pressure, proceed as follows:

- Turn the filler cock anticlockwise to allow water to enter the boiler;
- Keep the filler cock open until the pressure gauge shows a value of 1÷1.3 bar;
- Turn cock clockwise to close it.

Should boiler shuts down frequently occur it means there is boiler malfunction in progress. Contact qualified personnel or an authorised service centre for maintenance.



**DANGER**

**Make sure you close filler cock (A) carefully after filling procedure is completed.**

**If you do not, when the pressure increases, the safety valve may activate and discharge water.**




Fig. 2 Filler cock

(A\*) option.

#### 1.4.5 Alarm due to temperature probe malfunction

The following fault codes are shown on the display in the event of burner shut-down due to a temperature probe fault:

- **E05** for the central heating water probe; in this case, the boiler does not work.
- **E06** for the DHW probe; in this case, the boiler functions in central heating mode only, and the DHW function is disabled.
- **E12** for the boiler probe (KR/KRB model only); in this case the boiler works in heating mode only, whereas the boiler heating function is disabled.
- **E15** for the return probe; in this case the boiler functions normally.
- **E23** for the external probe; in this case the boiler works as usual. The operation with external probe is disabled.
- **E44** for the ambient probe; in this case the boiler works as usual. The operation with ambient probe is disabled.



#### WARNING

---

**In any case, contact a service centre or qualified personnel for maintenance.**

---

#### 1.4.6 Alarm due to (optional) Remote Control connection malfunction

The boiler recognises whether or not there is a Remote Control (optional, not compulsory).

If the boiler does not receive information from the Remote Control after the Remote Control itself is connected, the boiler attempts to re-establish communication for 60 seconds, after which the fault code **E31** is shown on the remote control display.

The boiler will continue to operate according to the settings on the touch screen and ignore the Remote Control settings.



#### WARNING

---

**Contact a service centre or a qualified service engineer to carry out the maintenance.**

---

The remote control can indicate faults or shutdown conditions and can also restore boiler operation after shutdown up to a maximum of 3 times in a 24 hour period.

If the maximum number of attempts is reached, fault code **E99** is shown on the boiler display.

To reset error **E99**, disconnect and re-connect again boiler from/to power mains.

#### 1.4.7 Shut-down for fan malfunction

The fan operation is constantly monitored and in case of malfunction the burner goes off; the code **E40** flashes on the display.

This mode is maintained until the fan recovers normal working parameters.

If the boiler does not start and remains in this mode, contact a service centre or a qualified service engineer.



## 1.5 Maintenance



### **WARNING**

---

**The boiler must be serviced periodically as indicated in the relevant section of this manual.**

**Appropriate boiler maintenance ensures efficient operation, environment preservation, and safety for people, animals and objects. Boilers must be maintained by qualified personnel only, under the requirements set forth by the prevailing rules.**

---

## 1.6 Notes for the user



### **WARNING**

---

**The user may only access parts of the boiler that can be reached without using special equipment or tools. The user is not authorised to remove the boiler casing or to operate on any internal parts.**

**No one, including qualified personnel, is authorised to modify the boiler.**

**The manufacturer shall not be held responsible in case of damage to people, animals, or property due to failure to follow the above mentioned instructions.**

---

## 2. Technical features and dimensions

### 2.1 Technical features

This boiler is equipped with a fully pre-mixed gas burner. The following models are available:

- **KC** condensing boiler with sealed chamber and forced draught, supplying CH water and instant DHW production;
- **KR** condensing boiler with sealed chamber and forced draught, supplying CH water only.
- **KRB** condensing boiler with sealed chamber and forced draught, supplying CH water only; with 3-way deviating valve for connection to external water heater (optional).

The following power rates are available:

- **KC/KR/KRB 24**: with heat input of 23.7 kW

All models are equipped with electronic ignition and ionisation flame sensing device.

The boilers meet local applicable Directives enforced in the country of destination, which are stated on their rating plate.

Installation in any other country may be a source of danger for people, animals and property.

The key technical features of the boilers are listed below.

#### 2.1.1 Manufacturing characteristics

- IPX4D electrically protected control panel.
- Integrated, modulating electronic safety board.
- Electronic start-up with built-in igniter and ionisation flame detection.
- Stainless steel, fully pre-mixed burner.
- Mono-thermal, high efficiency heat exchanger, made of aluminium, with manual air purging device.
- Twin shutter modulating gas valve with constant air/gas ratio.
- Modulating, electronically managed combustion fan.
- CH circulation pump with built-in air purging device.
- Minimum pressure switch.
- Heating flow water temperature probe.
- DHW temperature probe (KC).
- Limit thermostat.
- Flue gas thermostat on discharge tower
- Air pressure switch
- Integrated, automatic by-pass.
- 7 litre expansion vessel.
- System filler cock (KC).
- System water discharge tap.
- DHW plate heat exchanger made of stainless steel (KC).
- Motorised deviating valve (KC/KRB).
- DHW priority switch (KC).
- 13 l/min DHW flow-limiting device (KC).

#### 2.1.2 User interface

- Liquid crystal LCD interface for displaying and setting the boiler operating status: OFF, SUMMER, WINTER and CH ONLY.
- CH water temperature regulator: 20-78°C (standard range) or 20-45°C (reduced range).
- DHW water temperature regulator: 35-57°C (KC) - 35÷65°C (KR/KRB with optional water heater).
- System water pressure gauge.

### 2.1.3 Operating features

- CH electronic flame modulation with timer-controlled rising ramp (30 minutes, adjustable).
- DHW electronic flame modulation (models KC and KR/KRB with optional water heater).
- DHW priority function (model KC and models KR/KRB with optional water heater)
- Flow freeze protection function: ON 5°C; OFF 30°C or after 15 minutes of operation if CH temperature > 5 °C.
- DHW freeze protection function: ON 5°C; OFF 30°C or after 15 minutes of operation if CH temperature > 5 °C.
- Water heater anti-freeze function (KR with optional external water heater with NTC probe): ON 5°C; OFF 10 °C or after 15 minutes of operation if water heater temperature > 5 °C.
- Timer-controlled flue cleaning function: 15 minutes.
- Anti-legionella function (models KR/KRB with optional water heater).
- CH Maximum heat input parameter adjustment.
- Ignition heat input adjustment parameter.
- Possibility to select the heating range: standard or reduced.
- Ignition flame propagation function.
- CH thermostat timer: 30 minutes (adjustable).
- Heating pump post-circulation function in CH, freeze protection and flue cleaning modes: 30 seconds (adjustable).
- DHW post-circulation function (KC and KR/KRB with optional water heater): 30 seconds.
- Post-circulation function for heating temperature > 78 °C: 30 seconds.
- Post-ventilation function after working: 10 seconds.
- Post-ventilation function for CH temperature >95 °C.
- Circulation pump and deviating valve anti shut-down function: 10 seconds of operation after 24 hours of inactivity (adjustable).
- Anti-water hammer function: can be set from 0 to 10 seconds through parameter **P15**.
- Ready for connection to an (optional) ambient thermostat.
- Ready for operation with an external probe (optional, supplied by the manufacturer).
- Ready for operation with an ambient probe (optional, supplied by the manufacturer).
- Ready for operation with an OpenTherm remote control (optional, supplied by the manufacturer).

## 2.2 Dimensions




Fig. 3 Dimensions KC/KR

- S Trap inspection cap
- M CH system flow (3/4")
- C Domestic hot water outlet (1/2", only KC)
- G Gas inlet (1/2")
- F Cold water inlet (1/2")
- R CH system return (3/4")




Fig. 4 Dimensions KRB

- S Trap inspection cap
- M CH system flow (3/4")
- MB Water heater secondary flow (1/2")
- G Gas inlet (1/2")
- RB Water heater secondary return (1/2")
- R CH system return (3/4")

## 2.3 Boiler layouts




Fig. 5 Model KR wiring diagram

1. Condensate trap
2. Modulating gas valve
3. CH return water temperature probe
4. Safety thermostat on CH flow
5. CH flow water probe
6. Main condensing heat exchanger
7. Air-purging device
8. Intake pipe
9. Flue gas venting duct
10. Air intake duct
11. Flue gas analysis ports
12. Flue gas thermostat on venting duct
13. Flue gas circuit safety pressure switch
14. Modulating fan
15. Fan check probe
16. Ignition/detection electrode
17. Expansion vessel
18. Minimum pressure switch
19. Air-purging device
20. Circulation pump
21. System unloading cock.
22. 3-bar safety valve
23. Automatic by-pass




Fig. 6 Model KC wiring diagram

- |   |  |
|---|--|
| 1. Condensate trap                          | 20. Circulation pump                   |
| 2. Modulating gas valve                     | 21. System unloading cock.             |
| 3. CH return water temperature probe        | 22. 3-bar safety valve                 |
| 4. Safety thermostat on CH flow             | 23. DHW flow rate limiting device      |
| 5. CH flow water probe                      | 24. Filler cock                        |
| 6. Main condensing heat exchanger           | 25. Cold water flow switch with filter |
| 7. Air-purging device                       | 26. Secondary plate exchanger          |
| 8. Intake pipe                              | 27. DHW temperature probe              |
| 9. Flue gas venting duct                    | 28. Automatic by-pass                  |
| 10. Air intake duct                         | 29. Motorised 3-way valve              |
| 11. Flue gas analysis ports                 |  |
| 12. Flue gas thermostat on venting duct     |  |
| 13. Flue gas circuit safety pressure switch |  |
| 14. Modulating fan                          |  |
| 15. Fan check probe                         |  |
| 16. Ignition/detection electrode            |  |
| 17. Expansion vessel                        |  |
| 18. Minimum pressure switch                 |  |
| 19. Air-purging device                      |  |

- S** Condensate drain  
**M** CH system flow  
**MB** Water heater flow  
**G** Gas inlet  
**RB** Return from the water heater  
**R** CH system return




Fig. 7 Model KRB wiring diagram

- |   |                            |
|---|----------------------------|
| 1. Condensate trap                          | 20. Circulation pump       |
| 2. Modulating gas valve                     | 21. System unloading cock. |
| 3. CH return water temperature probe        | 22. 3-bar safety valve     |
| 4. Safety thermostat on CH flow             | 23. Automatic by-pass      |
| 5. CH flow water probe                      | 24. Motorised 3-way valve  |
| 6. Main condensing heat exchanger           |                            |
| 7. Air-purging device                       |                            |
| 8. Intake pipe                              |                            |
| 9. Flue gas venting duct                    |                            |
| 10. Air intake duct                         |                            |
| 11. Flue gas analysis ports                 |                            |
| 12. Flue gas thermostat on venting duct     |                            |
| 13. Flue gas circuit safety pressure switch |                            |
| 14. Modulating fan                          |                            |
| 15. Fan check probe                         |                            |
| 16. Ignition/detection electrode            |                            |
| 17. Expansion vessel                        |                            |
| 18. Minimum pressure switch                 |                            |
| 19. Air-purging device                      |                            |



## 2.4 Operating data

Burner pressures reported in the following page must be verified after the boiler has been operating for 3 minutes.

Gas category: II2H3P

| Fuel            | Gas mains pressure [mbar] | Diaphragm diameter [mm] | Flue CO2 value [%] |
|-----------------|---------------------------|-------------------------|--------------------|
| Natural gas G20 | 20                        | 5,7                     | 9.0 ÷ 9.6          |
| Propane Gas G31 | 37                        | 4,3                     | 9.7 ÷ 10.3         |

Tab. 1 Adjustment specifications KC-KR-KRB 24

## 2.5 General characteristics

| Description   | um      | KC 24   |
|---|---------|---------|
| CH nominal heat input   | kW      | 20,0    |
| Minimum heat input  | kW      | 5,0     |
| Maximum heat output (80-60°C) - CH  | kW      | 19,5    |
| Minimum heat output (80-60°C) - CH  | kW      | 4,8     |
| Maximum heat output (50-30°C) - CH  | kW      | 21,0    |
| Minimum heat output (50-30°C) - CH  | kW      | 5,4     |
| Minimum CH system pressure  | bar     | 0,5     |
| Maximum CH system pressure  | bar     | 3,0     |
| DHW maximum heat input  | kW      | 24,0    |
| DHW minimum heat input  | kW      | 5,0     |
| DHW circuit min. pressure   | bar     | 0,5     |
| DHW circuit max. pressure   | bar     | 6,0     |
| DHW specific flow rate ( $\Delta T=25K$ )   | l/min   | 14,6    |
| DHW specific flow rate ( $\Delta t=30K$ )   | l/min   | 12,2    |
| Electric power supply – voltage / frequency   | V - Hz  | 230 -50 |
| Power mains supply fuse   | A       | 3,15    |
| Maximum power consumption   | W       | 117     |
| Pump absorption   | W       | 86      |
| Electric protection rating  | IP      | X4D     |
| Net weight  | kg      | 23,5    |
| Natural gas consumption at maximum CH output (Value referred to 15 °C - 1013 mbar)                    | cu. m/h | 2,12    |
| Propane gas consumption at maximum CH output  | kg/h    | 1,55    |
| Maximum CH working temperature  | °C      | 83      |
| Maximum DHW working temperature   | °C      | 62      |
| Total capacity of expansion vessel  | l       | 7       |
| Maximum recommended system capacity (Maximum water temperature 83°C, expansion vessel pressure 1 bar) | l       | 100     |

Tab. 2 General specifications KC

| Description   | um      | KR/KRB 24 |
|---|---------|-----------|
| CH nominal heat input   | kW      | 20,0      |
| Minimum heat input  | kW      | 5,0       |
| Maximum heat output (80-60°C) - CH  | kW      | 19,5      |
| Minimum heat output (80-60°C) - CH  | kW      | 4,8       |
| Maximum heat output (50-30°C) - CH  | kW      | 21,0      |
| Minimum heat output (50-30°C) - CH  | kW      | 5,4       |
| Minimum CH system pressure  | bar     | 0,5       |
| Maximum CH system pressure  | bar     | 3,0       |
| Electric power supply – voltage / frequency   | V - Hz  | 230 -50   |
| Power mains supply fuse   | A       | 3,15      |
| Maximum power consumption   | W       | 117       |
| Pump absorption   | W       | 86        |
| Electric protection rating  | IP      | X4D       |
| Net weight  | kg      | 23,5      |
| Natural gas consumption at maximum CH output (Value referred to 15 °C - 1013 mbar)                    | cu. m/h | 2,12      |
| Propane gas consumption at maximum CH output  | kg/h    | 1,55      |
| Maximum CH working temperature  | °C      | 83        |
| Maximum DHW working temperature   | °C      | 62        |
| Total capacity of expansion vessel  | l       | 7         |
| Maximum recommended system capacity (Maximum water temperature 83°C, expansion vessel pressure 1 bar) | l       | 100       |

Tab. 3 General specifications KR/KRB

| Description                          | um  | Max. output | Min. output | 30% load |
|--------------------------------------|-----|-------------|-------------|----------|
| Casing heat loss with burner on      | %   | 0,64        | 2,43        | -        |
| Casing heat loss with burner off     | %   | 0,255       |             |          |
| Flue system heat loss with burner on | %   | 2,06        | 1,87        | -        |
| Flue system mass capacity            | g/s | 10,7        | 2,2         | -        |
| Flue temp. – air temp.               | °C  | 47,7        | 33,7        | -        |
| Heat efficiency (80-60°C)            | %   | 97,3        | 95,7        | -        |
| Heat efficiency (50-30°C)            | %   | 105,3       | 107,8       | -        |
| 30% heat output efficiency rating    | %   | -           | -           | 109,6    |
| NOx emission class                   | -   | 6           |             |          |

Tab. 4 KC-KR-KRB 24 combustion data

## 3. Instructions for the installer

### 3.1 Installation standards

This boiler must be installed in compliance with the laws and standards in force in the country of installation, which are herein considered as entirely transcribed.

To find out about the gas category and technical specifications, refer to operation data and general features specified in the previous pages.



**DANGER**

---

**Accessories and spare parts for installation and service procedures are to be supplied by the Manufacturer.  
Should non original accessories and spare parts be employed, boiler proper performance is not guaranteed.**

---

#### 3.1.1 Packaging

Boiler is shipped in a sturdy cardboard box.

Remove boiler from cardboard box and check its integrity.

The packing materials can be recycled. Disposal must be managed via appropriate waste collection sites.

Keep packaging out of reach of children, as it may be dangerous.

The manufacturer shall not be held responsible in case of damage to people, animals, or property due to failure to follow the above mentioned instructions.

Packaging includes one plastic bag containing:

- boiler installation, use and maintenance manual;
- the template for mounting the boiler on a wall (see Fig. 8 Paper template).
- 2 screws and relevant wall blocks for fixing the boiler to the wall;
- a corrugated pipe for condensate drain;

### 3.2 Choosing where to install the boiler

The following must be taken into account when choosing where to install the boiler:

- indications contained in paragraph *Air intake and flue gas venting system* on page 30 and its sub-paragraphs.
- check the wall for sturdiness, avoiding weak areas.
- do not install the boiler over appliances which may affect boiler operation (e.g. cookers, which produce steam and grease, washing machines etc.).
- do not install boilers in locations with a corrosive or very dusty atmosphere, such as hairdresser salons, laundries etc., as this may severely reduce the lifespan of the components of the boiler.

### 3.3 Positioning the boiler

Each boiler is supplied with a paper template, found inside the packaging (see Fig. 8 Paper template).

The template allows you to ensure that the pipes connected to the CH system, the DHW system and the gas mains, and the air intake/flue gas venting ducts are all laid out correctly during the realisation of the water system and before installation of the boiler.

This template is made of heavy-duty paper and must be fixed, with the help of a level, onto the wall where the boiler is to be mounted.

The template provides all the indications required to drill the boiler mounting holes to the wall, procedure which is done using two screws and wall blocks.

The lower area of the template shows where to mark the exact point at which the couplings are to be positioned for boiler connection to the gas supply pipe, cold water mains supply pipe, hot water outlet, CH flow and return pipes.

The upper area of the template shows where air intake and flue gas ducts are to be positioned.



**DANGER**

---

**Since the temperature of the walls on which the boiler is mounted and external temperature of coaxial air/flue gas system do not exceed 60°C, no minimum distance from flammable walls is to be accounted for.**

**For boilers with split air intake and flue gas venting ducts, in the case of proximity with flammable walls and passages through walls, apply insulating material between the wall and the flue gas venting duct.**

---




Fig. 8 Paper template

### 3.4 Installing the boiler



#### DANGER

---

**Before connecting the boiler to CH and DHW networks, clean the pipes carefully.**

**Before commissioning a NEW system, clean it to remove any metal chips due to machining and welding, and any oil and grease that might negatively affect boiler operation or even damage it in case they get inside it.**

**Before commissioning a RECONDITIONED system (where radiators have been added, the boiler has been replaced, etc.) thoroughly clean it to remove any sludge and residues.**

**Clean the system using standard non acid products, available on the market.**

**Do not use solvents as they could damage system components.**

**Furthermore, in the central heating system (either new or reconditioned), it is always advisable to add to water a suitable percentage of corrosion protectants for multi-metal systems that will create a protective film onto all internal surfaces.**

**The manufacturer shall not be held responsible in case of damage to people, animals, or property due to failure to follow the above mentioned instructions.**

---



#### DANGER

---

**For all boiler installation types, it is necessary to install a filter which can be inspected (Y-shaped type) with Ø 0.4mm-mesh, on the return pipe before the boiler.**

---

In order to install the boiler proceed as follows:

- Affix the template to the wall.
- Check that 1 cm to the right and 1 cm to the left of the boiler is left for casing removal.
- Drill two 12 mm diameter holes in the wall for the wall plugs, insert the wall plugs supplied with the boiler and apply and tighten the screws.
- If necessary, provide holes in the wall to allow air intake and/or flue gas venting ducts to pass through it;
- With reference to the lower part of the template, position the fittings for the connection of:
  - » gas supply pipe **G**;
  - » cold water supply pipe (KC/KR) or return from water heater (KRB) **F**;
  - » DHW outlet (KC) or flow to water heater (KRB) **C**;
  - » CH flow **M**;
  - » CH return **R**.
- Provide a condensate drain and an outlet for the 3-bar safety valve.
- Hook the boiler to the previously fitted screws.
- Connect the boiler to the feed pipes (see *Hydraulic connections* on page 35).
- Connect the boiler to an outlet for the 3-bar safety valve.
- Connect the boiler to pipe for condensate drain.
- Connect the boiler to the air intake and flue gas venting system (see *Air intake and flue gas venting system* on page 30).
- connect power supply, ambient thermostat (when available) and other available accessories (refer to the following paragraphs).

### 3.5 Boiler room ventilation

The boiler has sealed combustion chamber. Combustion air is not drawn from boiler room, therefore no specific recommendations need to be applied concerning the boiler room or openings and ventilation provided to the boiler room.



#### DANGER

---

**the boiler must be installed in a room that is compliant with the legislation and standards in force in the country of installation, which are herein considered as entirely transcribed.**

---

### 3.6 Air intake and flue gas venting system

Flue gas discharge into the atmosphere and air intake/flue gas venting systems must comply with applicable laws and standards in the country of installation that are considered as fully transcribed herein.



#### DANGER

The boiler is equipped with a safety device for flue gas exhaustion check.

It is strictly forbidden to tamper with and/or prevent operation of such safety device.

Should an air/flue gas system malfunction occur, the device will shut-down the boiler by interrupting the gas supply to the boiler and the LCD will display the E03 code.

In this case it is necessary to have safety device, boiler and the air intake/flue gas venting ducts promptly checked by a service centre or a qualified service engineer.

In case of repeated stops, it is necessary to have safety device, boiler and the air intake/flue gas venting ducts checked by a service centre or a qualified service engineer.

After each operation on the safety device or the air suction/flue gas exhaust system, it is necessary to perform a functional test of the boiler.

In case it is necessary to replace the safety device use only original spare parts supplied by the Manufacturer.

To reset the combustion gas exhaust control device operation it is necessary to press "Reset".



#### DANGER

For the air intake/flue gas venting systems, specific, manufacturer approved, condensate acid-resistant pipes and systems must be used, suitable for condensing boilers.



#### DANGER

Flue gas venting pipes are to be installed tilted toward the boiler so that condensate runs toward the combustion chamber, which is designed for condensate collection and drainage.

Should the above procedure not be possible, it is necessary to install, in condensate stagnation areas, devices designed for condensate collection and conveying to the condensate drain system.

It is necessary to avoid formation of condensate stagnation areas in the flue gas venting system, with the exception of the condensate trap possibly connected to the venting system itself.

The manufacturer cannot be held responsible for any damage caused by inappropriate boiler installation or operation, modification to the boiler, or due to non-observance of the instructions provided by the manufacturer or of legislation and standards applicable for the materials installed.




Fig. 9 Installation examples

### 3.6.1 Possible configuration of air intake and flue gas venting ducts

#### **Type B23**

Boiler intended for connection to an existing flue system external to the boiler room.

Combustion air is taken directly from the boiler room itself while flue gas is conveyed to the outside.

The boiler is not to be fitted with anti-wind gust device; it has to be equipped with a fan mounted before the combustion chamber/heat exchanger.

#### **Type B53**

Boiler intended for connection, via an independent duct, to the flue gas venting terminal.

Combustion air is taken directly from the boiler room itself while flue gas is conveyed to the outside.

The boiler is not to be fitted with anti-wind gust device; it has to be equipped with a fan mounted before the combustion chamber/heat exchanger.

#### **Type C13**

Boiler intended for connection to horizontal outlet and intake ducts connected to the outside by means of coaxial or split ducts.

The minimum distance between the air intake duct and the flue gas venting duct must be at least 250 mm, whereas both terminals must be contained within a square measuring 500 x 500 mm.

The boiler is to be equipped with a fan mounted before the combustion chamber/heat exchanger.

#### **Type C33**

Boiler intended for connection to vertical outlet and intake ducts connected to the outside by means of coaxial or split ducts.

The minimum distance between the air intake duct and the flue gas venting duct must be at least 250 mm, whereas both terminals must be contained within a square measuring 500 x 500 mm.

The boiler is to be equipped with a fan mounted before the combustion chamber/heat exchanger.

#### **Type C43**

Boiler intended for connection to collective chimney pipe system that includes two ducts, air intake and flue gas exhaustion. These ducts may be coaxial or split.

The chimney must be compliant with applicable legislation and standards.

The boiler is to be equipped with a fan mounted before the combustion chamber/heat exchanger.

#### **Type C53**

Boiler with separate pipes for combustion air intake and flue gas evacuation.

These flues may discharge in areas at a different pressure.

The terminals may not face each other from opposed walls.

The boiler is to be equipped with a fan mounted before the combustion chamber/heat exchanger.

#### **Type C83**

Boiler intended to be connected to combustion air terminal and to a single flue gas terminal or collective chimney.

The chimney must be compliant with applicable legislation and standards.

The boiler is to be equipped with a fan mounted before the combustion chamber/heat exchanger.

### 3.6.2 Ø 100/60 mm and Ø 125/80 mm air/flue gas coaxial duct system



#### WARNING

The information given above is with reference to air intake/flue gas venting ducts made from smooth, rigid pipes approved and supplied by the manufacturer.

#### C13/C13X installation type

- Minimum permissible length of horizontal coaxial pipes is 1 meter.
- Maximum permissible length of Ø100/60 mm horizontal coaxial pipes is 12 meters.
- Maximum permissible length of Ø125/80 mm horizontal coaxial pipes is 17 meters.
- For each additional 1 meter of straight pipe maximum permissible length is to be reduced by 1 meter.
- For each additional 90° elbow, maximum permissible length is to be reduced by 1 meter.
- For each additional 45° elbow, maximum permissible length is to be reduced by 0.5 meter.
- The wall terminal reduces maximum permissible length by 1.5 meters.
- The air intake duct is to be tilted down by 1% toward its exit, in order to avoid rain water to enter it.

#### C33/C33X installation type

- Minimum permissible length of vertical coaxial pipes is 1 meter.
- Maximum permissible length of Ø 100/60 mm vertical coaxial pipes is 12 meters.
- Maximum permissible length of Ø 125/80 mm vertical coaxial pipes is 17 meters.
- For each additional 1 meter of straight pipe maximum permissible length is to be reduced by 1 meter.
- For each additional 90° elbow, maximum permissible length is to be reduced by 1 meter.
- For each additional 45° elbow, maximum permissible length is to be reduced by 0.5 meter.
- The roof vent terminal reduces maximum permissible length by 1.5 meters.




Fig. 10 Type C13 - C33 coaxial ducts




Fig. 11 Type C12 - C33 coaxial pipes dimensione

A. Gasket

B. Blanking cap



### 3.6.3 Air intake and flue gas venting via 80 mm split pipes



#### WARNING

The information given above is with reference to air intake/flue gas venting ducts made from smooth, rigid pipes approved and supplied by the manufacturer.

#### Installation types C43 - C53 - C83

- Minimum permissible length of air intake pipe is 1 meter.
- Minimum permissible length of flue gas venting pipe is 1 meter.
- Maximum permissible length of intake/flue gas venting pipes is 95 meters (combined length of air intake and flue gas venting pipe).
- For each additional 1 meter of straight pipe maximum permissible length is to be reduced by 1 meter.
- For each additional 90° elbow, maximum permissible length is to be reduced by 1 meter.
- For each additional 45° elbow, maximum permissible length is to be reduced by 0.5 meter.
- The roof terminal reduces maximum permissible length by 5.5 meters.
- The wall terminal reduces maximum permissible length by 5.5 meters.




Fig. 12 Split pipe kit 0KITS DOP00




Fig. 13 Dimensions for split pipes

### 3.6.4 Air intake and flue gas venting via 60 mm split pipes



#### WARNING


The information given above is with reference to air intake/flue gas venting ducts made from smooth, rigid pipes approved and supplied by the manufacturer.

#### Installation types C43 - C53 - C83

- Minimum permissible length of air intake pipe is 1 meter.
- Minimum permissible length of flue gas venting pipe is 1 meter.
- Maximum permissible length of air intake/flue gas discharge pipes is 24 meters (combined length of air intake and flue gas discharge pipe length).
- For each additional 1 meter of straight pipe maximum permissible length is to be reduced by 1 meter.
- For each additional 90° elbow, maximum permissible length is to be reduced by 1 meter.
- For each additional 45° elbow, maximum permissible length is to be reduced by 0.5 meter.
- The wall terminal reduces maximum permissible length by 4 meters.

## 3.7 Checking combustion efficiency

### 3.7.1 Flue cleaning function

- The boiler features a flue cleaning function which must be used to measure combustion efficiency during operation and to adjust the burner.
- To activate the flue cleaning function, press and hold the buttons - **DHW** and **RESET** simultaneously for 5 seconds. The flow temperature and the  symbol are shown on the LCD.
- When the flue cleaning function is activated with the boiler in WINTER or SUMMER mode, the boiler performs the ignition sequence and then operates at a fixed power output predetermined by the parameter **P7** (maximum CH output).
- To exit the flue cleaning mode, press **RESET** or wait 15 minutes.

### 3.7.2 Measurement procedure

The boiler is equipped with a tower allowing for air intake/flue gas venting pipe connection (see Fig. 14 Plugs position and Fig. 15 Hole position).

The tower is designed with two pre-arranged openings directly accessing air and flue gas ducts (see Fig. 15 Hole position).

Remove caps **A** and **B** from the pre-arranged openings on the tower, before starting combustion checking procedure (see Fig. 14 Plugs position).

In order to verify combustion efficiency the following measurements must be implemented:

- assess combustion air from opening **1** (see Fig. 15 Hole position).
- assess flue gas temperature and CO<sub>2</sub> from opening **2** (see Fig. 15 Hole position).
- Allow boiler to reach working temperature before taking any measurement.




Fig. 14 Plugs position




Fig. 15 Hole position

### 3.8 Connection to gas mains

Cross-section gas pipe size must be chosen depending on its length, layout pattern, gas flow rate.  
Gas supply pipe cross-section must be equal or greater than boiler gas pipe.



#### DANGER

Comply with installation standards enforced in the country where the boiler is installed which are considered as fully transcribed in this booklet.

Remember that before operating an indoor gas distribution system and before connecting it to a meter, it must be checked for leaks.

If some system parts are not visible, the leak test is to be carried out before the pipes are covered.

Leak test is NOT to be carried out employing flammable gas: use air or nitrogen for this purpose.

Once gas is in the pipes, leak test by a naked flame is forbidden; use specific products available on the market.

When connecting the boiler to gas supply network, it is COMPULSORY to install an appropriately sized gasket (A) made from suitable material (see Fig. 16 Connection to gas mains).

The boiler gas inlet coupling is NOT suitable for hemp, teflon tape or similarly made gaskets.




Fig. 16 Connection to gas mains

### 3.9 Hydraulic connections

#### 3.9.1 Central heating

Prior to installing the boiler, the hydraulic system is to be cleaned in order to remove impurities; they could be present in system components and damage the pump and the heat exchanger.

The CH outlet and return pipes must be connected to the respective 3/4" connectors **M** and **R** on the boiler (see Fig. 8 Paper template).

When calculating the cross section of CH system pipes, bear in mind load losses induced by radiators, thermostatic valves, radiator gate valves, and the configuration of the system itself.



#### WARNING

As for water treating in the domestic heating systems in order to optimise efficiency and safety, ensure a long life, trouble-free operation of auxiliary equipment, minimise power consumption, thereby integrating the standards and rules in force in the country of installation, it is recommended to use specific products suitable for multi-metal heating systems.

The water pH value must be between 7 and 8.



#### WARNING

It is advisable to convey the discharge flow of boiler safety valve to the sewer system. Should the above precaution not be implemented and the safety valve be activated, boiler room flooding may occur.

The manufacturer shall not be held responsible in case of damage to people, animals, or property due to failure to follow the above mentioned instructions.

### 3.9.2 DHW

Prior to installing the boiler, the hydraulic system is to be cleaned in order to remove impurities; they could be present in system components and damage the pump and the heat exchanger.

#### Model KC

Cold water inlet and DHW outlet shall be connected to the boiler through the dedicated 1/2" **F** and **C** fittings.  
Hardness of water supplied to the boiler may increase the plate heat exchanger cleaning/replacement intervals.

#### Model KR

Cold water inlet shall be connected to the boiler through the special 1/2" fitting **F**.

#### Model KRB

Return from the water heater (RB) and flow to water heater (MB) must be connected to the respective 1/2" connectors **F** and **C** on the boiler



#### WARNING

**Depending on the hardness of the mains water supply, ascertain whether or not to install appropriate domestic water treatment systems using water treatment products suitable for drinking water and compliant with the regulations and standards in force in the country of installation.**

**Water treatment is always advisable when water supplied to the boiler is more than 15°F hard.**

**Water supplied by commonly marketed water softeners, due to its chemical-physical features, may not be compatible with some components of the heating system as the latter is filled with DHW.**

**For this reason we recommend using polyphosphate dosing systems.**

### 3.9.3 Condensate drain

Comply with condensate drain laws and standards applicable in the country of installation, which are considered herein integrally transcribed. Unless forbidden, the condensate produced by combustion is to be routed via the condensate drain through a discharge system connected to the domestic sewer, which due to its basicity, counteracts flue gas condensate acidity. In order to avoid domestic sewer odour to reach the premises, it is advisable to install an appropriate device between the discharge system and the domestic sewer. The condensate drain system and the domestic discharge system is to be made of an adequate, condensate-resistant material.

Condensate drain system must be connected to specific fitting (A) in the boiler (see Fig. 17 Condensate drain).

It is strictly forbidden to connect condensate drain system in trap inspection point (B).



#### WARNING

**The manufacturer shall not be held responsible in case of damage to people, animals, or property due to failure to follow the above mentioned instructions.**




Fig. 17 Condensate drain

### 3.10 Connection to electrical mains

The boiler is supplied with a three-poled power cable, already connected to the electronic board and it is provided with a safety clamp. The boiler is to be connected to a 230V-50Hz electrical power supply.

**When connecting it to power mains, follow correct phase / neutral polarity sequence.**

Installation standards must be complied with and they are herein considered as entirely transcribed.

An easily accessible two-poled switch, with a minimum 3 mm distance between contacts, is to be installed ahead of the boiler. The switch is to allow power supply cut-off in order to safely perform maintenance and service procedures.

Power supply to the boiler must be fitted with a residual-current circuit breaker having suitable disconnection capacity. Electric power supply must be properly earthed.

The above mentioned safety measure must be verified. If in doubt, ask a qualified technician to thoroughly check the power network.



#### WARNING

---

**The manufacturer cannot be held responsible for any damage caused by failure to earth the system correctly: gas, water, or CH system pipes are not suitable for grounding power networks.**

---

### 3.11 Connection to ambient thermostat (optional)

The boiler is designed to be connected to an ambient thermostat (optional, not compulsory).

Ambient thermostat contacts must be properly sized in compliance with a load of 4 mA at 20 Vdc.

The ambient thermostat cables must be connected to terminals (3) and (4) of the electronic board (see *Wiring diagrams* on page 47) after eliminating the jumper supplied as a standard with the boiler.

**The ambient thermostat cables are not to be grouped together in the same sheath as power mains supply cables.**

### 3.12 Installation of the ambient probe (optional)

Boiler can be connected to a probe measuring the ambient temperature (optional - not compulsory, supplied by the manufacturer).

**If an ambient probe is installed, then it will not be possible to install an external probe.**



#### WARNING

---

**Only original ambient probes supplied by the manufacturer must be used.**

**If non-original ambient temperature probes are used, correct operation of the boiler and probe cannot be guaranteed.**

---

The ambient temperature probe must be connected by means of a double insulated wire, minimum cross-section 0.35 sq.mm.

The ambient probe must be connected to terminals (1) and (2) of boiler electronic board.



#### WARNING

---

**The ambient temperature probe cables must NOT be routed together with power cables.**

---

To install the ambient probe follow the instructions supplied with the probe.

The ambient probe must be installed on an indoor wall at a height of approximately 1.5 m from the floor and in a suitable location for measuring ambient temperature: do not install in recess or corners, behind doors or curtains, and install away from heat sources, direct sunlight, air draughts and water sprays.

The ambient probe automatically modifies the CH flow temperature in relation to:

- Measured ambient temperature.
- Set ambient temperature.

The ambient temperature is set using **CH +/-** buttons that, with ambient probe installed, no longer work to set the heating water temperature. Through boiler parameter **P29** it is possible to display the value of the ambient temperature detected by the probe.

### 3.13 Installation and operation with Open Therm Remote Control (optional)



#### WARNING

**Only use original Remote Control Units supplied by the manufacturer.**

**The correct operation of the Remote Control itself and of the boiler is not guaranteed if non original Remote Control units not supplied by the manufacturer are used.**

The boiler may be connected to an Open Therm Remote Control (non-compulsory optional accessory supplied by manufacturer).

The Remote Control must only be installed by qualified personnel.

To install the Remote Control, refer to the instructions provided with the Remote Control itself.

The Remote Control must be installed on an indoor wall at a height of approximately 1.5 m from the floor and in a suitable location for measuring ambient temperature: do not install in recess or corners, behind doors or curtains, and install away from heat sources, direct sunlight, air draughts and water sprays.

The Remote Control cables must be connected to terminals (3) and (4) of the electronic board (see *Wiring diagrams* on page 47) after having eliminated the jumper supplied as a standard with the boiler.

The Remote Control connector is protected against inverted polarity, and the connections may be inverted.



#### WARNING

**Do not connect the remote control to mains electrical power 230 V ~ 50 Hz.**

**The remote control wiring must not be grouped together in the same sheath as the power cables: if the cables are sheathed together, electrical interference from the power cables may compromise the functions of the Remote Control;**

For complete instructions on how to program the Remote Control, refer to the instruction manual included in the Remote Control kit.

Board and Remote Control communicate in each operating mode: OFF, SUMMER, WINTER, CH ONLY.

Boiler display layout corresponds to the setting made from the Remote Control, as for the operating mode.

The remote control may be used to view and set a number of special parameters denominated **TSP** parameters and reserved solely for qualified technicians.

**TSP0** parameter sets default data table and restores all factory settings, cancelling all preceding modifications on single parameters.

If a single parameter is found to be incorrect, the value given in the default value table is restored.

If the user attempts to set a value not within the permissible range for the parameter, the new value is rejected and the existing value is maintained.

### 3.14 Selecting the operating range in heating mode

Heating water temperature adjustment range depends on the selected operating range.:

- **standard range:** from 20°C to 78°C (pressing **CH +/-**);
- **reduced range:** from 20°C to 45°C (pressing **CH +/-**).

The standard range is active with curves **P10**  $\geq 1$ , while the reduced range is active with curves **P10**  $< 1$ .

The two ranges can also be selected even with the external probe disconnected.

The waiting time between one boiler ignition and the following one, used to prevent boiler frequent turning on and off is 4 minutes for both ranges, and can be edited with the parameter **P11**.

If system water temperature decreases below a certain value, the waiting time is reset and the boiler re-ignited, as shown in the following table:

| Selected range | Re-ignition temperature |
|----------------|-------------------------|
| Standard range | < 40°C ( <b>P27</b> )   |
| Reduced range  | < 20°C                  |

Tab. 5 Boiler re-ignition temperature

Operation range selection is to be implemented by a qualified installer or a Service Centre.

### 3.15 Installation of the (optional) external probe and sliding temperature operation

The boiler can be connected to an (optional) external temperature probe (optional, provided by the manufacturer) for sliding temperature operation.

**If an external probe is installed, then it will not be possible to install an ambient probe.**



#### WARNING

---

**Only original external temperature probes supplied by the manufacturer must be used.**

**If non-original external temperature probes are used, correct operation of the boiler and external probe cannot be guaranteed.**

---

The external temperature probe must be connected by means of a double insulated wire, minimum cross-section 0.35 sq.mm.  
The external probe must be connected to terminals (1) and (2) of boiler electronic board.



#### WARNING

---

**The temperature probe cables must NOT be routed together with power cables.**

---

The temperature probe must be installed on an outside wall facing NORTH - NORTH EAST, in a position protected from weather.  
Do not install near a window, ventilation openings or sources of heat.

The external temperature probe automatically modifies the CH flow temperature in relation to:

- Measured external temperature.
- Selected thermoregulation curve.
- Selected fictitious ambient temperature.

The thermoregulation curve is selected via parameter **P10**.

During adjustment, the set value will flash on LCD. Such value can also be read as parameter **TSP10** on the Remote Control (when installed).

The relation between parameter **TSP10** setting and the thermoregulation curve coefficient is the following:

- coefficient = TSP10 value / 84.67

The fictitious ambient temperature is set using **CH +/-** buttons that, with external probe installed, no longer work to set the heating water temperature (see *Operation with external probe (optional)* on page 14).

Through boiler parameter **P29** it is possible to display the value of the outside temperature detected by the external probe.

The figure shows the curves for a fictitious ambient temperature of 20°C. Parameter **P10** allows selecting the curve value shown (see Fig. 18 Thermoregulation curves).

If fictitious ambient temperature value is edited on boiler display, the curves shift up or down, respectively, by the same amount.

With a fictitious ambient temperature setting of 20°C, for example, if you select the curve corresponding to parameter 1 and the outdoor temperature is - 4°C, the CH flow temperature will be 50°C.




Fig. 18 Thermoregulation curves

**Tm** indicates flow water temperature in °C

**Te** indicates external temperature in °C



### 3.16 TSP parameters

The boiler operation is controlled by several parameters.

To display the parameters, press and hold the buttons + **DHW** and - **DHW** simultaneously for 3 seconds.

The LCD display shows alternatively at intervals of 3 seconds the number of the parameter (e.g. P03) and the parameter value (e.g. 01).

Scroll through the parameters by pressing +/- **DHW** buttons.


To quit the parameter display mode, press the **Reset** button.

To modify parameters press buttons **Reset** and - **CH** together for 3 seconds.

The LCD display shows alternatively at intervals of 3 seconds the number of the parameter (e.g. P03) and the parameter value (e.g. 01).

Scroll through the parameters by pressing **CH +/-** buttons.


As soon as you reach the one to be modified, press **Operating status selection**.

The  symbol turns on to indicate that you can edit the parameter value.

The parameter value can be edited using **CH +/-** buttons.

To confirm modification press **Operating status selection**.

To quit the parameter editing mode, press the **Reset** button.



| Parameter  | Settable values | Default values         | Notes   |
|--|-----------------|------------------------|---|
| P0 - TSP0<br>Fuel gas type   | 0, 1            | According to the model | 0 = natural gas; 1 = propane  |
| P3 - TSP3<br>Boiler type selection   | 1 ÷ 3           | According to the model | 1 = combined instantaneous; 2 = heating only; 3 = with water heater |
| P4 - TSP4<br>Fan speed at burner maximum output  | TSP5 ÷ 255 Hz   | According to the model | 164 = natural gas; 169 = propane                                    |
| P5 - TSP5<br>Fan speed at burner minimum output  | 33 - 254 Hz     | 43                     | -   |
| P6 - TSP6<br>Fan speed at ignition power   | 33 ÷ 255 Hz     | 70                     | -   |
| P7 - TSP7<br>Fan speed at heating maximum output   | 10 ÷ 100%       | According to the model | 85 = natural gas; 83 = propane                                      |
| P8 - TSP8<br>Negative ramp start minimum speed   | P5 ÷ P6         | 56                     | -   |
| P9 - TSP9<br>Negative ramp time<br>(1 = 2 sec.)  | 0 ÷ 255         | 90                     | -   |
| P10 - TSP10<br>Heating output curves   | 0 ÷ 3           | 1,5                    | resolution 0.1  |
| P11 - TSP11<br>Heating thermostat timing   | 0 ÷ 30 min.     | 4                      | -   |
| P12 - TSP12<br>CH power rising ramp timer  | 0 ÷ 30 min.     | 1                      | -   |
| P13 - TSP13<br>Timer for CH post-circulation, freeze protection and flue cleaning function | 30 ÷ 180 sec.   | 30                     | -   |
| P15 - TSP15<br>Water hammer protection delay, configurable                                 | 0 ÷ 10 sec.     | 0                      | -   |

Tab. 6 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - I

| Parameter   | Settable values | Default values | Notes   |
|---|-----------------|----------------|---|
| P16 - TSP16<br>Ambient thermostat/remote control reading delay  | 0 ÷ 199 sec.    | 0 sec.         | -   |
| P17 - TSP17<br>Anti-seize function timer                        | 0 ÷ 30 sec.     | 10 sec.        | -   |
| P18 - TSP18<br>Anti-legionella function timer                   | 0 ÷ 255 days    | 15 days        | -   |
| P19 - TSP19<br>Anti-legionella function temperature             | 35 ÷ 70 °C      | 65 °C          | -   |
| P20 - TSP20<br>Anti-legionella function operation timer         | 0 ÷ 255 minutes | 30 minutes     | -   |
| P21 - TSP21<br>Association of supplementary input               | 0 ÷ 2           | 0              | 0 = no probe; 1 = ambient probe; 2 = external probe   |
| P22 - TSP22<br>Ambient probe triggering differential OFF        | 0.0 ÷ 1.0 °C    | 0.0 °C         | resolution 0.1 (only with connected ambient probe)  |
| P23 - TSP23<br>Ambient probe triggering differential ON         | -1.0 ÷ -0.1 °C  | -0.5 °C        | resolution 0.1 (only with connected ambient probe)  |
| P24 - TSP24<br>Ambient probe correction range                   | -5.0 ÷ 5.0 °C   | 0 °C           | resolution 0.1 (only with connected ambient probe)  |
| P25 - TSP25<br>Type of modulation with connected ambient probes | 0 ÷ 1           | 1              | 0 = on/off; 1 = ambient probe modulation  |
| P26 - TSP26<br>Flow temperature with P21=0 and P25=0            | 0 ÷ 78 °C       | 60 °C          | only with connected ambient probe   |
| P27 - TSP27<br>Heating timer reset temperature                  | 20 ÷ 78 °C      | 40 °C          | -   |
| P28 - TSP28<br>Type of temperature visualization on display     | 0 ÷ 3           | 0              | 0 = flow temperature; 1 = ambient probe temperature/external probe temperature; 2 = return temperature; 3 = DHW temperature |
| P29<br>Circulation pump minimum speed                           | 0 ÷ 100%        | 72%            | -   |
| P30<br>Circulation pump fixed speed                             | P29 ÷ 100%      | 100%           | for all functions except heating  |
| P31<br>Circulation pump speed in heating mode                   | P29 ÷ 101%      | 101%           | With P31 = 101 automatic speed. With P31 < 101 speed fixed at the set value   |
| P32<br>Flow/return differential in heating mode                 | 0 ÷ 50 °C       | 30 °C          | with P32 = 0, the return probe is disabled  |
| P33<br>Circulation pump algorithm time base                     | 0 ÷ 240 sec.    | 30 sec.        | n.a.  |

Tab. 7 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - II

Parameters from **P29** to **P34** do not apply to this boiler model. They must NOT be modified

| Parameter  | Settable values | Default values | Notes  |
|--|-----------------|----------------|--|
| P34<br>PWM circulation pump control                          | 0 ÷ 1           | 1              | With P34 = 0: PWM=100% pump stopped and PWM=0% pump at maximum operation.<br>With P34 = 1: PWM=100% pump at maximum operation and PWM=0% pump stopped. |
| P35<br>Setting of default parameters (except P0, P1, P2, P3) | 0 ÷ 1           | 0              | 0 = user parameters; 1 = default parameters  |
| P36<br>Display of reset shut-down and fault                  | 0 ÷ 1           | n.a.           | 0 = OFF; 1 = shut-downs and faults reset   |
| P37<br>Post-ventilation timer                                | 0 ÷ 60 sec.     | 10 sec.        | -  |
| P38<br>Water heater flow temperature                         | 0 ÷ 50 °C       | 0 °C           | With P38 = 0: automatic modulating water heater flow temperature.<br>With P38 > 0: water heater flow temperature = P38 + water heater set-point.       |
| P39<br>heating temperature minimum limit for STANDARD range  | 20 ÷ 59 °C      | 20 °C          | -  |
| P40<br>heating temperature maximum limit for STANDARD range  | 60 ÷ 78 °C      | 78 °C          | -  |
| P41<br>heating temperature minimum limit for REDUCED range   | 20 ÷ 30 °C      | 20 °C          | -  |
| P42<br>heating temperature maximum limit for REDUCED range   | 31 ÷ 45 °C      | 45 °C          | -  |
| P43<br>Ambient or external temperature                       | -               | -              | only with connected ambient or external probe  |
| P44<br>Flow temperature                                      | -               | -              | -  |
| P45<br>Nominal calculated flow temperature                   | -               | -              | only with connected ambient or external probe  |
| P46<br>DHW temperature                                       | -               | -              | -  |
| P47<br>Boiler return temperature                             | -               | -              | -  |
| P48<br>Flue gas temperature                                  | -               | -              | -  |
| P49<br>Display of boiler type                                | -               | -              | xyz<br>x= P0 value<br>y = P2 value<br>z = P3 value   |

Tab. 8 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - III

Parameters from **P29** to **P34** do not apply to this boiler model. They must NOT be modified

| Parameter   | Settable values | Default values | Notes |
|---|-----------------|----------------|-------|
| P50<br>Display of most recent boiler shut-down                    | -               | Shut-down code | -     |
| P51<br>display of number of days since last shut-down             | -               | -              | -     |
| P52<br>Display of penultimate boiler shut-down                    | -               | Shut-down code | -     |
| P53<br>display of number of days since second last shut-down      | -               | -              | -     |
| P54<br>Display of third last boiler shut-down                     | -               | Shut-down code | -     |
| P55<br>display of number of days since third last shut-down       | -               | -              | -     |
| P56<br>Display of fourth last boiler shut-down                    | -               | Shut-down code | -     |
| P57<br>display of number of days since fourth from last shut-down | -               | -              | -     |
| P58<br>Display of fifth last boiler shut-down                     | -               | Shut-down code | -     |
| P59<br>display of number of days since fifth from last shut-down  | -               | -              | -     |
| P60<br>Number of faults since last reset                          | -               | -              | -     |
| P61<br>Board use month displaying                                 | -               | -              | -     |

Tab. 9 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - IV

### 3.17 Filling the system

Once all boiler connections have been completed, CH system can be filled.

The procedure is to be cautiously carried out, following each step:

- Open the bleeding valves on all radiators and verify the boiler automatic valve operation.
- Gradually open the relevant filler cock, checking any automatic bleeding valves installed in the system properly work (see Fig. 2 Filler cock).
- Close all radiator bleeding valves as soon as water starts coming out.
- Check on pressure gauge that water pressure reaches the 1÷1.3 bar reading.
- Shut the filler cock and bleed any air out again, by opening the air bleeding valves on radiators.
- Start the boiler and bring the system to working temperature, stop the pump, and repeat air bleeding procedure.
- Allow the system to cool and restore water pressure to 1÷1.3 bars.



#### WARNING

---

**As for water treating in the domestic heating systems in order to optimise efficiency and safety, ensure a long life, trouble-free operation of auxiliary equipment, minimise power consumption, thereby integrating the standards and rules in force in the country of installation, it is recommended to use specific products suitable for multi-metal heating systems.**

**The water pH value must be between 7 and 8.**

---



#### WARNING

---

**After long inactivity of the boiler, its pump may be stuck.**

**Before starting up the boiler, make sure that the pump is operating, with the following procedure:**

- **Remove the boiler outer casing.**
  - **Unscrew the protective cap at the centre of the pump motor.**
  - **When the protection cap is removed, some water may flow out.**
  - **Put a screwdriver into the hole and manually rotate the circulation pump shaft clockwise.**
  - **Before refitting the boiler casing ensure that all surfaces are properly dried.**
  - **Once the unblocking operation is completed, screw the protective cap back on and check for water leaks.**
- 



#### WARNING

---

**The low water safety pressure switch will not electrically enable the burner ignition when water pressure is below 0.4-0.6 bar.**

**The CH system water pressure must not be lower than 1 bar. Otherwise, fill the heating system.**

**The procedure is to be followed while the system is cold.**

**Pressure gauge is used to read pressure inside the heating circuit.**

---

### 3.18 Starting up the boiler

#### 3.18.1 Preliminary checks

Before starting the boiler, check that:

- The flue gas venting duct and the relevant terminal are installed in conformity with the instructions: with the boiler operating, there must be no leakage of combustion by-products from any of the gaskets.
- The supply power to the boiler must be 230 V ~ 50 Hz.
- the heating system is correctly filled with water (pressure gauge reading 1÷1.3 bar).
- Any shut-off cocks in the system pipes are open.
- the mains gas type is correct for the boiler calibration: convert the boiler to the available gas if necessary (see *Adaptation to other gas types and burner adjustment* on page 53). This operation is to be exclusively carried out by qualified personnel.
- The gas supply cock is open.
- There are no fuel gas leaks.
- The main switch installed adjacent to the boiler is turned on.
- The 3-bar safety valve is not stuck.
- There are no water leaks.
- The pump has not seized.
- The condensate trap installed on the boiler is discharging condensate correctly and is not stuck.

#### 3.18.2 Switching on and switching off

To switch the boiler on and off, refer to the “**Instructions for the User**” (see *Instructions for the user* on page 8).

### 3.19 Available head




Fig. 19 Available head

**Q**.....Flow rate (l/h)

**H**.....Available head (mbar)

3.20 Wiring diagrams




Fig. 20 Wiring diagram KC

**Internal connections**

- P:**.....boiler pump
- V:**.....brushless fan
- VG:**.....gas valve
- MDV:**.....electric deviating valve
- DK:**.....low water pressure switch
- TS:**.....heating flow safety thermostat
- FT:**.....flue gas thermostat
- APS:**.....air pressure switch
- FL:**.....DHW flow switch
- SR:**.....return NTC temperature probe 10k Ohm a 25°C B=3435
- SS:**.....NTC DHW probe 10k Ohm at 25 °C B=3435
- SM:**.....CH NTC temperature probe 10k Ohm a 25°C B=3435
- PWM V:**.....PMW signal cable for fan
- E:**.....ignition/flame detection electrode

**Connections performed by the installer**

- 1-2:**.....NTC external probe 10k Ohm at 25 °C B=3977 or ambient NTC probe 10k Ohm at 25°C B=3977 (SEXT/SAMB)
- 3-4:**.....room thermostat or Remote Control (TA-CR)






Fig. 21 Wiring diagram KR

**Internal connections**

- P:**.....boiler pump
- V:**.....brushless fan
- VG:**.....gas valve
- DK:**.....low water pressure swich
- TS:** .....heating flow safety thermostat
- FT:** .....flue gas thermostat
- APS:**.....air pressure switch
- SR:** .....return NTC temperature probe 10k Ohm a 25°C B=3435
- SM:** .....CH NTC temperature probe 10k Ohm a 25°C B=3435
- PWM V:**.....PMW signal cable for fan
- E:**.....ignition/flame detection electrode

**Connections performed by the installer**

- 1-2:**.....NTC external probe 10k Ohm at 25 °C B=3977 or ambient NTC probe 10k Ohm at 25°C B=3977 (SEXT/SAMB)
- 3-4:**.....room thermostat or Remote Control (TA-CR)
- 5-6-7-8:** .....electric deviating valve
  - 5:** neutral
  - 6:** not used
  - 7:** DHW (NC)
  - 8:** heating (NO)
- 9-10:** .....water heater probe (SB)
- 11-12:**.....water heater thermostat (TB)




Fig. 22 Wiring diagram KRB

**Internal connections**

- P:**.....boiler pump
- V:**.....brushless fan
- VG:**.....gas valve
- MDV:**.....electric deviating valve
- DK:**.....low water pressure switch
- TS:**.....heating flow safety thermostat
- FT:**.....flue gas thermostat
- APS:**.....air pressure switch
- SR:**.....return NTC temperature probe 10k Ohm a 25°C B=3435
- SM:**.....CH NTC temperature probe 10k Ohm a 25°C B=3435
- PWM V:**.....PMW signal cable for fan
- E:**.....ignition/flame detection electrode

**Connections performed by the installer**

- 1-2:**.....NTC external probe 10k Ohm at 25 °C B=3977 or ambient NTC probe 10k Ohm at 25°C B=3977 (SEXT/SAMB)
- 3-4:**.....room thermostat or Remote Control (TA-CR)
- 5-6:**.....not used
- 7-8:**.....not used
- 9-10:**.....water heater probe (SB)
- 11-12:**.....water heater thermostat (TB)

**3.20.1 Relationship between temperature and nominal resistance of all NTC probes (B=3435)**

| T (°C) | 0     | 2     | 4     | 6     | 8     |
|--------|-------|-------|-------|-------|-------|
| 0      | 27203 | 24979 | 22959 | 21122 | 19451 |
| 10     | 17928 | 16539 | 15271 | 14113 | 13054 |
| 20     | 12084 | 11196 | 10382 | 9634  | 8948  |
| 30     | 8317  | 7736  | 7202  | 6709  | 6254  |
| 40     | 5835  | 5448  | 5090  | 4758  | 4452  |
| 50     | 4168  | 3904  | 3660  | 3433  | 3222  |
| 60     | 3026  | 2844  | 2674  | 2516  | 2369  |
| 70     | 2232  | 2104  | 1984  | 1872  | 1767  |
| 80     | 1670  | 1578  | 1492  | 1412  | 1336  |
| 90     | 1266  | 1199  | 1137  | 1079  | 1023  |

Tab. 10 Relationship between "Temperature and Nominal resistance" for temperature probes

### 3.21 Adaptation to other gas types and burner adjustment



#### WARNING

This boiler is built to run on the type of gas specified on the packaging and on the boiler rating plate.

Any later transformation is to be exclusively carried out by qualified personnel, using manufacturer designed accessories and following the procedure and adjustment instructions for an accurate boiler setting-up.

- Disconnect the boiler from the electric power supply.
- Close the gas cock.
- Remove boiler outer front panel.
- Turn the electronic board box downwards.
- Disconnect the gas pipe from the gas valve (see Fig. 23 Gas diaphragm replacement).
- Replace the gas diaphragm (A) with the one of the new gas type (see Fig. 23 Gas diaphragm replacement).





Fig. 23 Gas diaphragm replacement

- Reconnect the gas pipe to the gas valve.
- Refit the boiler outer front panel.
- Reconnect boiler to electric power supply, and open the gas cock.
- Edit value for parameter **P0-TSP0** depending on boiler power (see par. *TSP parameters* on page 41).
- Adjust the gas valve (see par. *Gas valve setting* on page 54).

### 3.21.1 Gas valve setting

#### Maximum heating output adjustment

- Make sure that the ambient thermostat (optional), if fitted, is set to **ON**.
- Select boiler operating mode "CH ONLY" by pressing the "Operating mode" button on the control panel until symbol  is shown.
- Start the "flue chimney" function (see *Flue cleaning function* on page 34). The boiler starts operating at maximum heat output.
- If a gas switching has been made, access the programming page and set the parameter **P0** based on the power and on the gas, as specified in Tab. 6 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - I.
- Check that **P4-P5-P6-P7-P8-P9** parameter values correspond to those specified in Tab. 6 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - I.
- Set flue gas CO2 content by turning the ratio adjuster **B** (see Fig. 24 Adjusting CO2 value) and ensure that reading falls within the limits of Tab. 11 Flue CO2 content. Let boiler flue cleaning function on and continue with the next point "Minimum heating output adjustment".

#### Minimum heating output adjustment

- Set boiler min. output operation by keeping **CH** - button pressed until the value corresponding to fan min. speed for the output and boiler gas is displayed, according to Tab. 6 Limits to be set for TSP parameters and default values in relation to boiler type (TSP0) - I.
- Boiler switches to min. output operation.
- Set flue gas CO2 content by turning the offset control **C** (see Fig. 24 Adjusting CO2 value) and ensure that reading falls within the limits of Tab. 11 Flue CO2 content.
- To exit the flue cleaning mode, press "Reset".




Fig. 24 Adjusting CO2 value

| Fuel        | CO2 value (%) |
|-------------|---------------|
| Natural gas | 9,0 - 9,6     |
| Propane     | 9,7 - 10,3    |

Tab. 11 Flue CO2 content

| Natural gas | Gas diaphragm (mm) |
|-------------|--------------------|
| Natural gas | 5,7                |
| Propane     | 4,3                |

Tab. 12 Gas diaphragm diameter (mm)

## 4. Testing the boiler

### 4.1 Preliminary checks

Before testing the boiler, it is recommended to check the following:

- the flue gas venting duct and the relative terminal are installed in conformity with the instructions: **there must be no leakage of combustion by-products from any of the gaskets.**
- the supply power to the boiler must be 230 V ~ 50 Hz;
- the system is correctly filled with water (pressure gauge reading 1 to 1.3 bar);
- any shut-off cocks in the system pipes are open;
- the mains gas type is correct for the boiler calibration: convert the boiler to the available gas when necessary; this operation must only be performed by qualified technical personnel;
- the gas supply cock is open;
- **there are no fuel gas leaks;**
- the main switch installed ahead of the boiler is turned on;
- the 3-bar safety valve is not stuck;
- there are no water leaks;
- the pump has not seized;
- the condensate trap installed on the boiler is discharging condensate correctly and is not stuck.



#### WARNING

---

**Should the boiler not be installed in compliance with the prevailing laws and standards, notify the system supervisor and do not test the boiler.**

---

### 4.2 Switching on and switching off

To switch the boiler on and off, refer to the **“Instructions for the User”**.

## 5. Maintenance



### WARNING

---

**Any maintenance (and repair) work must only be carried out by qualified personnel.**

---

The user is strongly advised to have the product serviced and repaired by a service centre or qualified personnel. Appropriate boiler maintenance ensures efficient operation, environment preservation, and safety for people, animals and objects.

**The boiler must be serviced at least once every year.**



### WARNING

---

**Disconnect electric power supply before starting any maintenance procedure, involving replacement of components and/or cleaning inside parts of boiler.**

---

### 5.1 Maintenance schedule

Maintenance operations include check and cleaning procedures. In particular:

#### ***Inspections and checks***

- Check general integrity of the boiler.
- Check boiler and network gas supply for leakage.
- Check gas supply pressure to boiler.
- Check boiler ignition sequence.
- Check the condition and seal integrity of the flue gas venting ducts.
- Check integrity of safety devices of the boiler in general.
- Check for water leaks and oxidised areas on the boiler's couplings.
- Check efficiency of the system safety valve.
- Check expansion vessel filling pressure.
- Check water pressure switch efficiency.
- Check boiler combustion parameters by flue gas analysis
- check the state of combustion fan.
- Check correct draining of condensate from the condensate trap installed on the boiler.

#### ***The following cleaning is to be done***

- Clean the general interior of the boiler.
- Clean the gas nozzles.
- Clean the air intake and flue gas venting circuits.
- Clean the heat exchanger.
- clean the condensate trap and discharge ducts.

#### ***When checking the boiler for the very first time, also verify:***

- Boiler room suitability.
- Diameter and length of flue gas system ducts.
- Boiler installation in accordance to this "Installation use and maintenance" manual instructions.



### WARNING

---

**Should the boiler not operate correctly, while not posing danger to people, animals or property, notify the system supervisor both verbally and in writing.**

---

### 5.2 Combustion analysis

The combustion parameters of the boiler, which have to be checked in order to determine efficiency and emissions, must be measured in compliance with applicable legislation and standards.



## 6. Decommissioning, disassembly and disposal



### Warning

---

**If you decide to definitively decommission the boiler, have decommissioning, disassembly and disposal procedures carried out by qualified personnel, only.**

**The user is not authorised to carry out such operations.**

---

Decommissioning, disassembly and disposal operations must be performed with boiler cold and disconnected from gas and power mains.

The materials the boiler is made of can all be recycled.

Once disassembled, boiler must be disposed of in accordance with the national prevailing regulations.

## 7. Malfunctions, possible causes and solutions

### 7.1 Troubleshooting

| BOILER STATUS                            | MALFUNCTION                                       | PROBABLE CAUSE  | USER'S TASKS   | QUALIFIED PERSONNEL'S TASKS                       |  |
|--|---|---|--|---|--|
| E01*                                     | Burner does not ignite                            | Gas supply failure.   | Check gas supply.<br>Check gas supply cock or gas network safety valve intervention. |   |  |
|  |   | Gas valve is disconnected.  | Contact qualified personnel  | Reconnect it.                                     |  |
|  |   | Gas valve is faulty.  | Contact qualified personnel  | Replace it.                                       |  |
|  |   | The board is faulty.  | Contact qualified personnel  | Replace it.                                       |  |
|  | Burner does not ignite: no spark                  | Ignition relay is faulty.   | Contact qualified personnel  | Replace the electrode.                            |  |
|  |   | Ignition transformer is faulty                                      | Contact qualified personnel  | Replace the ignition transformer.                 |  |
|  |   | Electronic board does not ignite. It is faulty.                     | Contact qualified personnel  | Replace electronic board.                         |  |
|  | Burner ignites for a few seconds and goes off.    | Electronic board does not detect flame: inverted phase and neutral. | Contact qualified personnel  | Verify correct neutral and phase connection.      |  |
|  |   | Detection electrode cable is interrupted.                           | Contact qualified personnel  | Reconnect or replace wire.                        |  |
|  |   | Detection electrode is faulty.                                      | Contact qualified personnel  | Replace the electrode.                            |  |
|  |   | Electronic board does not detect flame: it is faulty.               | Contact qualified personnel  | Replace electronic board.                         |  |
|  |   | Ignition heat input setting is too low.                             | Contact qualified personnel  | Increase it.                                      |  |
| Minimum heat input is not set correctly. |   | Contact qualified personnel   | Check burner setting.  |   |  |
| E02*                                     | Flow temperature exceeded the max. allowed value. | Circulation pump is faulty.   | Contact qualified personnel  | Replace it.                                       |  |
|  |   | Circulation pump is seized.   | Contact qualified personnel  | Check pump electrical connection.                 |  |
| E03*                                     | Flue thermostat triggering.                       | Poor flue draught.  | Contact qualified personnel  | Check the chimney and ambient air-intake grilles. |  |
|  |   | Flue vent/air intake duct is obstructed.                            | Contact qualified personnel  | Check for any duct obstruction, and eliminate.    |  |
|  |   | Flue gas thermostat is faulty.                                      | Contact qualified personnel  | Replace it.                                       |  |
| E04**                                    | CH system water pressure is low.                  | The system is leaking.  | Check system.  |   |  |
|  |   | Pressure transducer is disconnected.                                | Contact qualified personnel  | Reconnect it.                                     |  |
|  |   | Pressure transducer is faulty.                                      | Contact qualified personnel  | Replace it.                                       |  |
| E05**                                    | CH probe failure                                  | Flow probe is electrically disconnected.                            | Contact qualified personnel  | Reconnect it.                                     |  |
|  |   | Flow probe faulty.  | Contact qualified personnel  | Replace it.                                       |  |
| E06**                                    | DHW probe failure (KC only).                      | DHW probe is electrically disconnected.                             | Contact qualified personnel  | Reconnect it.                                     |  |
|  |   | DHW probe faulty.   | Contact qualified personnel  | Replace it.                                       |  |

| BOILER STATUS | MALFUNCTION  | PROBABLE CAUSE  | USER'S TASKS                | QUALIFIED PERSONNEL'S TASKS   |
|---------------|--|---|-----------------------------|---|
| E12**         | Water heater probe fault (KR/KRB with external water heater, optional and NTC probe, optional for Kr, standard for KRB). | Probe is disconnected.                                  | Contact qualified personnel | Reconnect it.   |
|               |  | Probe is faulty.  | Contact qualified personnel | Replace it.   |
| E15**         | Return probe failure.  | Probe is disconnected.                                  | Contact qualified personnel | Reconnect it.   |
|               |  | Probe is faulty.  | Contact qualified personnel | Replace it.   |
| E23**         | External probe fault (only with connected external probe).   | Probe is disconnected.                                  | Contact qualified personnel | Reconnect it.   |
|               |  | Probe is faulty.  | Contact qualified personnel | Replace it.   |
| E31**         | Remote Control connection failure (only shown on Remote Control display).  | The Remote Control is not connected to boiler board.    | Contact qualified personnel | Reconnect it.   |
|               |  | Remote control faulty.                                  | Contact qualified personnel | Replace it.   |
|               |  | Boiler board is faulty.                                 | Contact qualified personnel | Replace it.   |
| E40*          | Fan failure.   | Fan disconnected.                                       | Contact qualified personnel | Reconnect it.   |
|               |  | Fan faulty.   | Contact qualified personnel | Replace it.   |
| E44**         | Ambient probe fault (only with connected ambient probe).   | Probe is disconnected.                                  | Contact qualified personnel | Reconnect it.   |
|               |  | Probe is faulty.  | Contact qualified personnel | Replace it.   |
| E70*          | Problems with the air flow rate. Possible clogging on flue gas side of the heat exchanger.                               | Heat exchanger is clogged on the flue gas side.         | Contact qualified personnel | Check the heat exchanger.   |
| E77           | Problems in the electronic board power supply.   | Power mains not stable.                                 | Contact qualified personnel | Check the power mains.  |
| E78*          | Flow temperature increases too quickly.  | Pump is seized.   | Contact qualified personnel | Unseize the pump.   |
|               |  | Pump is faulty.   | Contact qualified personnel | Replace it.   |
|               |  | Air present inside heating system.                      | Contact qualified personnel | Bleed the air from the boiler by opening the jollies on the exchanger and pump. |
| E80*          | The $\Delta T$ between flow and return is not within the limits.   | Flow and/or return probes are faulty.                   | Contact qualified personnel | Replace them.   |
|               |  | Obstructed bypass pipe                                  | Contact qualified personnel | Remove any obstructions, or replace the pipe.                                   |
|               |  | The bypass valve is not assembled or wrongly assembled. | Contact qualified personnel | Restore bypass valve correct assembling.  |
|               |  | Heat exchanger primary circuit is obstructed.           | Contact qualified personnel | Clean or replace the exchanger.   |
| E81*          | The water circulation is the boiler is not correct.  | System pressure too low.                                | Contact qualified personnel | Check the system.   |
|               |  | Water does not circulate correctly in the system.       | Contact qualified personnel | Check the system.   |



0LIBMCEN66

Fondital S.p.A.  
25079 VOBARNO (Brescia) Italy - Via Cerreto, 40  
Tel. +39 0365/878.31  
Fax +39 0365/878.304  
e mail: [info@fondital.it](mailto:info@fondital.it)  
[www.fondital.com](http://www.fondital.com)

The manufacturer reserves the right to modify his/her products as deemed necessary, without altering the basic characteristics of the products themselves.

Uff. Pubblicità Fondital IST 03 C 971 - 01 Aprile 2016 (04/2016)