

GB
IE

IMPORTANT

FOLLOW COMMISSIONING INSTRUCTIONS
OBSERVE THE WARRANTY CONDITIONS
READ THE WHOLE MANUAL CAREFULLY
NO SAFETY DISCHARGE TO BE REDUCED IN SIZE.
CONDENSE TO BE 32 mm PVC

SERVICING

*Commissioning
Gas conversion
Maintenance
Operating faults
Options
Parts lists*



THI 0.9-9 C
THI 2-17 C / THI 5-25 C
THI 5-25 M75 V

GEMINOX

B O I L E R S

High technology heating

**T
E
C
H
N
I
C
A
L

I
N
S
T
R
U
C
T
I
O
N
S**



T30.36291.03

CONTENT

I - COMMISSIONING	4
1 - PROTECTION OF THE INSTALLATION.....	4
1.1 - Bionibal	4
1.2 - Bionibagel	4
1.3 - Products equivalent to Bionibal or Bionibagel	4
2 - FILLING THE INSTALLATION WITH WATER	5
3 - GAS SUPPLY	5
4 - SETTING THE DOMESTIC HOT WATER FLOW RATE.....	5
4.1 - THI 5-25 M75 V	5
5 - SETTING THE MAXIMUM POWER IN HEATING MODE.....	6
6 - VERIFICATIONS PRIOR TO COMMISSIONING	6
7 - USER INFORMATION.....	6
8 - COMMISSIONING	7
9 - FLAME SETTING	8
10 - COMBUSTION PRODUCT CHECKING.....	8
11 - ASSEMBLING THE COVER.....	8
12 - INFORMATION AVAILABLE FORM THE "INFO" KEY OF THE BOILER CONTROL PANEL	9
II - GAS CONVERSION	10
1 - GAS CHANGE	10
1.1 - Conversion from natural gas to Propane	10
1.2 - Conversion from propane to natural gas	10
2 - GAS/CO ₂ /CO/NO _X FLOW CONTROL AND SERVICE PRESSURE CONTROL	11
2.1 - Surveillance procedure	12
2.2 - Setting table	13
III - MAINTENANCE	14
1 - SERVICING THE FAN AND THE BURNER.....	14
2 - SERVICING THE HEAT EXCHANGER OF THE BOILER SHELL.....	15
3 - TANK MAINTENANCE (THI..M75 MODELS).....	15
4 - CHECKING ACCESSORIES	16
5 - EXPANSION VESSEL PRE-INFLATION PRESSURE CHECK	16
6 - COMBUSTION PRODUCT CONDUITS (FLUE)	16
7 - DRAINING	16
8 - SENSOR RESISTANCES	17
9 - PRESSURE SENSOR.....	17
IV - OPERATING FAULTS	18
1 - OPERATING FAULTS LIST	18
2 - MAINTENANCE.....	20
2.1 - Maintenance alarm	20
2.2 - Maintenance code	20
2.3 - Coding of maintenance alarms	20
2.4 - General activation of maintenance alarms	20
2.5 - Activation of the individual maintenance alarm	21
2.6 - Acknowledgement of maintenance alarms	21
2.7 - Resetting the maintenance alarms	21

V - OPTIONS	22
1 - REAR WALL SPACER	22
2 - MOUNTING BRACKET FOR LIGHT STUD WALLS	22
2.1 - THI...M75 V	22
3 - SET-UP TAKING ROOM TEMPERATURE INTO ACCOUNT (REG 73)	23
4 - LPB COMMUNICATION CLIP-IN KIT (REG 130)	23
5 - 2ND HEATING CIRCUIT CLIP-IN KIT	23
6 - DOUBLE CIRCUIT KIT (REG 125).....	24
7 - PROGRAMMABLE RELAY CLIP-IN KIT (REG 127).....	24
8 - PROGRAMMABLE RELAY CLIP-IN KIT (WITHOUT SENSOR) (REG 134)	24
9 - ZHTI 46 CONTROL UNIT (REG 129).....	25
10 - ZHTI 47 CONTROL UNIT (REG 128).....	25
11 - SOLAR HEATING CONTROL KIT (REG 152)	25
12 - DHW SENSOR KIT.....	26
13 - SELECTOR VALVE KIT FOR CONNECTING THI..C/BS	26
14 - TIMER KIT	26
VI - PARTS LISTS	27

2 - FILLING THE INSTALLATION WITH WATER

- The installation will have to be rinsed before the boiler is filled with water.
 - To ensure proper boiler bleeding during the installation's filling stage:
 - Filling the DHW tank for the THI C+ BS/ THI M75 models :
 - . Fill the tank with water by using the safety control box of the installation (item. 47, fig. 47 - page 39 and item. 18, fig. 48 - page 40 - chapter IV - INSTALLATION - INSTALLATION MANUAL), taking care to open a hot water tap,
 - . After filling, check that the tank access flap is tightened correctly.
 - Filling the installation for all models:
 - . Open the heating flow/return isolation valves,
 - . Open the cold water inlet valve,
 - . Fill the installation slowly (to make degassing easier) by using the valve of the filling system,
 - . check the leaktightness of the circuit,
 - . Bleed the entire installation, particularly the radiators. Continue to fill the system until a pressure of approximately 1.5 bar is reached.
- To read the pressure:
- 1) *Switch on the boiler*
 - 2) *Press the info key twice*
 - 3) *The value of the pressure is shown on the display*
- . turn off the filling valve.

3 - GAS SUPPLY

- Open the gas cock (item. 2, fig. 46 to fig. 48 - chapter IV - INSTALLATION - INSTALLATION MANUAL).
- Carefully bleed the gas piping. If the installation is new, the bleed evacuates the air that is contained in the piping so that the boiler has an adequate fuel.

The presence of air in the gas prevents the ignition of the burner and leads to safety shut-down by the flame monitoring unit.

This is the case both with a natural gas and a LPG new installation. With a LPG installation the storage tank must also be bled properly before commissioning.



The external discharge of the gas bleed must be carried out with all necessary safety measures.

- Check the tightness of the connectors and the airtightness of the gas circuit using a foaming product or a water column pressure gauge.

4 - SETTING THE DOMESTIC HOT WATER FLOW RATE

4.1 - THI 5-25 M75 V

Flow should be set for optimum hot water comfort:


- THI 5-25 M75: 12 l/min

5 - SETTING THE MAXIMUM POWER IN HEATING MODE


The maximum power of the boiler in heating mode can be limited. This operation requires modification of the PHz parameter in the boiler's LMU management unit.

Access to the PHz parameter is possible via the QAA 73 ambient temperature sensor (line 541) following the access mode.

The PHz value should be selected by following the diagram below. Adapting the boiler's maximum heating power to the maximum power of the installation helps avoid heavy loads during reheating phases and thus reduces the maximum sound output of the boiler.



6 - VERIFICATIONS PRIOR TO COMMISSIONING


- Ensure that the installation has been issued with a certificate of conformity granted by an approved organisation (according to the installation standards),
- Check that the boiler is adequately adapted to the gas used and that there are no gas leaks.
- Check that the boiler is filled with water and under pressure (1.5 bar) and that there are no leaks,
 -  **Never let the pressure drop below 1 bar.**
- Check that the electrical connections of the boiler are correct: 230 V, 50 Hz, earth connection compliant, polarities correct,
- Check that the combustion products outlet is correctly assembled, that there are no leaks and no obstruction,
- Check that the heating system ventilations are not obstructed,
- Check that the condensate siphons of the flues are filled with water,
- Check that the condensate outlet is connected properly and that there are no leaks.
- Check the system is totally cleaned and had been cleaned and flushed in accordance with BS 7593. Failure to do this may invalidate the warranty.

7 - USER INFORMATION

The heating engineer must inform the user about the unit's operating mode. In particular the user must be informed about the function and the operation of the safety systems and the need for regular servicing by a qualified person.

8 - COMMISSIONING

- Check that all the water stop valves and the gas cock are open,
- the boiler's external electrical circuit-breaker,
- Press button (14) to ON (Button illuminated).



- The following references will appear one after the other on the boiler control panel display (13),





For this example, this means that it is the version 3.00 of the LMU management unit and version 1.01 of the control interface.

When starting up the boiler, the LMU management unit recognises all the accessories connected (sensors, mixing valve, pumps, etc.) and automatically checks the values and settings according to the type of installation.



If a problem occurs, the LED “alarm signal” (11) is on (red):

- Press RESET (10) to reset the boiler,
- If the alarm persists, consult the list of operating faults in chapter IV - OPERATING FAULTS - page 18 - SERVICING MANUAL.

Display	Description	Consequences according to type of installation
	<p>“Function” key (1) gives access to 3 operating modes by pressing:</p> <ul style="list-style-type: none"> - auto mode: LED (4) on - winter mode: LED (5) on - summer mode: LED (4) and (5) off 	
	<p>LED (5) on / LED (4) off: Winter mode</p> <p>The boiler provides heating and domestic hot water</p>	<ul style="list-style-type: none"> - <i>Basic boiler model (without outside sensor and room sensor)</i> <ul style="list-style-type: none"> • Auto mode is inaccessible <ul style="list-style-type: none"> . The heating and hot water temperatures are set manually by using the boiler potentiometers. - <i>Boiler with outside sensor only</i> <ul style="list-style-type: none"> • Auto mode is not activated, <ul style="list-style-type: none"> . Heating operates continually except if there is a request for hot water, . The hot water temperature is set manually on the boiler potentiometer. - <i>Boiler with outside sensor and room sensor</i> <ul style="list-style-type: none"> • The heating and hot water temperatures are set via the room sensor QAA73.
	<p>LED (4 and 5) off: Summer mode</p> <p>The boiler provides domestic hot water only</p>	<ul style="list-style-type: none"> - <i>Basic boiler model (without outside sensor and room sensor)</i> <ul style="list-style-type: none"> • Auto mode is inaccessible <ul style="list-style-type: none"> . The hot water temperature is set manually by using the boiler potentiometers. - <i>Boiler with outside sensor only</i> <ul style="list-style-type: none"> • Auto mode is not activated, <ul style="list-style-type: none"> . The hot water temperature is set manually on the boiler potentiometer. - <i>Boiler with outside sensor and room sensor</i> <ul style="list-style-type: none"> • The hot water temperature is set via the room sensor QAA73.

Display	Description	Consequences according to type of installation
	<p>LED (4 and 5) on: Auto winter mode</p> <p>The boiler provides heating and domestic hot water</p>	<p>Auto mode is active:</p> <ul style="list-style-type: none"> - <i>Boiler with outside sensor only</i> <ul style="list-style-type: none"> • The heating starts up automatically and only when the average outside temperature computed by the LMU is below 19°C. • The hot water temperature is set manually on the boiler potentiometer. - <i>Boiler with outside sensor and room sensor</i> <ul style="list-style-type: none"> • The heating starts up automatically and only when the average outside temperature computed by the LMU is below 19°C. • The heating and hot water temperatures are set via the room sensor QAA73.
	<p>LED (4) on / LED (5) off: Auto summer mode</p> <p>The boiler provides domestic hot water only</p>	<p>Auto mode is active:</p> <ul style="list-style-type: none"> - <i>Boiler with outside sensor only</i> <ul style="list-style-type: none"> • The heating stops automatically and only when the average outside temperature computed by the LMU is below 19°C. • The hot water temperature is set manually on the boiler potentiometer. - <i>Boiler with outside sensor and room sensor</i> <ul style="list-style-type: none"> • The heating stops automatically and only when the average outside temperature computed by the LMU is below 19°C. • The hot water temperatures are set via the room sensor QAA73.

9 - FLAME SETTING

- After switching the boiler on:
- Check the flame control by disconnecting the ionizing electrode:
- The boiler goes into safety mode after two ignition attempts (display  and )

10- COMBUSTION PRODUCT CHECKING

The boiler is preset in the factory to operate with natural gas H (G20).


If the gas type is changes at the first commissioning,


check the combustion products according to the procedure described in chapter II - GAS CONVERSION - page 10 - SERVICING MANUAL.

11 - ASSEMBLING THE COVER




















After the commissioning and performing all the checks, put back the front panel of the boiler.

- fit the front panel (item G) to the frame of the boiler and support it with the latch (item F),
- connect the terminal of the earth wire (item O) positioned in the boiler to the tab on the front panel (item G),
- shut the front panel using the latch (item F) on the low of the boiler,
- lock both latches (item F) using the 2 screws (item E).





12- INFORMATION AVAILABLE FORM THE "INFO" KEY OF THE BOILER CONTROL PANEL

Initial display:																			
the green "°C" LED is on  the display shows the heating flow temperature.																			
Return to the initial display:																			
To return to the initial position (i.e. the display indicates the heating flow temperature) during the various levels described below or during any other actions on the boiler control panel:																			
- Press the  info key until the display reads  then release the key.																			
To access the different statuses of LEVEL 1:																			
- Press the  key once to move successively from one information to another (the corresponding information appears on the display).																			
- OR: wait for 8 minutes																			
General information (final user level)																			
LEVEL 1	<table border="1"> <thead> <tr> <th>Displays</th> <th>Variable name</th> <th>Functions</th> </tr> </thead> <tbody> <tr> <td></td> <td>Tbw1st1</td> <td>DHW value measured by the DHW 1 sensor (e.g. 45°C)</td> </tr> <tr> <td></td> <td>Druck</td> <td>Boiler water pressure (e.g. 1.5)</td> </tr> <tr> <td></td> <td>Betr.Phase</td> <td>Operating phase (e.g. 11)</td> </tr> <tr> <td></td> <td>Meldecode</td> <td>Fault diagnostic (system) code (e.g. 0 and the display flashes)</td> </tr> <tr> <td></td> <td>Tk1st</td> <td>Boiler flow temperature (= initial display)</td> </tr> </tbody> </table>	Displays	Variable name	Functions		Tbw1st1	DHW value measured by the DHW 1 sensor (e.g. 45°C)		Druck	Boiler water pressure (e.g. 1.5)		Betr.Phase	Operating phase (e.g. 11)		Meldecode	Fault diagnostic (system) code (e.g. 0 and the display flashes)		Tk1st	Boiler flow temperature (= initial display)
	Displays	Variable name	Functions																
		Tbw1st1	DHW value measured by the DHW 1 sensor (e.g. 45°C)																
		Druck	Boiler water pressure (e.g. 1.5)																
		Betr.Phase	Operating phase (e.g. 11)																
		Meldecode	Fault diagnostic (system) code (e.g. 0 and the display flashes)																
	Tk1st	Boiler flow temperature (= initial display)																	

II - GAS CONVERSION

Check that the boiler is properly adapted to the gas used, otherwise change the gas.

1 - GAS CHANGE




This operation must be carried out by a qualified person equipped with a calibrated combustion analyser.

Prior to any servicing cut the electrical and gas supplies.

The boiler is preset in the factory for natural gas H (G20) 20 mbar.

When changing the gas, the "gas setting" label that is in the [gas conversion set](#) must be fixed on the inside of the boiler so as to indicate the new setting.

Check the gas circuit for leak tightness after each intervention on the boiler.



1.1 - Conversion from natural gas to Propane

1.1.1 - THI 5-25 C/M75 models only

- Conversion to propane (G31) requires [the gas conversion set](#) (ref : V07.31649)

Refer to the installation instructions of [the gas conversion set](#)

1.2 - Conversion from propane to natural gas

1.2.1 - THI 5-25 C/M75 models only


- Conversion to natural gas requires [the gas conversion set](#) (ref : V07.31650)

Refer to the installation instructions of [the gas conversion set](#)

2 - GAS/CO₂/CO/NO_x FLOW CONTROL AND SERVICE PRESSURE CONTROL

Fig. 5

**GAS VALVE
SIEMENS/LANDIS
ref : VGU87A0236**



P_i = Network gas pressure
Natural gas H (G20) : 20 mbar,
Propane (G31) : 37 mbar.

P_o = Outlet gas pressure to the burner.

PL = Air pressure control (fan/ gas-valve)


V = Adjust the slope of the characteristic of the air/gas ratio only when the burner **is at high rate**. This setting is carried out in the factory for natural gas type H (G20). This means that the pressure P_o can be changed to obtain the required gas flow (section 2.2 - page 13 - chapter II - GAS CONVERSION - SERVICING MANUAL).



Screw to increase the gas flow

K = Adjust the parallel shift of the characteristic of the air/gas ratio only when the burner **is at low rate**. This screw is pre-set in the factory. Its setting must not be normally modified even for changing gas. If however an adjustment is required, it may be carried out with a low scale pressure gauge 0-10 mmCE, and a CO₂, CO analyser. **Screw to increase the gas flow.**

**GAS VALVE
SIT
ref : 848 SIGMA**



P_{IN} = Network gas pressure
Natural gas H (G20) : 20 mbar,
Propane (G31) : 37 mbar.

P_{OUT} = Outlet gas pressure to the burner.r.

PL = Air pressure control (fan/ gas-valve)


1 = Adjust the slope of the characteristic of the air/gas ratio only when the burner **is at high rate**. This setting is carried out in the factory for natural gas type H (G20). This means that the pressure "P_{OUT}" can be changed to obtain the required gas flow . (section 2.2 - page 13 - chapter II - GAS CONVERSION - SERVICING MANUAL).



Screw to decrease the gas flow

2 = Adjust the parallel shift of the characteristic of the air/gas ratio only when the burner **is at low rate**. This screw is pre-set in the factory. Its setting must not be normally modified even for changing gas. If however an adjustment is required, it may be carried out with a low scale pressure gauge 0-10 mmCE, and a CO₂, CO analyser

To modify the setting, if it is required, take off the protection screw, and **screw to increase the gas flow.** When the adjustments are realized, reset the protection screw.



B₂₃ chimney flue :

- Combustion control is carried out on the combustion product outlet system external and directly at the boiler outlet (with the boiler unit assembled). This opening must be closed again after checking

C₁₃ - C₃₃ balanced flue :

- Combustion control is carried out on the boiler through the opening (23) provided for this purpose after the cap is removed. This opening must be closed again after checking.

2.1 - Surveillance procedure

- To commission the burner:
 - Activate the regulator shut-down function - service key (6) (section 3.11 - page 20 - chapter III - OPERATION - INSTALLATION MANUAL) :
 - the code flashes on the display screen (13),
- Gradually position the d.h.w. potentiometer (3) to the maximum on the right:
 - the burner switches to max. rate,
- Gradually move the **V or 1** adjustment screw of the gas unit (fig. 5 - page 11 - chapter II - GAS CONVERSION - SERVICING MANUAL) to obtain a stable flame.
- Check the CO₂/CO ratio (see setting table section 2.2 - page 13 - chapter II - GAS CONVERSION - SERVICING MANUAL),
- Set the d.h.w. potentiometer (3) to the maximum on the left:
 - the burner switches to the minimum rate,
- Check the CO₂/CO ratio (see setting table section 2.2 - page 13 - chapter II - GAS CONVERSION - SERVICING MANUAL),
- If necessary:
 - adjust screw **K or 2** (fig. 5 - page 11 - chapter II - GAS CONVERSION - SERVICING MANUAL) (tightening and untightening increases and decreases gas flow).



Before starting the minimum rate setting (V or 1 and K or 2 screws), wait for a stable CO₂/CO analyser read-out. Repeat switching from the minimum rate to the maximum rate several times to ensure that the setting has been done properly.

- to return to normal operation, press on the sweep key (6) for 3 seconds then release it.

Note:

- Remember to reposition the d.h.w. potentiometer (3) to its initial value to return to the required d.h.w. setting.

2.2 - Setting table

Models			THI		
			0.9-9 C	2-17 C	5-25 C/M75
Natural gas burner type			X07.36236	X07.36235	X07.36238
Heat output (Heating)	30/50°C	kW	1.2/9.8	2,6/18,3	5.4/25.8
	60/80°C	kW	1.0/9.1	2,3/16,9	4.8/23.9
Heat input (Heating)		kW	1.1/9.3	2,5/17,4	5.0/24.5
∅ Gas reducer	Nat Gas H Propane	mm	3.00 -	4,20 -	5.75 4.65
∅ Air reducer	Nat Gas H Propane	mm	12 -	18,2 -	29 27
Gas flow (15°C, 1013 mbar)	Nat Gas H Propane	m ³ /h	0.12/0.98 -	0,26/1,84 -	0.53/2.59 0.39/1.90
Gas pressure P _o / P_OUT (gas unit to burner)	Nat Gas H Propane	mbar	0.25/8.0 -	0,3/6,5 -	0.35/4.50 0.35/4.50
Servo-system air pressure (PL)	Nat Gas H Propane	Pa	35/950 -	40/810 -	40/600 40/600
CO ₂ Emission	Nat Gas H Propane	%	8.0-8.5/9.0-9.5 -		8.0-8.5/9.0-9.5 10.0-10.5/10.5-11.0
CO Emission	Nat Gas H Propane	ppm	0/20		0/20 0/40

- Combustion product evacuation outlet back pressure: 0 mmCE.
- **P_o / P_OUT** = Gas pressure at the gas valve regulator outlet.
- **PL** = Servo-system air pressure (fan - gas unit).
- The P_o / P_OUT and PL values may be more or less high according to whether back pressure is greater or smaller.

III - MAINTENANCE

The annual inspection of the boiler and of the combustion product outlet is compulsory and validates a warranty. It must be carried out by a qualified person.

Spare parts must be ordered by using the references listed in chapter VI - PARTS LISTS - page 27 - SERVICING, and specifying the type and serial number of each part.




Before any servicing, cut the power supply. Close the gas inlet of the boiler and the isolation valves if required.


If the boiler is removed, provide a port at the end of the gas piping.



Remove the front panel (item G) from the boiler and disconnect the earth wire (item O).



1 - SERVICING THE FAN AND THE BURNER



Check the state of the ventilator and the burner and clean them if necessary (following their service instructions).

Disassembling the burner/fan unit:


- Electrically disconnect the burner/fan unit:
 - remove the 2 cable lugs connecting the ignition electrode (3) to the ignition transformer (A),
 - remove the cable lug connecting the ionising electrode (2) to the X2-05 terminal of the boiler control panel,
 - remove the fan (7):
 - from the connector of the fan power cord,
 - from the connector of the fan's PWM signal,
- disconnect the air/gas servo-system (B) from the gas valve,

Disassembling the fan:

- Unscrew the four screws (1) fixing the fan (7) to the burner's air sleeve (6),
- Clean it using a domestic vacuum cleaner by placing the suction device over the air inlet and outlet successively.

Disassembling the burner:

- Unscrew the four screws fixing (5) the burner (4) to the boiler shell (8),
- Disassemble the nut (9),
- Clean the burner (4) using a domestic vacuum cleaner by placing the suction device over the air inlet and the gas inlet successively,
- Check the ignition electrodes (3) and the ionisation electrodes (2).



When fitting back the burner/fan unit:

- Replace the seal at the level of the nut (9) and check that there are no gas leaks,
- when fitting the fan back onto the boiler:
 - check that the fan/burner seal (10) is correctly positioned,
 - check that there is no leakage at this seal and replace it if necessary.
- check that the burner (4) and boiler shell (8) have no leaks - replace the seal if necessary.

2 - SERVICING THE HEAT EXCHANGER OF THE BOILER SHELL

The heat exchanger must be cleaned once the burner has been disassembled (section 1 - page 14 - chapter III - MAINTENANCE - SERVICING).

- Sprinkle the heat exchanger with water. The water is evacuated through the condensate evacuation siphon,
- when reassembling the burner onto the boiler shell check the correct positioning of the gasket.

3 - TANK MAINTENANCE (THI..M75 MODELS)

- The stainless steel hot water tank is resistant to lime scale. Nevertheless, the access flap gives access to the tank and the exchanger.

4 - CHECKING ACCESSORIES

- Check that the safety and control devices (3 bar safety valve, air bleed, safety control box, etc.) are operating properly.
- Clean the condensate drain siphon and then fill it with water.
- Also check that neither the installation nor the boiler present any water or fuel leaks (leaks may

produce a risk for safety and shorten the lifespan).

- When it is frequently necessary to add water to maintain pressure in the installation, even though no leaks have been discovered, perform an expansion vessel check (section 5 - page 16 - chapter III - MAINTENANCE - SERVICING).

5 - EXPANSION VESSEL PRE-INFLATION PRESSURE CHECK

- Drop the pressure in the heating installation by opening the drain cock or the safety valve (pressure gauge reading under 0.5 bar).
- Check the pressure in the expansion vessel and if necessary bring it back up to pressure, or replace it if the membrane is punctured (water present in the inflating valve).
- To optimise the efficiency of the vessel:

- adjust its pre-inflation pressure in line with the installation. It must correspond to the static height of the installation (H) expressed in bars (height between the highest point of the installation and the expansion vessel, with 10 metres = 1 bar),
- adjust the filling pressure of the installation to a value of over 0.2 bar above the pre-inflation pressure of the vessel (after totally bleeding the air from the installation).

6 - COMBUSTION PRODUCT CONDUITS (FLUE)

- Check the combustion product evacuation conduit and the air inlet conduit at least once a year

(airtightness of the parts that may be disassembled - conduits not obstructed).


7 - DRAINING

- Cut the power supply,
- turn off the gas cock,
- turn off the heating flow/return valves (if they are fitted),
- connect the drain valve (item. 18) to the sewage system,
- open the drain valve.



Ensure that the air bleed (item. 16) is open, as soon as the pressure gauge indicates a zero pressure to allow air to enter the boiler shell.

Fig. 9



8 - SENSOR RESISTANCES


The resistance of the sensors must be measured after they have been disconnected from the control panel.

Resistance values of the sensors	
Temperature	Heating outlet sensor Boiler return sensor Domestic hot water sensor Flue gas sensor
0.00 °C	32624
10.00 °C	19897
15.00 °C	15711
20.00 °C	12493
25.00 °C	10000
30.00 °C	8056
40.00 °C	5324
50.00 °C	3599
60.00 °C	2483
70.00 °C	1748
80.00 °C	1252
90.00 °C	912

Resistance values of the sensors	
Temperature	Outside sensor
-20.00 °C	7578
-15.00 °C	5861
-10.00 °C	4574
-5.00 °C	3600
0.00 °C	2857
5.00 °C	2284
10.00 °C	1840
15.00 °C	1492
20.00 °C	1218
25.00 °C	1000
30.00 °C	826,8
35.00 °C	687,5

9 - PRESSURE SENSOR



















The output voltage on the water pressure sensor is measured between the terminals GND (-) and OUT.



IV - OPERATING FAULTS

1 - OPERATING FAULTS LIST

Display A0	Description	Solution
10	Outside sensor fault	Check that the sensor is correctly fitted and connected
20	Boiler sensor 1 fault	Check that the sensor is correctly fitted and connected
28	Flue gas detector fault	Check that the sensor is correctly fitted and connected
32	Flow sensor 2 fault	Check that the sensor is correctly fitted and connected
40	Return sensor 1 fault	Check that the sensor is correctly fitted and connected
50	Domestic hot water sensor 1 fault	Check that the sensor is correctly fitted and connected
51	Room device 1 faulty	Check the boiler connections
62	Room device 1 error or radio clock error	Check compatibility of the room device or clock
78	Water pressure sensor fault	Check the connections of the pressure sensor
81	Short-circuit on LPB or no voltage	Check the wiring
82	Two identical addresses on the LPB	Check the addressing
91	Loss of data in the EEPROM	Change the LMU
92	Component fault in the LMU	Change the LMU
88 00	Two master clocks (only one normally), programming problem	Check parameter 96 of the QAA73 (only one device can have the message "QAA73")
88 05	Maintenance alarm	Check the maintenance code value, QAA 73 setting 726 (section 2 -page 20 - chapter IV - OPERATING FAULTS - SERVICING)
88 10	STB (boiler overheating safety) activated	Check that shunt X3-01 is present and whether the installation water flow is sufficient (circulating pump, isolation valve, etc.)
88 11	Response of the safety thermostat	Check whether the installation water flow is sufficient (circulating pump, isolation valve, etc.)
88 13	Flue gas alarm displayed (problem of the flue gas temperature being too high)	Check whether the boiler is not on thermal overload or that the exchanger is not clogged
88 17	Water pressure too high	Check and adjust the pressure level if necessary with $P < 4$ bar
88 18	Water pressure too low	Check and adjust the pressure level if necessary with $P > 0.4$ bar

Display A0	Description	Solution
	Flame failure while the boiler is operating	Check and adjust the gas valve, check the ionisation electrode and the connections, possible live-neutral inversion of the transformer supply
	Poor air supply	Check the ventilator and the air inlet
	Maximum flue gas temperature exceeded	Check whether the boiler is not on thermal overload or that the exchanger is not clogged
	Safety device activated	Check that shunt X10-03 is present and that the wires are properly connected
	No flame formed after the safety time period	Check that the gas reaches the boiler (Pi), check the condition of the gas valve, if there is a major adjustment fault on the gas valve, check the condition of the transformer, cables, ignition electrode, ionisation current value
	Segment number or unauthorised addressing on LPB or LMU	Check the addressing consistency
	Incompatibility between the LMU and LPB	Check the addressing consistency
	New LMU configuration	Check the b0 internal code
	LMU setting error	Check the b0 internal code
	The boiler is blocked	Press Reset to clear the message
	Violation of the plausibility criteria (STB related criteria)	Check the value of the criteria related to the boiler overheating security
	The minimum speed threshold of the fan is not reached	Check the wiring of the fan and LMU, ensure that the fan is turning correctly
	The maximum speed threshold of the fan is exceeded	Check the mains supply and the fan cable connections
	The service function is active	-
	The regulator shut-down function is active	-
	The boiler is in setting mode	This appears after one or more settings are loaded either by the QAA73 or by the PC TOOL. This means that a reset is necessary to validate the new setting(s) and for the boiler to return to normal operating.
	Modem function is active	-
	"Controlled screed drying" function is active	-

Note :

- The **last 5 working faults** are accessible through the QAA 73, from LMU version 3.00, lines 728 /

729 / 730 / 731 / 732. The last saved fault code is displayed at line 728.

2 - MAINTENANCE

Maintenance alarms can be automatically triggered, indicating that maintenance jobs are due. The following reasons for maintenance alarms can be delivered:

- Interval of burner hours run since last regular service visit exceeded.
- Interval of the number of startups since last regular service visit exceeded.
- Number of months since last regular service visit exceeded.

The alarm displayed is always the maintenance alarm that occurred first.

There is no storage for the maintenance alarms since all pending alarms can be checked at any time via the counter readings or the relevant parameters.

2.1 - Maintenance alarm

If a maintenance alarm occurs, an error code "105 maintenance" appears on the display of the boiler and / or room unit.

This code does not give precise information on maintenance but is only a general maintenance note.

These maintenance alarms are a priority lower than that of the error codes to ensure the error codes prevail.

The maintenance alarm is sent until the enduser has acknowledged the message or the heating engineer has rectified the fault.

2.2 - Maintenance code

The maintenance alarm does not provide detailed information about the reason for the fault. Details can be displayed using parameter "WartungsCode" (QAA 73 setting : 726).

The maintenance code can also be viewed on the display of the boiler (b0).

2.3 - Coding of maintenance alarms

Maintenance alarm	Maintenance code	Internal error code b0	Meaning
-	0	-	No maintenance alarm
105	1	560	Burner hours run
105	2	561	Startups
105	3	562	Months-service

2.4 - General activation of maintenance alarms

Parameter "WartungsEinstellungen" (QAA 73 setting : 630) permits or suppresses the generation of maintenance alarms.

The subdivision of parameter "WartungsEinstellungen" by bit is shown in the following table :

Bit0	1 = general activation of maintenance alarms
Bit1	1 = single reset of hours run maintenance alarm
Bit2	1 = single reset of startup maintenance alarm
Bit3	1 = single reset of months- service maintenance alarm
Bit6	1 = total reset for all maintenance alarms

2.5 - Activation of the individual maintenance alarm

Every cause can be individually activated or deactivated by entering the associated limits.

- **Burner hours run :**

Burner hours run maintenance is activated by setting parameter "BetrStdWartGrenz" (QAA 73 setting : 625) to a value other than "0".

This value represents the target number of hours run. When this limit is reached, a maintenance alarm will be delivered (interval since last service visit).

- **Number of startups:**

Startup maintenance is activated by setting parameter "InbetrSetzWartGrenze" (QAA 73 setting : 626) to a value other than "0".

This value represents the target number of startups. When this limit is reached, a maintenance alarm will be delivered (interval since last service visit).

- **Months (service):**

Service maintenance is activated by setting parameter "MonatWartGrenze" (QAA 73 setting : 627) to a value other than "0".

This value represents the target number of months. When this limit is reached, a maintenance alarm will be delivered (interval since last service unit).

Note :

- The month counter is only active when the device is connected to power.

2.6 - Acknowledgement of maintenance alarms

The acknowledgement sets the internal error code "b0" and the fault statut message to "0", but the maintenance code still gives the precise reason for the maintenance alarm.

2.6.1 - Acknowledgement via QAA 73

For the parameter "WartungsQuittierung" (QAA 73 setting : 629) (default value: 0), to acknowledge the maintenance alarm the heating engineer (or the enduser) enters the value of "1".

If no repetition is required, all maintenance alarms after this acknowledgement will be locked, even if other reasons for maintenance occur. In that case, parameter "WartungsQuittierung" remains constantly at 1.

2.6.2 - Activation of the repetition after acknowledgement

If required, a timer (duration of repetition) can be started, that is, the maintenance alarm will reappear on the display after a certain period of time. An acknowledgement can also be made then. This period of time starts after each acknowledgement.

The repetition can be set via parameter «WartungsRepetitionsDauer» (QAA 73 setting 633).

Contents of parameter «WartungsRepetitionsDauer» is the desired period of time (in days) until the maintenance alarm appears again.

If a value other than «0» is entered there, a repetition is made within the entered duration of the repetition time.



During this period of time, no more maintenance alarms will appear, even if other reasons for maintenance occur.

2.7 - Resetting the maintenance alarms

Resetting can take place at any time, and after acknowledgement or during the repetition sequence.

A reset can be made in 1 of 2 ways:

- **Total reset :**

Here, all maintenance alarms can be reset at the same time. If, in parameter «WartungsEinstellungen» (QAA 73 setting 630), «1» is entered, all maintenance counters will be set to «0» when the parameter is saved.

The maintenance counters of the hours run, startups and months maintenance alarms will be newly started.

- **Individual reset of a certain maintenance alarm :**

Individual maintenance alarms can also be reset. In that case, parameter «WartungsEinstellungen» (QAA 73 setting : 630) will again be addressed bit by bit.

There is a bit available for each maintenance alarm via which this maintenance alarm can be reset (section 2.4 - page 20 - chapter IV - OPERATING FAULTS - SERVICING). It is thus possible to also reset other reasons for maintenance although they have not yet occurred.

When resetting the maintenance alarm, the maintenance code and the internal error code (b0) will automatically also be reset.


Note : Only the QAA 73 can the maintenance alarms be activated, the reasons for the maintenance alarms be checked and a reset via parameter be made.

1 - REAR WALL SPACER

The rear wall spacer (1) allows pipes to be fitted behind the boiler type **THI...C**, in the case of installation in a vertical direction.

Fitting:

- Fit the support plate (2) (section 3 - page 26 - chapter IV - INSTALLATION - INSTALLATION MANUAL),
- Place the rear wall spacer (1) onto the support plate,
- Fit the boiler to the rear wall spacer.




2 - MOUNTING BRACKET FOR LIGHT STUD WALLS

The bracket allows for the fitting of a boiler **THI..M75** on to a light stud wall

- Fix the bracket to the wall,
- Fit the boiler to the mounting bracket.


2.1 - **THI...M75 V**



3 - SET-UP TAKING ROOM TEMPERATURE INTO ACCOUNT (REG 73)

The REG 73 is a multifunctional digital room sensor for one or two heating circuits and for the control of domestic hot water.

Refer to the kit installation instructions.




4 - LPB COMMUNICATION CLIP-IN KIT (REG 130)

The LPB communication clip-in kit is used to connect the LMU control unit to different units or accessories of the type:

- RVA 46: zone regulator
- RVA 47: cascade regulator
- + others (distance management etc.)


Refer to kit installation instructions.



5 - 2ND HEATING CIRCUIT CLIP-IN KIT

The 2nd heating circuit clip-in kit is used when a second heating circuit is connected to the boiler. It allows the communication between the boiler's LMU control unit and the various accessories of the secondary circuit.

Refer to kit installation instructions.




6 - DOUBLE CIRCUIT KIT (REG 125)

The double circuit kit is used whenever a second heating circuit is connected to the boiler:

- The 2nd circuit clip-in ensures communication between the boiler's LMU management unit; the 2nd circuit pump control and also the mixing valve motor (accessories supplied with the kit).

Refer to kit installation instructions.




7 - PROGRAMMABLE RELAY CLIP-IN KIT (REG 127)

The programmable relay clip-in kit (sensor inlet)

enables:

- a 2nd heating pump to be controlled in parallel with the boiler pump in the case of operation using a header.
- with the flow sensor positioned at the outlet of the header, the heating outlet can be controlled after the header.
- an external safety gas solenoid to be connected,
- an alarm to be connected.

Refer to kit installation instructions.




8 - PROGRAMMABLE RELAY CLIP-IN KIT (WITHOUT SENSOR) (REG 134)

The programmable relay clip-in kit (without sensor) enables, for example:


- a domestic hot water circulation pump to be controlled,
- an outside gas safety solenoid valve to be connected.

Refer to the assembly instructions for the kit.



9 - ZHTi 46 CONTROL UNIT (REG 129)

The control unit ZHTi 46 enables an additional heating circuit to be controlled. (Required from 3 heating circuits - refer to technical specifications of the ZHTi 46).




10- ZHTi 47 CONTROL UNIT (REG 128)

The control unit ZHTi 47 manages 2 cascading boilers.

Note:


- For multiple boiler management, use clip-in kits LBP (130).

Refer to ZHTi 47 technical specifications.



11- SOLAR HEATING CONTROL KIT (REG 152)


The solar heating control kit is intended for type C THI boilers that have a solar tank. It is used to control the production of domestic hot water by solar panels.



12- DHW SENSOR KIT

The DHW sensor kit allows the connection of the domestic hot water sensor to the hot water heater at the boiler control unit.


Refer to kit installation instructions.



13- SELECTOR VALVE KIT FOR CONNECTING THI..C/BS

The selector valve kit allows the connection of a central heating only type boiler to a domestic hot water heater.

Refer to kit installation instructions.




14- TIMER KIT

The timer kit is fitted to the boiler's control panel and controls an installation only possessing one heating circuit.




Fitting a clip-in to the boiler's LMU management unit will not work with this timer.

Refer to kit installation instructions.



VI - PARTS LISTS

THI 0.9-9 C




PLTIC43151

Rep.	Reference	Description
1	H20.32834	FRONTPANEL GREY
2	Y00.20593	WHITE STAND FOR EXPANSION VESSEL THR
2	Y09.34942	STAND FOR EXPANSION VESSEL; WHITE
3	Y90.35966	WHITE COVER THRI C
4	A00.03141	COLORLESS PLASTIC CAP
5	T25.31875	FIXING PART; UPPER COVER
6	I20.21452	MESSING LOCK NUT 1
7	U07.31501	GAS SUPPLY ; GREY ; THISION
8	V90.33616	WIRED SIT GAS VALVE SET
8	V90.37322	GAS VALVE SIEMENS VGU 87
9	L10.10607	HONEYWELL O'RING 22 X 2,5
10	L10.33774	FLANGE G 3/4" FOR SIT VALVE
11	U07.31527	GAS PIPE BURNER THISION
12	E00.03424	NITRILE O'RING D. 8 X 2 80 SHORE
13	V00.21491	PROTECTING RING 1
14	W07.31558	ELECTR. CONTROL PANEL + WIRING 0,9-9 THISION
15	U07.31498	90° ELBOW ; D.80 DRILLED
16	L20.31496	SENSOR TASSERON NTC SENSOR D10X20 10K
17	T40.01051	INSIDE CIRCLIPS D.30 YELLOW BICHROMATE
18	B59.00692	STAINLESS STEEL WASHER 30,4X25,5X0,3
19	T20.00582	SIGHTGLASS PYREX D.30X5
20	V07.31526	STAINLESS STEEL BOILER SHELL THISION
21	F00.26572	GLASS BRAID RING D. 12 LG. 685
22	X00.25969	BURNER THR1-10
23	U00.03505	FIXING BRACKET FOR BURNER MZ/THR
24	L00.16673	IGNITION ELECTRODE SHORT 74,5 AV CABLE
25	L00.25959	IONISATION ELECTRODE BURNER 1-10
26	C90.31466	IGNITION TRANSFORMER ANSTOSS ZAG 2XV 01/10
27	Y00.18234	LEFT HAND CONSOLE (269,4X25X1,5)
28	Y90.33464	CHASSIS ; EQUIPPED C/SEP
29	X00.12864	REMOVABLE PROTECTION FOR BURNER (580 X 30 X 1,5)
30	Y00.14139	FASTENING HOOK
31	B00.18392	PIPE RING 41,1/44
32	O90.16681	PIPE BURNER / FAN (THR)
33	Y00.13849	BACK STOP PLATE FOR MZ (3355X80,4X1,5)
34	Y00.17570	FLANGE FOR WHITE STAND FOR THR FAN
35	Y00.18233	RIGHT HAND CONSOLE (269,4X25X1,5)
36	V07.31962	WALL FASTENING ; C MODEL
37	Y00.17569	WHITE STAND FOR THR FAN
38	C50.31464	FAN MVL-EBM RG 128/1300-3612
39	I20.25635	AIR REDUCER D12
40	A00.24109	ORANGE CAP D. 34,7 EZ-16
41	E20.23654	EXTENSIBLE SEALING D. 18 / RED SILICONE
42	E00.01005	O' RING DIA DIA 29,32 X 3,6
43	I20.13579	BRASS NIPPLE MAL3/4-MAL3/4(LONG)
44	U00.19252	SUMP INLET THRC/S GREY
45	L90.24635	AUTOMATIC AIR VALVE WATTS WITH ISOLATED VALVE
46	E20.03889	SEALING AFM34D 30X21X3
47	A20.23655	SIPHONIC TRAP WITH PIPE 650 MM
48	L30.31468	GRUNDFOS CIRCULATING PUMP UPER 15-50 CACAO
49	U00.19465	HEATING FLOW PIPE GREY THRC
50	H30.24159	MESSING CAP 28X52 + 2 O'RING
51	L50.35152	PRESSURE SENSOR HUBA TYPE 505.91540
51	V90.35156	REPLACEMENT SET OF IMIT SENSOR BY HUBA SENSOR
52	L20.31470	SENSOR TASSERON NTC SENSOR M5 TSA-TYPE

Rep.	Reference	Description
53	L90.24178	SAFETY VALVE
54	I20.21441	MESSING SEALED CONNECTION "OLIVE" 22/1
55	V00.23999	STOP PLATE FOR HEATING AND DHW
56	K50.24473	DRAIN COCK / RETURN UNIT
57	Y00.10807	FIXING SYSTEM FOR FLUE PIPE
58	U00.20366	ELBOW D. 80 45°
59	E00.24496	SEALING / O'RING INT. D. 39,45
60	L40.24495	STAINLESS STEEL FILTER / HEATING RETURN
61	U90.28983	HEATING RETURN UNIT
62	L20.31471	SENSOR T7335D1024B
63	N40.16810	REDUCED FLUE OUTLET PIPE F75/M80 L360
64	A00.19467	GREY PLASTIC CAP MALE 75
65	Y07.32842	COVER + FRONT PANEL
66	C91.03071	WIRE CARRIER
67	V07.32114	RING FOR BOILER COVER L685
68	E20.03890	SEALING AFM34 D 24X17X3
69	I20.31599	GAS REDUCER
70	W07.32303	OUTSIDE SENSOR .QAC34/101 THRI
71	O00.20679	STAINLESS STEEL FLEXIBLE PIPE MALE 1/4 WITH ELBOW
71	O00.36107	FLEXIBLE PIPE
72	L90.03520	EXPANSION CYLIND, VESSEL 8L MALE 3/4
72	L90.36106	EXPANSION VESSEL 8L D.197
73	A00.19059	PLASTIC STOPPER MAL 9 WHITE
74	E20.25892	RING 3/8 AFM34 D.14,5 (+0,3-0,1)X9 EP : 3
75	K20.10719	REDUCER MALE FEM F12/17 - M8/13
76	E20.03901	SEALING QUALITY AFM34 D.11X4X3
*	A00.28827	PLASTIC CAP MALE 1/4
*	C09.31469	CABLE WITH RECTIFIER VDU GAS VALVE
*	C09.33608	CABLE 0.960.401+CONNECT. GAS VALVE SIT 848 SIGMA
*	E00.10822	EPDM LIP SEAL D. 80 75 SHORE
*	E10.12503	EPDM STICKING SEAL PIPE 6/9 LENGTH 18
*	E20.24399	GASKET DN 80; BLACK FOR PART NUMBER U00.12053 AND U00.20366
*	I30.31973	STOP TECHNYL D.20X19
*	U00.08190	VERSILIC PIPE 6X10 LENGTH 800MM
*	U00.11405	VERSILIC SLEEVE 4X8 LENGTH 640
*	V00.24191	MOUNTING KEY; HONEYWELL
*	X00.05193	FIXING BRACKET FOR IONISATION PROBE

THI 2-17 C




PLTIC43191

Rep.	Reference	Description
1	H20.32834	FRONTPANEL GREY
2	Y00.20593	WHITE STAND FOR EXPANSION VESSEL THR
2	Y09.34942	STAND FOR EXPANSION VESSEL; WHITE
3	Y90.35966	WHITE COVER THRI C
4	A00.03141	COLORLESS PLASTIC CAP
5	T25.31875	FIXING PART; UPPER COVER
6	I20.21452	MESSING LOCK NUT 1
7	U07.31501	GAS SUPPLY ; GREY ; THISION
8	V90.33616	WIRED SIT GAS VALVE SET
8	V90.37322	GAS VALVE SIEMENS VGU 87
9	L10.10607	HONEYWELL O'RING 22 X 2,5
10	L10.33774	FLANGE G 3/4" FOR SIT VALVE
11	U07.31527	GAS PIPE BURNER THISION
12	E00.03424	NITRILE O'RING D. 8 X 2 80 SHORE
13	V00.21491	PROTECTING RING 1
14	W07.35261	CONTROL BOX ; PROGRAMMED WIRING THI 2-17
15	U07.31498	90° ELBOW ; D.80 DRILLED
16	L20.31496	SENSOR TASSERON NTC SENSOR D10X20 10K
17	T40.01051	INSIDE CIRCLIPS D.30 YELLOW BICHROMATE
18	B59.00692	STAINLESS STEEL WASHER 30,4X25,5X0,3
19	T20.00582	SIGHTGLASS PYREX D.30X5
20	V07.31526	STAINLESS STEEL BOILER SHELL THISION
21	F00.26572	GLASS BRAID RING D. 12 LG. 685
22	X00.21867	BURNER FOR THR 2-13
23	U00.03505	FIXING BRACKET FOR BURNER MZ/THR
24	L00.16673	IGNITION ELECTRODE SHORT 74,5 AV CABLE
25	L00.25959	IONISATION ELECTRODE BURNER 1-10
26	C90.31466	IGNITION TRANSFORMER ANSTOSS ZAG 2XV 01/10
27	Y00.18234	LEFT HAND CONSOLE (269,4X25X1,5)
28	Y90.33464	CHASSIS ; EQUIPPED C/SEP
29	X00.12864	REMOVABLE PROTECTION FOR BURNER (580 X 30 X 1,5)
30	Y00.14139	FASTENING HOOK
31	B00.18392	PIPE RING 41,1/44
32	O90.16681	PIPE BURNER / FAN (THR)
33	Y00.13849	BACK STOP PLATE FOR MZ (3355X80,4X1,5)
34	Y00.17570	FLANGE FOR WHITE STAND FOR THR FAN
35	Y00.18233	RIGHT HAND CONSOLE (269,4X25X1,5)
36	V07.31962	WALL FASTENING ; C MODEL
37	Y00.17569	WHITE STAND FOR THR FAN
38	C50.31464	FAN MVL-EBM RG 128/1300-3612
39	I20.34522	AIR ADJUSTMENT RING D. 18,2
40	A00.24109	ORANGE CAP D. 34,7 EZ-16
41	E20.23654	EXTENSIBLE SEALING D. 18 / RED SILICONE
42	E00.01005	O' RING DIA DIA 29,32 X 3,6
43	I20.13579	BRASS NIPPLE MAL3/4-MAL3/4(LONG)
44	U00.19252	SUMP INLET THRC/S GREY
45	L90.24635	AUTOMATIC AIR VALVE WATTS WITH ISOLATED VALVE
46	E20.03889	SEALING AFM34D 30X21X3
47	A20.23655	SIPHONIC TRAP WITH PIPE 650 MM
48	L30.31468	GRUNDFOS CIRCULATING PUMP UPER 15-50 CACAO
49	U00.19465	HEATING FLOW PIPE GREY THRC
50	V90.33015	SELECTOR VALVE KIT
51	L50.35152	PRESSURE SENSOR HUBA TYPE 505.91540
51	V90.35156	REPLACEMENT SET OF IMIT SENSOR BY HUBA SENSOR
52	L20.31470	SENSOR TASSERON NTC SENSOR M5 TSA-TYPE

Rep.	Reference	Description
53	L90.24178	SAFETY VALVE
54	I20.21441	MESSING SEALED CONNECTION "OLIVE" 22/1
55	V00.23999	STOP PLATE FOR HEATING AND DHW
56	K50.24473	DRAIN COCK / RETURN UNIT
57	Y00.10807	FIXING SYSTEM FOR FLUE PIPE
58	U00.20366	ELBOW D. 80 45°
59	E00.24496	SEALING / O'RING INT. D. 39,45
60	L40.24495	STAINLESS STEEL FILTER / HEATING RETURN
61	U90.28983	HEATING RETURN UNIT
62	L20.31471	SENSOR T7335D1024B
63	N40.16810	REDUCED FLUE OUTLET PIPE F75/M80 L360
64	A00.19467	GREY PLASTIC CAP MALE 75
65	Y07.32842	COVER + FRONT PANEL
66	C91.03071	WIRE CARRIER
67	V07.32114	RING FOR BOILER COVER L685
68	E20.03890	SEALING AFM34 D 24X17X3
69	I20.17832	UNION REDUCER D.12 D. 4,20
70	W07.32303	OUTSIDE SENSOR .QAC34/101 THRI
71	O00.20679	STAINLESS STEEL FLEXIBLE PIPE MALE 1/4 WITH ELBOW
71	O00.36107	FLEXIBLE PIPE
72	L90.03520	EXPANSION CYLIND, VESSEL 8L MALE 3/4
72	L90.36106	EXPANSION VESSEL 8L D.197
73	A00.19059	PLASTIC STOPPER MAL 9 WHITE
74	U00.23957	TANK RETURN; GREY; THR
75	E20.03890	SEALING AFM34 D 24X17X3
76	W07.31704	MOTOR; SELECTIVE VALVE WITH CABLE
77	L20.31472	SENSOR;TASSERON NTCSENSOR CABLE TSK-TYPE
78	C15.15690	LUMBERG 2 PTS SCREW PLUG 361102K15
79	E20.25892	RING 3/8 AFM34 D.14,5 (+0,3-0,1)X9 EP : 3
80	K20.10719	REDUCER MALE FEM F12/17 - M8/13
81	E20.03901	SEALING QUALITY AFM34 D.11X4X3
*	A00.28827	PLASTIC CAP MALE 1/4
*	C09.31469	CABLE WITH RECTIFIER VDU GAS VALVE
*	C09.33608	CABLE 0.960.401+CONNECT. GAS VALVE SIT 848 SIGMA
*	E00.10822	EPDM LIP SEAL D. 80 75 SHORE
*	E10.12503	EPDM STICKING SEAL PIPE 6/9 LENGTH 18
*	E20.24399	GASKET DN 80; BLACK FOR PART NUMBER U00.12053 AND U00.20366
*	I30.31973	STOP TECHNYL D.20X19
*	U00.08190	VERSILIC PIPE 6X10 LENGTH 800MM
*	U00.11405	VERSILIC SLEEVE 4X8 LENGTH 640
*	V00.24191	MOUNTING KEY; HONEYWELL
*	X00.05193	FIXING BRACKET FOR IONISATION PROBE

THI 5-25 C




PLTIC43101

Rep.	Reference	Description
1	H20.32834	FRONTPANEL GREY
2	Y00.20593	WHITE STAND FOR EXPANSION VESSEL THR
2	Y09.34942	STAND FOR EXPANSION VESSEL; WHITE
3	Y90.35966	WHITE COVER THRI C
4	A00.03141	COLORLESS PLASTIC CAP
5	T25.31875	FIXING PART; UPPER COVER
6	I20.21452	MESSING LOCK NUT 1
7	U07.31501	GAS SUPPLY ; GREY ; THISION
8	V90.33616	WIRED SIT GAS VALVE SET
8	V90.37322	GAS VALVE SIEMENS VGU 87
9	L10.10607	HONEYWELL O'RING 22 X 2,5
10	L10.33774	FLANGE G 3/4" FOR SIT VALVE
11	U07.31527	GAS PIPE BURNER THISION
12	E00.03424	NITRILE O'RING D. 8 X 2 80 SHORE
13	V00.21491	PROTECTING RING 1
14	W07.31542	ELECTRICAL TERMINAL BOX
15	U07.31498	90° ELBOW ; D.80 DRILLED
16	L20.31496	SENSOR TASSERON NTC SENSOR D10X20 10K
17	T40.01051	INSIDE CIRCLIPS D.30 YELLOW BICHROMATE
18	B59.00692	STAINLESS STEEL WASHER 30,4X25,5X0,3
19	T20.00582	SIGHTGLASS PYREX D.30X5
20	V07.31526	STAINLESS STEEL BOILER SHELL THISION
21	F00.26572	GLASS BRAID RING D. 12 LG. 685
22	X90.23481	BURNER SET FOR THR 5-25 LPG
22	X90.26473	BURNER KIT THR 5-25 GN
23	U00.03505	FIXING BRACKET FOR BURNER MZ/THR
24	L00.16673	IGNITION ELECTRODE SHORT 74,5 AV CABLE
25	L00.12950	IONISATION PROBE (SHORT 20)
26	C90.31466	IGNITION TRANSFORMER ANSTOSS ZAG 2XV 01/10
27	Y00.18234	LEFT HAND CONSOLE (269,4X25X1,5)
28	Y90.33464	CHASSIS ; EQUIPPED C/SEP
29	X00.12864	REMOVABLE PROTECTION FOR BURNER (580 X 30 X 1,5)
30	Y00.14139	FASTENING HOOK
31	B00.18392	PIPE RING 41,1/44
32	O90.16681	PIPE BURNER / FAN (THR)
33	Y00.13849	BACK STOP PLATE FOR MZ (3355X80,4X1,5)
34	Y00.17570	FLANGE FOR WHITE STAND FOR THR FAN
35	Y00.18233	RIGHT HAND CONSOLE (269,4X25X1,5)
36	V07.31962	WALL FASTENING ; C MODEL
37	Y00.17569	WHITE STAND FOR THR FAN
38	C50.31464	FAN MVL-EBM RG 128/1300-3612
39	I20.12530	AIR REDUCER D. 29
39	I20.23374	AIR REDUCER D. 27 THR 5-25 NG/LPG
40	A00.24109	ORANGE CAP D. 34,7 EZ-16
41	E20.23654	EXTENSIBLE SEALING D. 18 / RED SILICONE
42	E00.01005	O' RING DIA DIA 29,32 X 3,6
43	I20.13579	BRASS NIPPLE MAL3/4-MAL3/4(LONG)
44	U00.19252	SUMP INLET THRC/S GREY
45	L90.24635	AUTOMATIC AIR VALVE WATTS WITH ISOLATED VALVE
46	E20.03889	SEALING AFM34D 30X21X3
47	A20.23655	SIPHONIC TRAP WITH PIPE 650 MM
48	L30.31468	GRUNDFOS CIRCULATING PUMP UPER 15-50 CACAO
49	U00.19465	HEATING FLOW PIPE GREY THRC
50	V90.33015	SELECTOR VALVE KIT
51	L50.35152	PRESSURE SENSOR HUBA TYPE 505.91540

Rep.	Reference	Description
51	V90.35156	REPLACEMENT SET OF IMIT SENSOR BY HUBA SENSOR
52	L20.31470	SENSOR TASSERON NTC SENSOR M5 TSA-TYPE
53	L90.24178	SAFETY VALVE
54	I20.21441	MESSING SEALED CONNECTION "OLIVE" 22/1
55	V00.23999	STOP PLATE FOR HEATING AND DHW
56	K50.24473	DRAIN COCK / RETURN UNIT
57	Y00.10807	FIXING SYSTEM FOR FLUE PIPE
58	U00.20366	ELBOW D. 80 45°
59	E00.24496	SEALING / O'RING INT. D. 39,45
60	L40.24495	STAINLESS STEEL FILTER / HEATING RETURN
61	U90.28983	HEATING RETURN UNIT
62	L20.31471	SENSOR T7335D1024B
63	N40.16810	REDUCED FLUE OUTLET PIPE F75/M80 L360
64	A00.19467	GREY PLASTIC CAP MALE 75
65	Y07.32842	COVER + FRONT PANEL
66	C91.03071	WIRE CARRIER
67	V07.32114	RING FOR BOILER COVER L685
68	E20.03890	SEALING AFM34 D 24X17X3
69	I20.12056	REDUCER D.12 D.4,60
69	I20.31601	GAS REDUCER GAZ D.
70	W07.32303	OUTSIDE SENSOR .QAC34/101 THRI
71	O00.20679	STAINLESS STEEL FLEXIBLE PIPE MALE 1/4 WITH ELBOW
71	O00.36107	FLEXIBLE PIPE
72	L90.03520	EXPANSION CYLIND, VESSEL 8L MALE 3/4
72	L90.36106	EXPANSION VESSEL 8L D.197
73	A00.19059	PLASTIC STOPPER MAL 9 WHITE
74	U00.23957	TANK RETURN; GREY; THR
75	E20.03890	SEALING AFM34 D 24X17X3
76	W07.31704	MOTOR; SELECTIVE VALVE WITH CABLE
77	L20.31472	SENSOR;TASSERON NTCSENSOR CABLE TSK-TYPE
78	C15.15690	LUMBERG 2 PTS SCREW PLUG 361102K15
79	E20.25892	RING 3/8 AFM34 D.14,5 (+0,3-0,1)X9 EP : 3
80	K20.10719	REDUCER MALE FEM F12/17 - M8/13
81	E20.03901	SEALING QUALITY AFM34 D.11X4X3
*	A00.28827	PLASTIC CAP MALE 1/4
*	C09.31469	CABLE WITH RECTIFIER VDU GAS VALVE
*	C09.33608	CABLE 0.960.401+CONNECT. GAS VALVE SIT 848 SIGMA
*	E00.10822	EPDM LIP SEAL D. 80 75 SHORE
*	E10.12503	EPDM STICKING SEAL PIPE 6/9 LENGTH 18
*	E20.24399	GASKET DN 80; BLACK FOR PART NUMBER U00.12053 AND U00.20366
*	I30.31973	STOP TECHNYL D.20X19
*	U00.08190	VERSILIC PIPE 6X10 LENGTH 800MM
*	U00.11405	VERSILIC SLEEVE 4X8 LENGTH 640
*	V00.24191	MOUNTING KEY; HONEYWELL
*	V07.31649	GAS CONVERSION SET GN/GP THI 5-25
*	X00.05193	FIXING BRACKET FOR IONISATION PROBE
*	X90.30472	IGNITION ANGLE WITH SCREW

THI 5-25 M75 V




TIM43101-1

Rep.	Reference	Designation
1	U07.31527	GAS PIPE BURNER THISION
2	L10.33774	FLANGE G 3/4" FOR SIT VALVE
3	L10.10607	HONEYWELL O'RING 22 X 2,5
4	A00.03141	COLORLESS PLASTIC CAP
5	V90.33616	WIRED SIT GAS VALVE SET
5	V90.37322	GAS VALVE SIEMENS VGU 87
6	Y90.35964	WHITE COVER THRIM75V DT
7	V07.32114	RING FOR BOILER COVER L685
8	W07.32303	OUTSIDE SENSOR .QAC34/101 THRI
9	H20.32834	FRONTPANEL GREY
10	Y07.32845	COMPLETE COVER GREY THI M75V
11	N40.16810	REDUCED FLUE OUTLET PIPE F75/M80 L360
12	W07.32382	CONTROL BOX; WIRED; PROGRAMMED THI 5-25 M75 DT
13	K50.18085	ANODE + CAP +SEALING 3/4-D.22X230 MAGNESIUM
14	I10.29477	FLANGE FOR CLEANING DOOR
15	E20.10187	SEALING / CLEANING DOOR
16	V07.32168	75 L DHW TANK; EQUIPPED;12 M; CONTACT SENSOR
17	U00.24123	TANK OUTLET PIPE FOR THR M75 V
18	E20.03890	SEALING AFM34 D 24X17X3
19	V00.21467	STOP PLATE FOR GAS + DHW THR M75 V
20	V00.21491	PROTECTING RING 1
21	I20.21452	MESSING LOCK NUT 1
22	V00.21492	PROTECTING RING 3/4
23	K20.03068	MESSING LOCK NUT 3/4
24	E20.25892	RING 3/8 AFM34 D.14,5 (+0,3-0,1)X9 EP : 3
25	U90.28983	HEATING RETURN UNIT
26	E20.03901	SEALING QUALITY AFM34 D.11X4X3
27	V09.38039	STOP PLATE ; TANK
28	V00.21466	STOP PLATE/ HEATING FLOW PIPE THR
29	I20.21441	MESSING SEALED CONNECTION "OLIVE" 22/1
30	V90.33015	SELECTOR VALVE KIT
31	W07.31704	MOTOR; SELECTIVE VALVE WITH CABLE
32	U00.15646	BRAZED DHW-PIPE FOR THR M75 V
33	L50.35152	PRESSURE SENSOR HUBA TYPE 505.91540
33	V90.35156	REPLACEMENT SET OF IMIT SENSOR BY HUBA SENSOR
34	L90.24178	SAFETY VALVE
35	U00.24535	LOW BRAZED BOILER FLOW PIPE FOR THR M75V
36	U07.38423	RETURN PIPE UPSTREAM THRIL75V
37	L90.24597	10 LITER EXPANSION VESSEL
38	O00.34006	FLEXIBLE FOR EXPANSION VESSEL MU 1/4"-CB 1/2"
39	A20.14915	FLEXIBLE PIPE/SIPHON OUTLET D. 32 LENGTH 1300
40	L30.31468	GRUNDFOS CIRCULATING PUMP UPER 15-50 CACAO
41	A20.11061	SIPHONIC TRAP PP D. 32 DEPTH 60 MM
42	V09.37159	HOLDER FOR EXPANSION VESSEL; WHITE
43	U00.20427	SUMP INLET PIPE GREY THRM75V
44	L90.24635	AUTOMATIC AIR VALVE WATTS WITH ISOLATED VALVE
45	E00.01005	O' RING DIA DIA 29,32 X 3,6
46	U00.19944	BOILE FLOW PIPE GREY THRM75
47	Y90.33468	CHASSIS ; EQUIPPED THI M75V
48	Y00.13849	BACK STOP PLATE FOR MZ (3355X80,4X1,5)
49	C50.31464	FAN MVL-EBM RG 128/1300-3612
50	Y00.17570	FLANGE FOR WHITE STAND FOR THR FAN
51	Y00.18233	RIGHT HAND CONSOLE (269,4X25X1,5)
52	Y00.17569	WHITE STAND FOR THR FAN
53	O90.16681	PIPE BURNER / FAN (THR)

Rep.	Reference	Designation
54	B00.18392	PIPE RING 41,1/44
55	Y00.14139	FASTENING HOOK
56	A00.19467	GREY PLASTIC CAP MALE 75
57	V07.31962	WALL FASTENING ; C MODEL
58	Y00.10807	FIXING SYSTEM FOR FLUE PIPE
59	U00.20366	ELBOW D. 80 45°
60	C90.31466	IGNITION TRANSFORMER ANSTOSS ZAG 2XV 01/10
61	Y00.18234	LEFT HAND CONSOLE (269,4X25X1,5)
62	I20.12530	AIR REDUCER D. 29
62	I20.23374	AIR REDUCER D. 27 THR 5-25 NG/LPG
63	L00.12950	IONISATION PROBE (SHORT 20)
64	L00.16673	IGNITION ELECTRODE SHORT 74,5 AV CABLE
65	X90.23481	BURNER SET FOR THR 5-25 LPG
65	X90.26473	BURNER KIT THR 5-25 GN
66	U07.31655	GAS INLET; EQUIPPED; THISION M75V
67	X00.12864	REMOVABLE PROTECTION FOR BURNER (580 X 30 X 1,5)
68	F00.26572	GLASS BRAID RING D. 12 LG. 685
69	L20.31470	SENSOR TASSERON NTC SENSOR M5 TSA-TYPE
70	V07.31526	STAINLESS STEEL BOILER SHELL THISION
71	L20.31471	SENSOR T7335D1024B
72	L20.31496	SENSOR TASSERON NTC SENSOR D10X20 10K
73	U07.31498	90° ELBOW ; D.80 DRILLED
74	B59.00692	STAINLESS STEEL WASHER 30,4X25,5X0,3
75	T40.01051	INSIDE CIRCLIPS D.30 YELLOW BICHROMATE
76	T20.00582	SIGHTGLASS PYREX D.30X5
77	E20.03889	SEALING AFM34D 30X21X3
78	E20.23654	EXTENSIBLE SEALING D. 18 / RED SILICONE
79	V90.19984	ANODE CLEANING DOOR
79	V90.26382	CLEANING DOORD (WITHOUT ANODE)
80	T25.31875	FIXING PART; UPPER COVER
81	I20.13579	BRASS NIPPLE MAL3/4-MAL3/4(LONG)
82	L20.32178	SURFACE TEMP. SENSOR T7335D1073B
83	E00.03424	NITRILE O'RING D. 8 X 2 80 SHORE
84	I20.12056	REDUCER D.12 D.4,60
84	I20.31601	GAS REDUCER GAZ D.
85	A00.19059	PLASTIC STOPPER MAL 9 WHITE
*	A00.28827	PLASTIC CAP MALE 1/4
*	A90.20473	HANDLE FOR CLEANING DOOR, POLYETHYLENE
*	C09.31469	CABLE WITH RECTIFIER VDU GAS VALVE
*	C09.33608	CABLE 0.960.401+CONNECT. GAS VALVE SIT 848 SIGMA
*	E00.10822	EPDM LIP SEAL D. 80 75 SHORE
*	E10.12503	EPDM STICKING SEAL PIPE 6/9 LENGTH 18
*	E20.24399	GASKET DN 80; BLACK FOR PART NUMBER U00.12053 AND U00.20366
*	I30.24257	DHW PIPE THRM70
*	U00.03505	FIXING BRACKET FOR BURNER MZ/THR
*	U00.11405	VERSILIC SLEEVE 4X8 LENGTH 640
*	U00.15255	VERSILIC 6X10 LENGTH 1300 MM/DEGASIFIER OULET
*	V00.24191	MOUNTING KEY; HONEYWELL
*	V07.31649	GAS CONVERSION SET GN/GP THI 5-25
*	V07.34145	INSULATION TANK 75L BOX
*	W00.25015	EARTH WIRE L600
*	X00.05193	FIXING BRACKET FOR IONISATION PROBE
*	X90.30472	IGNITION ANGLE WITH SCREW

CONTROL BOX



PLW0731542

Rep.	Reference	Description
1	H20.31449	CONTROL BUTTON
2	Y07.31525	CONTROL PANEL + STICKER
3	W07.31892	INTERFACE; EQUIPPED; AGU2.303A136
4	L20.31476	COMMUNICATION MODULE CLIP-IN LPB (VOIR OPTION W07.30832)
4	L20.31477	MODULE CIRCUIT 2 CLIP-IN (VOIR OPTION W07.30833)
4	L20.31499	SUB-MODULE RELAIS CLIP-IN AGU2.511A109 (VOIR OPTION W07.30515)
5	L20.36214	ELECTRONIC CONTROL UNIT LMU64.010D136 V3.03
6	A90.27098	CABLE GRIP D=6,5 MM BLACK
6	C91.38454	CABLE FASTENING TWIST LOCK
7	Y07.31507	ELECTR. BOX
8	C19.32006	SCREW EARTH CONNECTION
9	C20.12490	TIGHT CAP FOR SWITCH
10	C20.12487	BIPOLAR SWITCH; BLACK/LIGHTNING/GREEN
11	L25.17432	TIMER GRASSLIN 230 V FM - DIGI20
*	C09.31469	CABLE WITH RECTIFIER VDU GAS VALVE
*	C09.33608	CABLE 0.960.401+CONNECT. GAS VALVE SIT 848 SIGMA
*	C09.37989	IONISATION CABLE Ø 2,5 LG 1020 MM
*	C09.37989	IONISATION CABLE Ø 2,5 LG 1020 MM
*	C90.31497	COVER KEY-TOP 4X4 THISION
*	W07.31478	WIRING OF THE CONTROL BOX
*	W07.31479	WIRING OF THE CONTROL BOX; 10-50 MODEL
*	W07.31492	CONNECTING CABLE LG LMU64/AGU2
*	W07.31508	ELECTR. CONTROL BOX + WIRING 2-13 THISION
*	W07.31542	ELECTRICAL TERMINAL BOX
*	W07.31558	ELECTR. CONTROL PANEL + WIRING 0,9-9 THISION
*	W07.31562	CONTROL BOX PROGRAMMED THRI/THI 10-50C (DT)
*	W07.32380	CONTROL BOX ; WIRED ; PROGRAMMED THI 5-25 S DT
*	W07.32381	CONTROL BOX ; WIRED ; PROGRAMMED THI 2-13 M 75 DT
*	W07.32382	CONTROL BOX; WIRED; PROGRAMMED THI 5-25 M75 DT
*	W07.32899	CONTROL BOX ; WIRED ; PROGRAMMED THRI5-25SEP(DT)
*	W07.32995	WIRING - TIMER THRI
*	W07.34114	WIRED PROGRAMMED BOX THI 5-25/28 SEP GB/DK
*	W07.34211	CONTROL BOX, PROGRAMMED, WIRED
*	W07.34228	WIRED, PROGRAMM. CONTROL BOX THI 5-25 M75H DC
*	W07.34974	PROGRAMMED ; CONTROL BOX WIRING
*	W07.35261	CONTROL BOX ; PROGRAMMED WIRING THI 2-17
*	W07.35314	PROGRAMMED CONTROL BOX ; WIRING 2-17 B120
*	W07.35319	PROGRAMMED CONTROL BOX ; WIRING 2-17 B120 DC
*	W07.36535	WIRED & PROGRAMMED CONTROL BOX THI 5-25 B120 GB
*	W07.36536	WIRED & PROGRAMMED CONTROL BOX THI 5-25 B120 DC
*	W07.36930	CONTROL BOX ; WIRED ; PROGRAMMED
*	W07.37986	SUPPLY CABLE 230V THRI
*	W07.37991	CABLE TRANSFORMER+MASS THRI BURNER
*	W07.37992	SWITCH CABLE THRI
*	W07.37995	FAN CABLE THRI
*	W07.37996	FAN CABLE THRI
*	W07.37998	MASS CABLE THRI COVER
*	W07.38000	SENSORS CONNECTION THRI
*	W07.38001	CABLE PWM FOR THRI FAN
*	W07.38002	FAN PWM CABLE THRI 10-50C
*	W07.38004	SENSORS CONNECTION THRI 10-50 C
*	W07.38379	FAN CABLE THRI/THISION/THI 10-50
*	W09.37943	WIRING DHW SENSOR ZEM B120/SEP/M50