STREBEL S-CB⁺ Boiler Range

Models *60 - *80 - *100 - *120 - *150 - *180

Wall hung high efficiency condensing boiler

Installation, Operating & Maintenance Manual





2015-07-21 v1

TABLE OF CONTENTS

	INTRO	DUCTIC	DN	7
1	SAFET	Y GUID	ELINES	7
2	TECHN		ATA S-CB ⁺ BOILERS	9
	2.1		IONAL INTRODUCTION	
	2.2	TECHN	IICAL SPECIFICATIONS DATASHEET	10
3	DIMEN	SIONS.		12
•	3.1		60-120	
	3.2		150-180	
4		SODIE	S AND UNPACKING	11
4	4.1		SORIES	
	4.2		CKING	
5	INSTAL	LATIO	N OF THE S-CB ⁺	15
	5.1	Gener	RAL NOTES	15
	5.2	Moun	TING THE BOILER	16
6	CONNE	CTION	S WATER SIDE	17
v	6.1		R CONNECTIONS	
	6.2	-	ENSATE DRAIN CONNECTION	
	6.3		AND RETURN CONNECTIONS	
	6.4		KPANSION VESSEL	
	6.5		SURE RELIEF VALVE	
	6.6		S	
	6.7	-	FUNCTIONALITY	-
	6.8			
	6.9 6.10		LING A STRAINER AND/OR DIRT SEPARATOR R QUALITY	
	6.10		IC PIPING IN THE HEATING SYSTEM	
	6.12		ATIC AIR VENT	
	6.13		ATIC WATER FILLING SYSTEMS	
	6.14		R PRESSURE	
	6.15	Снемі	CAL WATER TREATMENT	21
	6.16	UNDEF	R FLOOR HEATING	21
	6.17		THE SYSTEM WITH FRESH WATER	
	6.18		LATION EXAMPLES	
			Example of a standard single boiler heating circuit with low loss header	
	6.	18.2	Example of a multiple boiler heating circuit with low loss header	23
7	PUMP (-	CTERISTICS	
	7.1		AULIC GRAPHS	
	7.2	PUMPS	S: MAXIMUM ELECTRICAL POWER	27
8	FLUE G	GAS AN	ID AIR SUPPLY SYSTEM	27
	8.1	-	RAL	
	8.2		IPPLY	
			Combustion air quality	
	-		Air supply through humid areas	
	8.3 8.4		ERMINAL	
	8.5		EIGHTS AND MUTUAL DISTANCES ON A FLAT ROOF	
	8.6		CERTIFIED	-
	8.7		ERTIFIED	
	8.8		GAS AND AIR SUPPLY RESISTANCE TABLE	
	8.9		YPICAL EXAMPLES	
			Example A: Twin pipe system	
			Example B: Twin pipe system with concentric roof terminal	
			Example C: Single flue gas outlet. Air supply from boiler room	
			Example D: Concentric flue gas/air supply pipe (roof-mounted)	
			Example E: Concentric flue gas/air supply pipe (wall-mounted)	
9			INSTALLATION	
	9.1	Genef	RAL	37

	9.2	ELECTRICAL CONNECTIONS	
	9.3	EXPLANATION OF THE CONNECTIONS	37
	9.4	ELECTRICAL SCHEMATICS	
	9.5	SENSOR VALUES	
10	USER IN	ITERFACE	43
	10.1	CONTROL PANEL / DISPLAY UNIT	43
	10.2	CONTROL PANEL MENU STRUCTURE	44
	10.3	DISPLAY DURING OPERATION	46
	10.4	MONITOR SCREENS	
	10.5	Service function	
	10.5	SCHORNSTEINFEGER FUNCTION	
	10.7	PROGRAMMING IN STANDBY MODE	
	10.8	SETTING THE TIME & DATE	
	10.9	SET POINTS	
	10.10	SETTING THE TIMER PROGRAMS	
	10.11	SETTING THE OUTDOOR SPECIFICATIONS	56
	10.12	CHECKING THE OPERATING HISTORY	60
	10.13	CHECKING THE FAULT HISTORY	61
	10.14	SETTING THE MAINTENANCE SPECIFICATIONS	62
	10.15	SETTING THE USER LOCK	66
	10.16	SETTING THE PARAMETERS AT THE CONTROL PANEL	
		FAULT CODES DISPLAY	
		.17.1 Lock-out codes	
		.17.2 Blocking codes	
		.17.3 Messages	
11	CONTR	OLLING OPTIONS AND SETTINGS	78
	11.1	GENERAL	78
	11	.1.1 Extra boiler control	78
	11	.1.2 Max cooling time	78
		.1.3 Temperature display on/off	
		.1.4 Water pressure	
		.1.5 Gas type selection	
		.1.6 Soft start option	
		.1.7 Pump mode (EC technology)	
		.2.1 Controlling behaviour settings	
		.2.2 Room thermostat on/off	
		.2.3 Room thermostat OPEN-THERM	
		.2.5 0-10 Vdc remote flow temperature set point	
		.2.6 0-10 Vdc Remote burner input control	
		.2.7 Timer contact function	-
	11.3	INDIRECT HOT WATER/CALORIFIER	
		.3.1 Pump and 3-way valve control	
		.3.2 Tank thermostat	
		.3.3 Tank sensor	
		.3.4 Low/high flow temperature to tank coil	
		.3.5 Heating and hot water switching time	
	11	.3.6 Heating and hot water switching at sudden temperature drop	85
	11	.3.7 Anti-Legionnaires' disease function (pasteurisation)	86
	11.4	CASCADE CONTROL	87
	11	.4.1 Parameter settings for cascaded boilers	87
	11	.4.2 Monitor screens	
		.4.3 Output control and boiler sequence	
12			
	12.1	FIRST: FLUSHING THE BOILER WITH WATER	
	12.2	SECOND: FILLING & VENTING THE BOILER AND THE SYSTEM	
	12.3	THIRD: CHECK THE WATER FLOW	90
12	STADT	NG THE BOILER	مە
13	13.1	GENERAL	
	13.1	GENERAL	
	13.2		92

ADJUSTING AND SETTING THE BURNER	93
14.1 INTRODUCTION	
14.1.1 Adjustment tables	
14.1.2 Setting screws gas valve(s): drawings	
14.1.3 Gas valve classes A+C and B+J (B+J only for Poland)	
14.1.4 Adjustment actions: general scheme	97
14.3 ADJUSTING IN CASE OF VALVE REPLACEMENT OR GAS CONVERSION (CASE B)	
14.3.1 General remarks	
14.3.3 Checking and adjusting at minimum load $A^+60 / A^+80 / A^+100$	
14.3.4 Checking and adjusting at maximum load A ⁺ 120 / A ⁺ 150 / A ⁺ 180	
14.4 ADJUSTING PROCEDURES	100
PUTTING THE BOILER OUT OF OPERATION	101
15.1 OUT OF OPERATION: ON/OFF FUNCTION	101
15.2 OUT OF OPERATION: POWER OFF	101
FAULT CODES, BLOCKING CODES	102
	-
MAINTENANCE	
17.1 GENERAL	113
17.2 INSPECTION & MAINTENANCE	113
USER INSTRUCTIONS	117
INSTALLATION EXAMPLES	
INDEX	
	 14.1 INTRODUCTION

INTRODUCTION

This manual is written for:

- The installer
- System design engineer
- . The service engineer

The following symbol is used in this manual:



Warning: important information concerning the safety of persons and/or the appliance.

Strebel Ltd is not accountable for any damage caused by incorrect following the mounting instructions. For service and repair purposes use only original Strebel spare parts.

All documentation produced by the manufacturer is subject to copyright law.

1 SAFETY GUIDELINES

Carefully read all the instructions before commencing installation.

Keep these instructions near the boiler for quick reference.

The appliance should be installed by a skilled installer such as GAS SAFE registered person, electrical work carried out by a qualified person, all according to national and regional standards.

Failure to comply with these regulations could deem the warranty invalid. This appliance must be installed in accordance with the rules that apply and only be used in an adequately ventilated space conforming to standards in place.

Without written approval of the manufacturer the internals of the boiler may not be changed. When changes are executed without approval, the boiler certification becomes invalid.

Commissioning, maintenance and repair must be done by a skilled installer/engineer, according to all applicable standards and regulations.

What should one do when there is the smell of gas: -

- Don't use any electrical equipment.
- Don't press any switches.
- Close the gas supply.
- Ventilate the room (open the windows and/or outdoor boiler room doors).
- Immediately warn the responsible person.



The manufacturer/supplier is not liable for any damage caused by inaccurately following these mounting instructions. Only original parts may be used when carrying out any repair or service work.



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

These instructions are written for the installer of Strebel products and contain all necessary information on the installation and adjustment of S-CB⁺ Ranges of boilers. Please read these instructions fully before installation to ensure that all work is carried out correctly.

We suggest that you keep a copy of these instructions near the boiler.

These instructions together with those in any supplemental instruction booklet cover the basic principles to ensure the satisfactory installation of the boiler, although detail may need slight modification to suit particular local site conditions.

It is the law that all gas appliances and fittings are installed by a competent person (such as a Gas Safe registered installer) and in accordance with The Gas Safety (installation and Use) Regulations.

The relevant British standards for installation, codes of practice or rules in force and in accordance with the Manufactures' instructions.

The installation must be carried out in accordance with the following regulations plus relevant codes & standards:

- Due consideration must be given to current Health & Safety Legislation while this product is being installed.
- Key Approved Documents to the Building Regulations, in the region of the United Kingdom that this product is being installed.
- The Local Building Regulations and Local water by-laws, the gas services area and the Local Authority recommendations.
- The appropriate British & European Standards for the type of installation and fuel used, including but not exclusively the following standards:
 - o BS 5440: Parts 2 (Flues and Ventilation).
 - o BS 6644: Installation of gas-fired hot water boilers of rated inputs between 70kW & 1.8MW
- The clean air act as defined by the local authority.
- The appropriate documents as produced by the Institution of Gas Engineers and Managers Documents (IGEM) for the type of installation and fuel used, including but not exclusively the following documents: -
 - IGE/UP1
 - IGE/UP2
 - o IGE/UP4
 - o IGE/UP10
- If the product is being fuelled with LPG then the appropriate UKLPG Codes of Practice (CoP) should be referred to.
- Wiring to the appliance must be in accordance with the IEE (BS 7671) Wiring Regulations the Health and Safety Document No 635 "The Electricity at Work Regulations 1989" and any local regulations that apply.
- CP 342: Part 2, 1994. Code of practice for centralised hot water supply buildings other than individual dwellings.
- CIBSE, Guides A, B and C.

Adhere to all regulations that are in force at the time of installation or service.

2 TECHNICAL DATA S-CB⁺ BOILERS

2.1 Functional introduction

The S-CB⁺ boilers are central heating boilers with a maximum high efficiency. Such a performance can be reached by, amongst other things, using a special heat exchanger made of stainless steel. This allows the flue gases to cool down below the condensation point, and so release extra heat. This has an immediate positive impact on the efficiency, exceeding the 100%.

The S-CB⁺ boiler is standard set for Natural gas G20

Gases used must meet the European standard EN 437.

Fuel used should have sulphur rates according to the European standard, a maximum annual peak over a short period of time of 150 mg/m³ and an annual average of 30 mg/m³.

Boiler control includes:

- Cascade control for up to twelve boilers
- Remote operation and heat demand indication from each boiler
- Weather compensation control
- Hot water cylinder control

Connections for:

- 0-10 VDC remote flow temperature (set point) control
- 0-10 VDC remote burner input control
- Outdoor temperature sensor
- External hot water cylinder pump or diverter valve

Cascade control

When using the integrated cascade control, a maximum of twelve boilers can be controlled in a cascade configuration. By the use of an appropriate external control, this number may be increased at will.

0-10 VDC connection available

The boiler flow temperature or power input can be controlled by an external 0-10 VDC signal. When a number of boilers are cascaded, and controlled by the integrated cascade control, the signal should be directed to the master boiler only. If an alternative control is used, more than one boiler may be controlled by a 0-10 VDC signal. A signal of 1,48 Volt will switch on the boiler(s), less than 1,4 Volt will switch off the boiler(s).

Time program

For both central heating and hot water function of the boiler, time programs with three programmable periods per day are available. These time programs are set and activated by entering the desired settings directly at the boiler control panel.

2.2 Technical specifications datasheet

GENERAL										
Product Identification N	umber	-	CE 0063 BP3254							
Classification		-	II2H3P (for NL II2L3P)							
Gas Appliance Type		-	B23,	B23, B23P; C13X, C23X, C33X, C43X, C53X, C63X, C83X						
Type boiler			S-CB⁺60	S-CB ⁺ 80	S-CB ⁺ 100	S-CB ⁺ 120	S-CB ⁺ 150	S-CB ⁺ 180		
Dimensions (h x w x d)		mm		842 x 47	76 x 486		898 x 4	76 x 677		
Water content estimate	d	litre	3,9	5,0	6,5	8,3	10,4	12,9		
Weight (empty)		kg	46	73	78	83	92	101		
Flow/return connection	(boiler)	inch	R 1"	R 1"	R 1"	R 1"	R 1¼"	R 1¼"		
Flow/return connection	(T-piece)	inch	Rp 1¼"	Rp1¼"	Rp 1¼"	Rp 1¼"	Rp 1½"	Rp 1½"		
Gas connection		inch	R ¾"	R ¾"	R ¾"	R ³⁄₄"	R 1"	R 1"		
Flue duct flue/air inlet (*	as supplied)	mm	80/125*	80/125*	100/150*	100/150*	100/150	100/150		
Parallel connection (* a	s supplied)	mm	80-80	80-80	100-100	100-100	130-130*	130-130*		
HEATING			Values r	nin-max:						
Nominal input (Net)		kW	12,5 - 55,6	14,6 - 74,3	17,2 - 92,2	26,0 - 111	34,0 - 138	45,0 - 166		
Nominal input (gross) (G20, G25)	kW	13,9 - 61,8	16,2 - 82,5	19,1 - 102	28,9 - 123	37,8 - 153	50,0 - 184		
Nominal input (gross) (G31)	kW	13,6 - 60,4	15,9 - 80,8	18,7 - 100	28,3 - 121	37,0 - 150	48,9 - 180		
Nominal input (gross) (G30)	kW	13,5 - 60,3	15,8 - 80,2	18,6 - 99,7	34,7 - 120	36,8 - 150	48,8 - 180		
Nom. output 80/60°C		kW	12,0 - 53,5	14,0 - 71,2	16,5 - 88,4	24,7 - 106	32,6 - 132	43,3 - 160		
Nom. output 50/30°C		kW	12,9 - 57,4	15,2 - 77,5	18,0 - 96,2	27,2 - 116	35,5 - 144	47,3 - 175		
Nom. output 37/30°C		kW	13,5 - 59,8	15,7 - 80,1	18,6 - 99,5	28,1 - 120	36,7 - 149	48,5 - 179		
Efficiency 40/30°C DIN	4702-8	%	up to 110,6 % within the S-CB ⁺ range							
GAS CONSUMPTION	[EN437]		Values n	nin-max:						
Natural gas G25		m³ _{st} /h	1,54 - 6,84	1,80 - 9,14	2,12 - 11,4	3,20 - 13,7	4,18 - 17,0	5,54 - 20,4		
Natural gas G20		m³ _{st} /h	1,32 - 5,88	1,54 - 7,86	1,82 - 9,76	2,75 - 11,8	3,60 - 14,6	4,76 - 17,6		
Propane gas G31 ¹		m³ _{st} /h	0,51 - 2,27	0,60 - 3,04	0,70 - 3,77	1,06 - 4,54	1,39 - 5,65	1,84 - 6,79		
Butane gas (B/P) G	30 ¹	m³ _{st} /h	0,39 - 1,72	0,45 - 2,29	0,53 - 2,85	0,99 - 3,44	1,05 - 4,28	1,40 - 5,15		
	G25	mbar			25					
Gas supply pressure	G20	mbar			20					
nom. ²	G31 ¹	mbar			30/	37				
	G30 ¹	mbar			50					
NOTES										
¹ Using propage or b	utane/propane	mixtures	(B/P) maxin	num fan spe	ed needs to	be reduced	(parameter F	24BD)		
 ¹ Using propane or butane/propane mixtures (B/P), maximum fan speed needs to be reduced (parameter P4BD) ² Min. and max. gas supply pressures according to EN437: 								,		
Γ	p nominal [n	nbar]	p min [mbar]	p max [mbar]				
G25	25		20	_	30	_				
G20	20		17	7	25	5				
G31	30		25		35					
	37		25		45					
G30	50		43	3	57					

Type boiler				S-CB⁺60	S-CB ⁺ 80	S-CB ⁺ 100	S-CB ⁺ 120	S-CB ⁺ 150	S-CB⁺180	
EMISSION [EN437]			Values	min-max:					
	G25	/G20	%	8,7 - 9,0	8,7 - 9,0	8,7 - 9,0	8,7 - 9,0	8,7 - 9,0	8.7 - 9.0	
CO ₂ flue gas ³	G31		%	9,3 - 10,3	9,3 - 10,3	9,3 - 10,3	9,3 - 10,3	9,3 - 10,4	9.3 - 10.5	
	G30	(B/P)	%	9,3 - 10,4	9,3 - 10,4	9,3 - 10,4	9,3 - 10,4	9,3 - 10,5	9.3 - 10.6	
	rom	ingion	ppm	21,0	31,5	24,6	27,4	25,3	16,5	
NOx at 0% O ₂ , yea	i em	1551011	mg/kWh	37,7	56,6	44,2	49,2	45,4	29,7	
NOx class [EN483	/ EN	15420]	-			ţ	5			
Flue gas temperatura air temperature = 2		t combustion	°C			~ 85	5-95			
Available pressure tem ⁴	Available pressure for the flue system ⁴					20	00			
INSTALLATION										
Available pressure	for	ΔT = 20 K	mWC	3,8	1,3	1,5	1,0	0,7	0,1	
the installation at		∆T = 25 K	mWC	5,1	3,7	3,7	3,0	3,2	2,5	
Pressure boiler mir	n-ma	х.	bar	1,0 - 4,0 ⁵						
Max. flow temperat	ture		°C			90				
ELECTRIC										
Power consumption	n		W	355	355	355	370	60	00	
Power supply			V/Hz			230	/50			
Protection class			-	IPX4D						
NOTES	NOTES									
³ CO ₂ of the unit measured/set without the boiler front panel in place ⁵ When the built-in water pressure sense by a water pressure switch, water pre										
⁴ Maximum allow gas and air sup				flue	up to 6,0	bar				

3 **DIMENSIONS**

3.1S-CB⁺ 60-120

TWIN PIPE





CONCENTRIC (Standard Delivery)







	Connections			twi	n pipe		Concentric (Standard Delivery)			
	U	onnections	⁺60	*80	⁺ 100	⁺ 120	⁺60	*80	⁺ 100	⁺ 120
	FG flue gas AI air inlet		80	-80	100-	-100	80/125		100/150	
Г	siz	e " A "	1	12			155	112		
	siz	e "B"	1	135			150	0 135		
	siz	e " C "	3	808			N.A.			
	F	flow	F	R 1¼" (I	male)					
	C condensate R return		f	lexible l	hose Ø2	5/21 x 75	0 mm			
			R 1¼" (male)							
	G	gas	F	R ¾" (m	ale)					



308 385

TWIN PIPE (Standard Delivery)

CONCENTRIC





C	onnections	twin pipe (Standard Delivery)	concentric
FG Al	flue gas air inlet	130-130	100/150
F C R G	flow condensate return gas	R 1½" (male) flexible hose Ø2 R 1½" (male) R 1" (male)	5/21 x 750 mm

4 ACCESSORIES AND UNPACKING

4.1 Accessories

Depending on the selected controlling behaviour for the central heating system and/or the optional use of a calorifier, the following items can be supplied with the boiler. Ask your supplier for the specifications.

Iten	1	Part №.
Out	door (air) temperature sensor: 12kOhm@25°C (to be connected to the boiler connections)	E04.016.585
	ernal flow temperature sensor for system side of the low loss header: 10kOhm@25°C (to nounted to the boiler connections)	E04.016.304
Calo	prifier temperature sensor: 10kOhm@25°C (to be connected to the boiler connections)	S04.016.303
6	S-CB ⁺ 60: concentric to twin pipe 80/125 \rightarrow 80-80	E61.001.162
minals	S-CB ⁺ 60: twin pipe to concentric 80-80 \rightarrow 80/125	E61.001.187
Conversion sets flue and air terminals	S-CB ⁺ 80: concentric to twin pipe 80/125 \rightarrow 80-80	E61.001.163
and a	S-CB ⁺ 80: twin pipe to concentric 80-80 \rightarrow 80/125	E61.001.170
s flue	S-CB ⁺ 100-120: concentric to twin pipe 100/150 \rightarrow 100-100	E61.001.164
on set	S-CB ⁺ 100-120: twin pipe to concentric 100-100 \rightarrow 100/150	E61.001.171
versic	S-CB ⁺ 150-180: concentric to twin pipe 100/150 \rightarrow 130-130	E61.001.165
Con	S-CB ⁺ 150-180: twin pipe to concentric 130-130 \rightarrow 100/150	E61.001.172
Roo	m Controller "OpenTherm" RC (Modulating) with room sensor	S04.016.355
Roo	m Controller "OpenTherm" RC (Modulating) no room sensor/to be used with E04.016.359	S04.016.358
Exte	ernal room sensor for the RC and RCH controller: 5kOhm@25°C	E04.016.359
	m thermostat (modulating) RCH with e-bus interface, to control one heating zone (Ther- tat includes room sensor).	S04.016.357
	C heating zone controller to control 2 different heating zones. This EBC will include the wall sing unit, for an easy installation and connection.	S04.016.550
	fface IF to convert an OpenTherm signal to an E-bus signal (One interface for each boiler ne interface for cascaded boilers).	S04.016.552
Exte	ernal flow sensor for one heating zone: 5 kOhm@25°C	E04.016.363
Soft	ware + interface cable for programming the boiler with a computer/laptop	S04.016.586

4.2Unpacking

The S-CB⁺ boiler will be supplied with the following documents and accessories:

- One "Mounting Instructions" manual for the installer
- One suspension bracket with locking plate and bolts
- Three spare nuts for mounting the burner plate, two spare fuses for the boiler control and a gas conversion sticker (all in a bag attached to the front of the gas valve)
- Bottom part of the siphon
- Two T-pieces for the flow and return connections of the boiler

After delivery, always check the boiler package to see if it is complete and without any defects. Report any imperfections immediately to your supplier.

5 INSTALLATION OF THE S-CB⁺

5.1 General notes

At every side of the boiler at least 50 mm of clearance should be applied to walls or wall units, 350 mm above the top side of the boiler and 250 mm from the bottom of the boiler.

The installation area/room must have the following provisions:

- 230 V 50 Hz power source socket with earth connection.
- Open connection to the sewer system for draining condensing water.
- A sound-deadening wall.

Note:

The wall used for mounting the boiler must be able to hold the weight of the boiler. If not, it is recommended to mount the boiler by means of a (cascade) frame.

Other considerations related to the boiler location.

- The ventilation of the boiler room must meet local and national standards and regulations, regardless of the selected supply of fresh air to the boiler.
- Both the air supply and the flue gas pipes must be connected to the outside wall and/or the outside roof.
- The installation area must be dry and frost-free.
- The boiler has a built-in fan that will generate noise, depending on the total heat demand. The boiler location should minimise any disturbance this might cause. Preferably mount the boiler on a brick wall.
- There must be sufficient lighting available in the boiler room to work safely on the boiler.
- When a boiler is positioned at the highest point of the installation, the supply and return pipes must first
 protrude 0.5 m above the top of the boiler, before these pipes go to the installation side. In other words, the
 water level must always be 0.5 meter above the top of the boiler and an automatic air vent must be installed in the supply or return pipe. A low-water level protection should also be installed at the installation
 side.
- Remind the positioning of electrical components in relation to the temperature sensitivity.
- Make sure there is an open connection with the sewer to drain the condensate. This connection should be lower than the condensate drain level of the boiler.

The boiler must be positioned and installed by a skilled installer in accordance with all applicable standards and regulations. Commissioning of the boiler must be done by a skilled service/commissioning engineer, who is trained for this type of boiler.

5.2 Mounting the boiler

Before mounting and installing the boiler the following connections should be considered:

- Flue gas system and the flue gas pipe connections
- Air supply system and connections
- Flow and return pipe connection
- Condensate and pressure relief valve drainage
- Power supply (preferably the power connection positioned above the boiler)



All lines/piping must be mounted free of tension. The weight of the installation components should be supported separately from the boiler so there will be no standing forces on the connections. This might influence the mounting position of the boiler.

Determine the position of the flow and return pipes by using the included suspension bracket or a suspension frame (when supplied).

While marking the holes, ensure that the suspension bracket or frame is <u>perpendicular and the boiler does not lean</u> <u>forward</u>. If necessary adjust the position with the adjusting bolts at the lower rear side of the back panel (see drawing). When the adjusting bolts aren't sufficient, fill the gap behind the bolts to get the boiler in position. The exact boiler position lies between the boiler hanging level and hanging slightly backwards.

The boiler should not lean forward in the mounted position.

Lock the suspension bracket with the security cover before making any other connections to the boiler. This security cover will prevent the boiler from falling off the bracket. Don't use excessive force during the mounting of the boiler connections.



6 CONNECTIONS WATER SIDE

FRONT VIEW



Open connection

to the sewer.

6.1 Boiler connections

- 1 Flow CH
- 2 Condensate drain
- 3 Siphon cleaning point
- 4 Return CH
- 5 Gas

6.2Condensate drain connection

The condensate drain is placed at the centre and at the bottom of the boiler and has a $\frac{3}{4}$ inch hose discharge. Connect this flexible hose to the sewer system.

Use only plastic parts with the condensate drain. Metal lines are not allowed.

Blockage of this drain might damage the boiler. The drain connection is correct when the condensate can be seen flowing away, e.g. using a funnel. Any damage that might occur, when the drain is not installed correctly, is not covered by the warranty of the boiler.

There should be an <u>open</u> connection of the condensate hose into the sewage system. A possible vacuum in the sewage system must never give the opportunity to suck on the boiler's condensate drain hose.



When mounting the bottom part of the siphon, before commissioning the boiler and/or after maintenance, the siphon must **ALWAYS** be <u>completely</u> filled with water.

This is a safety measure: the water in the siphon keeps the flue gases from leaking out of the heat exchanger via the condensate drain.





6.3Flow and return connections

Two separate T-pieces are shipped with the boiler. These are applied for externally mounting the pressure relief valve and the boiler bleed valve for servicing the boiler. We advise to install two service valves in the flow and return pipes underneath the boiler, so the boiler can be isolated from the heating system and eventually disconnected, when needed.

When using a system pump, this pump should <u>always</u> be mounted in the return pipe of the heating system. Do not use chloride-based fluxes for soldering any pipes of the water system.

6.4The expansion vessel

The capacity of the expansion vessel must be selected and based on the capacity of the central heating system and the static pressure. Suggested is to fit the expansion vessel in the return pipe of the central heating system. It can be combined with the drain valve for service. See the above drawing.

6.5Pressure relief valve

The boiler has no internal pressure relief valve. This should be installed close to the boiler in the flow pipe of the heating system. When having cascaded boilers, each boiler should have its own pressure relief valve. It is advised to use the T-piece that is supplied with the boiler, for this.

Advice is always to install service valves, so the boiler can be isolated from the heating system, when needed. Make sure that the pressure relief valve is mounted between the boiler and the service valves.

The specifications and size of the relief valve should be determined by the installer and must comply with all applicable regulations and boiler capacity.

6.6Bypass

The boiler has no internal bypass. When many thermostatic valves are being used, the system should have a bypass to allow an adequate flow when all thermostatic valves are closed. Instead of a bypass also a low-loss header can be used for this function.

The boiler flow will also be influenced when a pipe of the heating system is frozen / blocked. Make sure all heating pipes are free from the risk of frost. If there is the risk of freezing of the heating system, all the pipe section must be insulated and/or protected with the help of a tracing.

6.7Pump functionality

Controlling the pump:

The pump speed is controlled by a PWM signal provided by the burner controller at a value causing a Delta T across the heat exchanger of 20°C at the whole burner modulation range.

When the boiler modulates down or up, also the pump speed decreases or increases, keeping delta T at 20°C until it reaches the end of its modulation range.

Delta T monitoring:

The delta T monitoring parameters are active. A malfunctioning of the pump, burner controller or a high resistance in the hydraulic system will cause a high Delta T and will therefore be detected by the burner controller. The display shows "dT Block" or "FlowReturn dTfault".

6.8Frost protection

The boiler has a built-in frost protection that is automatically activating the central heating pump when the boiler return (water) temperature drops below the 5°C (programmable). When the boiler return temperature drops below the 3°C (programmable), the burner is also ignited. The pump and/or burner will shut down as soon as the return temperature has reached the 10°C (programmable). The mentioned temperatures are related to the temperatures measured by the RETURN sensor of the boiler. This frost protection function will not fire up the boiler in case of a "general blocking" of the burner demand.

NOTICE: This "Frost Protection" function is only useable for the boiler and not for the whole central heating system. Because it concerns a programmable setting, a boiler damaged by frost is not covered under warranty.

6.9Installing a strainer and/or dirt separator



Always install a strainer (water filter) and/or a dirt separator in the return pipe of the boiler; in such a way that the water going to the boiler is free of any debris/particles. When using a water filter always check a week after installation to determine the strainer cleaning interval. Advice is to mount valves before and after the strainer, including an air bleed valve, so the strainer can be isolated from the heating circuit for service operations. Clean water is very important, blocked and/or polluted heat exchangers, including failures and/or damages caused by this blockage are not covered by the warranty.

6.10 Water quality

The pH value of the water must be within the following limits: 7.5 < pH < 9.5. This pH value is reached with the steady conditions. These steady conditions will occur, when after filling the heating system (pH around 7) with fresh water, the water will lose its air because of the air bleeding operation and heating up (dead water conditions).

Water hardness must be within the following limits: $3,5^{\circ}$ Clark (50 ppm CaCO₃) < total hardness < $10,5^{\circ}$ Clark (150 ppm CaCO₃)

When the water might contain aluminium particles, this should be of a maximum of 0.2 mg/litre. If there is the risk of contamination of the water by any kind of debris/chemicals in the period after installing, a plate heat exchanger should be used to separate the boiler circuit from the heating circuit (see drawing below).

It is advised to prevent the possible air intake and water leakage of the central heating system. Fresh oxygenated water might damage the heat exchanger of the boiler and should therefore be prevented! Usual spots where air is most likely to seep in are: suction gaskets, pumps, air valve working as a venting pipe, O-rings / gaskets in stuffing box, under floor heating pipes.

6.11 Plastic piping in the heating system

When plastic pipes are used in the central heating system, these should be separated from the boiler system by using a plate heat exchanger. Diffusion (through the plastic) can cause air to enter the heating system. This could damage the boiler, pumps and other components in the system. Be aware that plastic piping is often used in under floor heating systems. When no measures have been taken to prevent the entrance of air into the boiler system, the warranty of the boiler and any boiler part may be deemed invalid.



6.12 Automatic air vent

An automatic air vent is mounted on the boiler to remove the air from the water circuit.

NOTICE: This automatic air vent is only used for bleeding the air in the heat exchanger of the boiler. One or more external automatic air vent(s) and/or air separators must always be mounted in the heating system to take out the air trapped in the heating circuit.

DE-AERATION PROGRAM. When the unit is fired for the first time the unit starts a de-aeration program. One cycle means 5 seconds pump running and 5 seconds pump off. A complete de-aeration program consists out of three cycles. The de-aeration program can be interrupted/stopped by briefly pressing the service button.

6.13 Automatic water filling systems

When using an automatic water refill system some precautions should be taken (fresh water is bringing fresh oxygen into the system), like installing a water meter to measure and evaluate the total water volume that is added to the system. This to detect and eliminate any water leakage as soon as possible.

When an automatic water refill system is used, some form of logging should take place to prevent continuously filling of the system with large amounts of oxygenated fresh water. This can happen when a leak in the system is not detected and the total added water amount is not being logged.

6.14 Water pressure

First and for all, the installation should be designed and built conform all applicable regulations and standards, including the right safety valves. IMPORTANT: Always keep the pressure in the boiler lower than the value at which its safety valve opens.

Sensor

A water pressure sensor has been built into the boiler. With this sensor, the minimum water pressure in the boiler is 0,8 bar and the maximum pressure is 4,0 bar (sensor values). The normal water pressure is supposed to be between 1,5 and 2,0 bar.

The pressure sensor will stop the boiler from firing when the water pressure drops below 0,8 bar, and start the boiler firing again when the water pressure reaches above the 1,0 bar. These values can be changed in the boiler control settings.

Higher pressure systems (e.g. in high buildings)

If pressures higher than 4,0 bar occur in the heating system, the best solution is to separate the system from the boiler by means of a plate heat exchanger. Now the boiler pressure can still be under 4,0 bar and the boiler control remains as described above.

Without plate heat exchanger, above 4,0 bar, a water pressure switch has to be built into the boiler instead of the water pressure sensor - the <u>maximum</u> allowed value in the boiler now is <u>6,0 bar</u> and the boiler control needs to be adjusted.

6.15 Chemical water treatment

The chemical compatibility of several products for treatment of the central heating equipment has been tested on the heat exchangers and the boilers. A list with the corrosion inhibitors in preventative and curative treatment for gas fired central heating boilers can be supplied by Strebel Ltd.

6.16 Under floor heating

When using an under floor heating system, the boiler circuit must be separated from the heating circuit with a plate heat exchanger.

6.17 Flush the system with fresh water

The water of the boiler and heating circuit should be free of any particles, debris and pollution. Therefore the complete installation must always be thoroughly flushed with clean water before installing and using the boiler(s).

6.18 Installation examples





6.18.2 EXAMPLE OF A MULTIPLE BOILER HEATING CIRCUIT WITH LOW LOSS HEADER



7 PUMP CHARACTERISTICS

7.1 Hydraulic graphs

Boiler and pump graph **S-CB⁺ 60**. UPML 25-105PWM:



Boiler and pump graph **S-CB⁺ 80**. UPML 25-105PWM:





Boiler and pump graph S-CB⁺ 100. UPML 25-105PWM:

Boiler and pump graph **S-CB⁺ 120**. UPML25-105 PWM:





Boiler and pump graph S-CB⁺ 150. Wilo Stratos Para 30/1-12 PWM:

Boiler and pump graph S-CB⁺ 180. Wilo Stratos Para 30/1-12 PWM:



Explanation pump graph:

The S-CB⁺ range is equipped with high efficiency pumps, in the hydraulic graph there is a minimum and maximum head for the pump. This is the range in which the pump will modulate.

The pump speed is controlled by a PWM signal provided by the burner controller at a value causing a Delta T across the heat exchanger of 20°C at the whole burner modulation range.

7.2Pumps: maximum electrical power

General

- The start current of a conventional pump is approximately 21/2 x its nominal current.

- The maximum switch current of the PCB is 5 A.

When the two statements are combined, the conclusion is that nominal currents of pumps, controlled by the PCB, may not exceed 2 A.

Pump P1 - boiler pump.

This modulating pump is part of the appliance. The speed and power consumption depends on the Delta T across the heat exchanger and is controlled by the burner controller.

Pump P2 - calorifier pump.

Pump P2 is a DHWi pump and is used when P4AA = 1, meaning the appliance is an indirect calorifier.

Pumps P1 and P2 are connected to one fuse of 5 A, so their total nominal current may not exceed 5 A. To limit the inrush current, the switching sequence has been modified so pump P2 always switches 100 ms later than pump P1.

The maximum nominal current of pump P2 must also be 2 A, again due to the inrush current.

3 way valve.

The combined nominal current of pump P1 and the 3 way valve must be smaller than 5 A. So, the inrush current of the 3 way valve must be lower than 3 A.

Pump P3 - system pump.

The nominal current of pump P3 must be equal to or lower than 2 A.

Warning (EC pumps):

In case of using an electronic commutating pump, the relays 1, 2 or 3 <u>may not be used</u> for the power connection, because of the inrush current of the electronics of the pump.

Directly connect the pump to an external power supply.

Control connections of an EC pump can be established in several ways, set by parameter P5BN.

See § 11.1.7 on page 79.

8 FLUE GAS AND AIR SUPPLY SYSTEM

8.1 General

The boiler has a positive pressure flue system. The available combined pressure drop for the inlet and outlet system is 200 Pa for the complete boiler range.

Notice:

- Install the horizontal flue components with an angle of 3° downwards in the direction of the boiler (roughly equal to five centimetres for every linear meter). When not installed accordingly, it may result in condensate building-up in the flue gas tube, eventually causing component failure.
- Wall flue terminals are generally used up to 60-80 kW. Using these terminals with larger capacities will give unpleasant large condensate clouds.
- When using a wall terminal, there is the possible risk of ice building-up on surrounding parts/structures, because the condensate will freeze. This risk should be taken into account during the design phase of the heating installation.

Note

Because the flue gases can have a low temperature, the boiler needs to have a high efficiency approved stainless steel or plastic flue system. These materials, including the gaskets, should be usable for positive pressure flue gas systems and have a temperature class of **T120**.

8.2Air supply

When an air supply duct is connected from the outside of the building to the boiler, the boiler will operate as a room-independent boiler (closed boiler).

The air supply duct can be made of:

- PVC / PP
- Thin-walled aluminium
- Stainless steel

8.2.1 COMBUSTION AIR QUALITY

Combustion air must be free of contaminants. For example: chlorine, ammonia and/or alkali agents, dust, sand and pollen. Remind that installing a boiler near a swimming pool, a washing machine, laundry or chemical plants does expose combustion air to these contaminants.

8.2.2 AIR SUPPLY THROUGH HUMID AREAS

When the supply duct will be placed in a boiler room with moist air (for example: greenhouses), a double walled supply duct or an insulated duct must be used to prevent the possible condensation at the outside of the duct. It is not possible to insulate the internal air pipes of the boiler and therefore condensation at the internal air canals must be prevented.

When roof mounted, the air supply duct needs to be protected against rain, so no water will be entering the boiler.

8.3Flue terminal

Never use aluminium (containing) flue gas materials for this boiler.

The flue terminal duct can be made of:

- Stainless steel in combination with T120 gaskets
- PP temperature class T120

Multiple boilers can be connected to a common duct. These flue gas systems for multiple boiler installations must always be engineered as zero or negative pressure systems; this to prevent the risk of recirculation of the flue gases. Consult the flue gas supplier for detailed information and engineering. See also the cascade manual for these multiple boiler installations.

8.4S-CB⁺ 60 Twin pipe version

The S-CB⁺ 60 boiler as shown in the picture below, is a <u>twin pipe</u> boiler with separate air inlet and flue outlet pipes. <u>Do NOT connect a concentric pipe to this boiler</u>.

Note the sticker on the flue pipe, indicating that this is a <u>twin pipe</u> boiler.



The twin pipe version is recognized by the two pipes, one of which has a **RED** ring cap.

8.5Pipe heights and mutual distances on a flat roof

Height A

This is the height of the air inlet. A rain hood should prevent rainwater entering the air supply system.

When the inlet and outlet are mounted on a flat roof, the inlet should be at least 60 cm above the roof surface and at least 30 cm above the maximum snow level.

Example 1:

When the maximum snow level on the roof surface is 45 cm then the air inlet should be at 45+30=75 cm. 75 cm is more than the minimum 60 so the height will be 75 cm.

Example 2:

When the maximum snow level on the roof surface is 15 cm then the air inlet should be at 15+30=45 cm. 45 cm is less than the minimum 60 cm so the height will be 60 cm.

Height difference B

This is the distance between the flue outlet and the air inlet.

The flue gas outlet should be at least 70 cm above the air inlet. It is advised to be equipped with a conical outlet.

When no air inlet connection is applied on the roof, the flue outlet should be situated at least 100 cm above the roof surface.

Distance C

The horizontal mutual distance at roof level. This distance should be at least 70 cm.

8.6B23P certified

Overpressure flue gas systems

For boiler classification B23P and for overpressure flue gas systems the minimum requirements of the flue gas material for Eco Boilers can be determined in a designation string according to the EN1443 (see table):

CE string flue gas material (B23P)	European stan- dard	Tempera- ture class		- • • •	Corrosion resis- tance class	
min. requirement PP	EN 14471	T120	P1	W	1	
min. requirement StS	EN 1856-1	T120	P1	W	1	

					Plastics: enclosure
	0	30	l or E	C/E	L
L20040	0	40			

A few examples of flue gas material suitable for ECO boilers:

CE String for Plastic PPs: EN14471 T120 P1 W 2 O(30) I C/E L

CE String for Stainless Steel: EN1856-1 T250 P1 W V2-L50040 O (50)

When selecting flue gas systems, be aware that the minimum requirements are met. So only select flue gas materials having the same or better properties than this table.

8.7C63 certified

In general, boilers are certified with their own flue gas material. If a boiler is C63 certified, no specific type flue gas material has been certified in combination with the boiler. In this case the flue gas material does not need to be certified in combination with the boiler but should be fit for purpose, and comply with the applicable European standards. It must be able to handle the condensate forming and transport, overpressure and must have a minimum temperature class of **T120**.



8.8Flue gas and air supply resistance table

In the next section, for five typical flue gas outlet & air inlet configurations the maximum lengths of the straight pipes will be calculated. First all component resistance values are given in the next table:

		⁺60	⁺ 80	⁺ 100	⁺ 120	⁺ 150	⁺ 180
FLUE GAS PIPING	Ø [mm] *	1	·	RESISTA	NCE [Pa]	1
straight tube/m	80	5,0	8,0	-	-	-	-
-	100	2,0	3,5	4,0	6,5	-	-
	130	0,45	0,8	1,2	1,8	3,8	6,0
	150	-	-	0,5	0,8	1,7	3,0
45° bend	80	2,5	4,0	-	-	-	-
	100	1,0	1,7	2,0	3,2	-	-
	130	0,2	0,4	0,6	0,8	1,9	3,0
	150	-	-	0,2	0,4	0,8	1,5
90° bend	80	5,0	8,0	-	-	-	-
	100	2,0	3,5	4	6,5	-	-
	130	0,4	0,8	1,2	1,8	3,8	6,0
	150	-	-	0,5	0,7	1,7	3,0
Flue outlet zeta=0,05	80	0,7	1,2	-	-	-	-
	100	0,3	0,5	0,8	1,1	-	-
	130	0,1	0,18	0,3	0,4	0,6	0,9
	150	-	-	0,15	0,2	0,35	0,5
Flue outlet zeta=1	80	13,8	24,0	-	-	-	-
	100	5,6	9,8	15,2	22,1	-	-
	130	2,0	3,5	5,3	7,8	12,0	17,3
	150	-	-	3,0	4,4	6,8	9,8
Flue outlet zeta=1,5	80	20,6	36,0	-	-	-	-
	100	8,5	14,8	22,8	33,2	-	-
	130	3,0	5,2	8,0	11,6	18,0	26,0
	150	-	-	4,5	6,6	10,2	14,7
AIR SUPPLY PIPING	Ø [mm] *			RESISTA	NCE [Pa]	
straight tube/m	80	4,0	7,5	-	-	-	-
	100	1,2	3,0	3,5	4,0	-	-
	130	0,35	0,75	0,8	1,1	1,2	2,0
	150	-	-	0,3	0,4	0,6	1,2
45° bend	80	2,0	3,5	-	-	-	-
	100	0,6	1,5	1,7	2	-	-
	130	0,2	0,4	0,4	0,5	0,6	1,0
	150	-	-	0,15	0,2	0,3	0,6
90° bend	80	4,0	7,0	-	-	-	-
	100	1,2	3,0	3,5	4,0	-	-
	130	0,3	0,7	0,8	1,1	1,2	2,0
	150	-	-	0,3	0,4	0,6	1,2
Air inlet zeta =1	80	10,4	18,1	-	-	-	-
	100	4,2	7,4	11,4	16,7	-	-
	130	1,5	2,6	4,0	5,8	9,1	13,1
	150	-	-	2,3	3,3	5,1	7,4
CONCENTRIC PARTS	Ø [mm] *			RESISTA	NCE [Pa]	
roof terminal	80/125	34	61	-	-	-	-
	100/150	-	-	39	45	69	86
	130/200	-	-	-	-	15	23
outside wall terminal	80/125	13	22	-	-	-	-
	100/150	-	-	19	24	40	48
straight tube/m	80/125	9	12	-	-	-	-
	100/150	-	-	8	10	14	16
5		5	7	-	-	-	-
45° bend concentric	80/125	5		1 -	<u> </u>	14	16
•		-	-	8	9	14	10
•	80/125 100/150 80/125	- 8	- 13	8	-	-	-
45° bend concentric	100/150 80/125	-	- 13 -	8 - 11	9 - 13	- 22	- 28
45° bend concentric	100/150	- 8		-	-	-	-







* Never reduce pipe diameters relative to boiler connections

Values printed in grey applicable for larger pipe diameters than boiler connection

NOTICE: This table may only be used for a single flue/air system for one boiler. Do NOT use this table for common flue systems with cascaded boilers.

8.9Five typical examples

- A: Twin pipe system with separate pipes for flue gas and air supply
- **B**: Twin pipe system with separate pipes and concentric roof terminal
- **C**: Single pipe for flue gas outlet only (air supply from boiler room)
- D: Concentric pipe for flue gas/air supply (roof-mounted)
- E: Concentric pipe for flue gas/air supply (wall-mounted)

8.9.1 EXAMPLE A: TWIN PIPE SYSTEM



Calculation example with given lengths: checking resistance

	Boiler type:		S-CB ⁺ 180					
	Diameter: 1	30 mm	Number	Ра	Pa total			
gas	Straight tube m ¹	total	9	6	54			
	Bend	90°	2	6	12			
Flue	Flue outlet	conical	1	0,9	0,9			
	Total res	istance flue	gas outlet:		66.9			
У	Diameter: 1	30 mm	Number	Ра	Pa total			
supply	Straight tube m ¹	total	8	2	16			
sup	Bend	90°	2	2	4			
Air :	Air inlet	H/D = 1,0	1	13,1	13,1			
٩	33,1							
-	Total resistance flu	e gas outlet	and air su	oply:	100 Pa			

C13, C33, C43, C63, C93

B23, B23P, B33

The total resistance is less than 200 Pa. This flue gas / air supply system is functional.

8.9.2 EXAMPLE B: TWIN PIPE SYSTEM WITH CONCENTRIC ROOF TERMINAL



Calculation example with given lengths: checking resistance

	Boiler type:		S-CB⁺ 120						
	Diameter: 10)0 mm	Number	Ра	Pa total				
(0	Straight tube m ¹	total	6	6,5	39				
gas	Bend	90°	2	6,5	13				
0	Roof terminal	concentric 150/100	1	45	45				
-	Adaptor conc./par.	150/100	1	22	22				
	Total resi		119						
Ļ	Diameter: 10)0 mm	Number	Ра	Pa total				
Air sup- ply	Straight tube m ¹	total	6	4	24				
hir s pl	Bend	90°	2	4	8				
4	32								
	Total resistance flue	Total resistance flue gas outlet and air supply:							

The total resistance is less than 200 Pa. This flue gas / air supply system is functional.





Example A									
k	oiler type \rightarrow	S-CB ⁺ 60	S-CB ⁺ 80	S-CB [↑] 100	S-CB [↑] 120	S-CB [↑] 150	S-CB [⁺] 180		
Diameter air inlet	[mm]	80	80	100	100	130	130		
Diameter flue outlet	[mm]	80	80	100	100	130	130		
Diam. roof terminals	[mm]	80	80	100	100	130	130		
Maximum pipe leng (inlet + outlet togethe	r imi	27,5	18,0	31,5	24,0	44,5	30,0		

Example B									
boiler type \rightarrow		S-CB ⁺ 60	S-CB ⁺ 80	S-CB [↑] 100	S-CB [↑] 120	S-CB [↑] 150	S-CB ⁺ 180		
Diameter air inlet	[mm]	80	80	100	100	130	130		
Diameter flue outlet	[mm]	80	80	100	100	130	130		
Concentric roof terminal	[mm]	80/125	80/125	100/150	100/150	130/200	130/200		
Maximum pipe length (inlet + outlet together)	[m]	21,0	12,0	23,0	16,5	40,5	25,5		

8.9.3 EXAMPLE C: SINGLE FLUE GAS OUTLET. AIR SUPPLY FROM BOILER ROOM



	Boiler type:		S-CB ⁺ 100					
	Diameter: 10	Number	Ра	Pa total				
S	Straight tube m ¹	total	13	4	52			
gas	Bend	90°	2	4	8			
Flue	Bend	45°	2	2	4			
	Flue outlet	H/D = 1,0	1	15,2	15,2			
	Total resi	79,2						

Calculation example with given lengths: checking resistance

The total resistance is less than 200 Pa. This flue gas / air supply system is functional.



Example C								
	boiler type $ ightarrow$	S-CB ⁺ 60	S-CB ⁺ 80	S-CB [⁺] 100	S-CB [⁺] 120	S-CB [⁺] 150	S-CB ⁺ 180	
Diameter air inlet	[mm]	80	80	100	100	130	130	
Diameter flue outlet	[mm]	80	80	100	100	130	130	
Diam. roof terminal	[mm]	80	80	100	100	130	130	
Maximum pipe length (total outlet length)	[m]	36,5	21,5	46,5	27,5	49,5	30,0	

8.9.4 EXAMPLE D: CONCENTRIC FLUE GAS/AIR SUPPLY PIPE (ROOF-MOUNTED)



Calculation example with given lengths: checking resistance

	Boiler type:	S-CB ⁺ 60					
	Diameter: 80/12	5 mm.	Number	Ра	Pa total		
	Adaptor conc./par.	80/125	1	10	10		
tric	Straight tube m ¹	total	11	9	99		
cen	Bend	90°	3	8	24		
Concentric	Bend	45°	2	5	10		
0	Concentric terminal	roof	1	34	34		
	Total resistance flo (c	177					

The total resistance is less than 200 Pa. This flue gas / air supply system is functional.

8.9.5 EXAMPLE E: CONCENTRIC FLUE GAS/AIR SUPPLY PIPE (WALL-MOUNTED)



Calculation example with given lengths: checking resistance

	Boiler type:		S-CE	3⁺ 60	
	Diameter: 80/12	Number	Ра	Pa total	
S	Adaptor conc./par.	80/125	1	10	10
entri	Straight tube m ¹	total	9	9	81
Concentric	Bend	90°	1	8	8
ŏ	Concentric terminal	wall	1	13	13
	Total resistance flu (c	112			

The total resistance is less than 200 Pa. This flue gas / air supply system is functional.

Examples D and E maximum pipe lengths



Example D								
boile	er type \rightarrow	S-CB ⁺ 60	S-CB ⁺ 80	S-CB [⁺] 100	S-CB [⁺] 120	S-CB [⁺] 150	S-CB [⁺] 180	
Diameter concentric pipe	[mm]	80/125	80/125	100/150	100/150			
Concentric roof terminal	[mm]	80/125	80/125	100/150	100/150			
Maximum pipe length [m]		13,5	6,0	12,0	7,5	(choose I		

Example E								
boiler type \rightarrow		S-CB ⁺ 60	S-CB ⁺ 80	S-CB⁺ 100	S-CB⁺ 120	S-CB⁺ 150	S-CB⁺ 180	
Diameter concentric pipe	[mm]	80/125	80/125	100/150	100/150	100/150	100/150	
Concentric wall terminal	[mm]	80/125	80/125	100/150	100/150	100/150	100/150	
Maximum pipe length	[m]	18,5	12,5	19,0	14,0	7,0	4,0	
9 ELECTRICAL INSTALLATION

9.1 General

All the wiring is connected to a separate connector that is fitted in a socket. The connector can be taken from the sockets without loosening the wiring. The connections are placed on top of the display panel and can be accessed by removing the boiler front door and the connector protection cover.

- For operation the boiler needs a power supply of 230 Vac 50Hz.
- The boiler connections are not life/neutral sensitive (the boiler is not phase-sensitive).
- The wiring for the connections can be entered at the bottom of the boiler through the cable glands.
- NOTICE: Before starting to work on the boiler, it must be switched off and the power supply to the boiler must be disconnected.
- Electrical wiring should be installed according to all applicable standards and regulations.
- Working on the boiler should only be done by a qualified service engineer that is skilled in working on electrical installations and according to all applicable standards.



9.2 Electrical connections

9.3Explanation of the connections

1-2	OUTDOOR SENSOR										
When an outdoor temperature sensor is connected, the boiler will control the flow water temperature											
by using a calculated setting, which is relative to the outdoor temperature.											
PARAMETER: No parameter settings needed.											
3-4	EXTERNAL FLOW SENSOR										
sensor must be mo TICE: The sensor n	When a low loss header is used, this sensor measures the flow temperature at the system side. The sensor must be mounted on the supply pipe at the system side, just behind the low loss header. NO-TICE: The sensor must be used when boilers are cascaded with the internal cascade manager. PARAMETER: No parameter settings needed.										
5-6 CALORIFIER SENSOR or THERMOSTAT											
When an indirect hot water tank / calorifier is installed, a hot water sensor must be connected to these terminals. In case of a DHW heat demand, the set point will be shown in the display. An external on/off thermostat can also be connected to these terminals. When there is heat demand (terminals 5 and 6 are bridged) the flow temperature going to the heating coil(s) will be shown in the display.											

7-8	GENERAL BLOCKING
	at will start the burner will be blocked when terminals 7 and 8 are not bridged. This
	ne use of external safety devices (terminals must be bridged for allowing burner to
fire). 9-10	EMPTY
5 10	
11-12	EXTERNAL WATER PRESSURE SWITCH
stalled. The sensor	sensor is mounted in the boiler. As an option a water pressure switch can be in- can be replaced by the water pressure switch, which can be wired to the terminals. -12 are not bridged, the boiler will lock-out. PARAMETER: A parameter change is
13-14	ON/OFF STAT OR OPENTHERM HEATING CIRCUIT
temperature for the OPTION 2: An Op	I/OFF thermostat can be connected. The boiler will use the set/programmed flow e heating system when these terminals 13 and 14 are bridged. enTherm (OT) controller can be connected to the terminals 13 and 14. The boiler and use this OpenTherm signal automatically.
15-16	0-10 VDC CONTROL SIGNAL
	e used for an external 0-10 VDC control signal. PARAMETER: A parameter change : Terminal 15 [+] (positive) and terminal 16 [-] (negative).
17-18	CASCADE CONNECTION
	are used when boilers are cascaded with the internal cascade manager for control- ide. NOTICE: Connect all terminals 17 and all terminals 18 together, do not switch ninals.
19-20	LOCK-OUT OR PUMP ON/OFF
This contact can a then a parameter c	. (normally open). When the unit is in lock-out this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed.
	-
21-22	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF
This contact is N.C tact will be closed.	-
This contact is N.C tact will be closed.	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF 0. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF D. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection;
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter c 25-26-27	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF b. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed. CH SYSTEM PUMP P3
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter c 25-26-27 Connections for a c	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF D. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed.
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter c 25-26-27 Connections for a c Nominal pump curr	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF D. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed. CH SYSTEM PUMP P3 central heating system pump (P3).
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter of 25-26-27 Connections for a of Nominal pump curr § 0. 28-29-30-31 When using a calou the heating coil of tank/calorifier has a 28 = L2 wire (heating	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF D. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed. CH SYSTEM PUMP P3 central heating system pump (P3). rent of P3 may not exceed 2 A, therefore its power may not exceed 460 W, see also
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter of 25-26-27 Connections for a of Nominal pump curr § 0. 28-29-30-31 When using a calou the heating coil of tank/calorifier has a 28 = L2 wire (heating	 BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF b. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed. CH SYSTEM PUMP P3 central heating system pump (P3). eent of P3 may not exceed 2 A, therefore its power may not exceed 460 W, see also DIVERTER VALVE CALORIFIER rifier/hot water tank, a 3-way valve or a pump (P2) can be used to divert hot water to of the calorifier/tank. This 3-way valve will open, when the hot water storage a heat demand. PARAMETER: A parameter change is needed. ng position); 29 = Neutral wire; 30 = Ground wire; 31 = L1 wire (hot water position).
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter of 25-26-27 Connections for a c Nominal pump curr § 0. 28-29-30-31 When using a calou the heating coil of tank/calorifier has a 28 = L2 wire (heatin The inrush current 29-30-31 When using a calou the heating coil of creates a hot water	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF D. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a ate control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed. CH SYSTEM PUMP P3 central heating system pump (P3). rent of P3 may not exceed 2 A, therefore its power may not exceed 460 W, see also DIVERTER VALVE CALORIFIER rifier/hot water tank, a 3-way valve or a pump (P2) can be used to divert hot water to of the calorifier/tank. This 3-way valve will open, when the hot water storage a heat demand. PARAMETER: A parameter change is needed. mg position); 29 = Neutral wire; 30 = Ground wire; 31 = L1 wire (hot water position). of the 3-way valve may not exceed 3 A, see also § 0.
This contact is N.C tact will be closed. pump with a separa 23-24 This contact is N.O This contact can a then a parameter of 25-26-27 Connections for a of Nominal pump curr § 0. 28-29-30-31 When using a calou the heating coil of tank/calorifier has a 28 = L2 wire (heating The inrush current 29-30-31 When using a calou the heating coil of creates a hot water Nominal pump curr	BURNER BURNING OR EXTRA BOILER OR PUMP ON/OFF D. (normally open). When the unit starts the burner and detects the flame, this con- This contact can also be used to control an external boiler or for the switching of a late control input connection; in both latter cases a parameter change is needed. HEAT DEMAND OR PUMP ON/OFF . (normally open). When the unit receives any heat demand this contact will close. Iso be used for the switching of a pump with a separate control input connection; hange is needed. CH SYSTEM PUMP P3 central heating system pump (P3). rent of P3 may not exceed 2 A, therefore its power may not exceed 460 W, see also DIVERTER VALVE CALORIFIER rifier/hot water tank, a 3-way valve or a pump (P2) can be used to divert hot water to a heat demand. PARAMETER: A parameter change is needed. mg position); 29 = Neutral wire; 30 = Ground wire; 31 = L1 wire (hot water position). of the 3-way valve may not exceed 3 A, see also § 0. CALORIFIER PUMP P2 rifier/hot water tank, a 3-way valve or a pump (P2) can be used to divert hot water to a heat demand. PARAMETER: A parameter change is needed. mg position); 29 = Neutral wire; 30 = Ground wire; 31 = L1 wire (hot water position). of the 3-way valve may not exceed 3 A, see also § 0. CALORIFIER PUMP P2 rifier/hot water tank, a 3-way valve or a pump (P2) can be used to divert hot water to the calorifier/tank. This pump will start when the hot water storage tank/calorifier demand. PARAMETER: A parameter change is needed.

9.4Electrical schematics





9.5Sensor values

SENSOR	SENSOR TYPE	SENSOR VALUE
S1	internal flow sensor	NTC-10K-B3977
S2	internal return sensor	NTC-10K-B3977
S3	external flow sensor	NTC-10K-B3977
S4	calorifier/tank sensor	NTC-10K-B3977
S5	outdoor sensor	NTC-12K-B3740
S6	flue gas sensor	NTC-10K-B3977

Conversion table temperature vs. resistance outdoor sensor NTC-12k B3740

Temperature (°C)	Resistance (Ω)	Temperature (°C)	Resistance (Ω)
-50		0	36130
-45		5	28600
-40		10	22800
-35		15	18300
-30	171800	20	14770
-25	129800	25	12000
-20	98930	30	9804
-15	76020	35	8054
-10	58880	40	6652
- 5	45950	45	5522

Conversion table temperature vs. resistance all sensors except outdoor sensor. NTC-10k B3977

Temperature (°C)	Resistance (Ω)	Temperature (°C)	Resistance (Ω)	Temperature (°C)	Resistance (Ω)	Temperature (°C)	Resistance (Ω)
-30	175203	20	12488	70	1753	120	387
-25	129289	25	10000	75	1481	125	339
-20	96360	30	8059	80	1256	130	298
-15	72502	35	6535	85	1070	135	262
-10	55047	40	5330	90	915	140	232
-5	42158	45	4372	95	786	145	206
0	32555	50	3605	100	677	150	183
5	25339	55	2989	105	586	155	163
10	19873	60	2490	110	508	160	145
15	15699	65	2084	115	443	165	130

10 USER INTERFACE

10.1 Control panel / display unit



10.2 Control panel menu structure





10.3 Display during operation

During normal operation the text in the display shows the status of the boiler. In the following graphs the several displays during normal operation are explained.

H E A T I N G : N o d e m a n d > > : 1 2 3 . 4 ° C (1 2 3 . 4 ° C cascade communication indicator temp. set point control sensor showing the measured temperature. Can be turned off by P5 When heat is needed for the calorifier the text "HEATING" change into "HOTWATR". Image: Calorifier the text "HEATING" change into "HOTWATR".	C)
cascade com- munication indicator temp. set point control sensor showing the measured temperature. Can be turned off by P5 When heat is needed for the calorifier the text "HEATING" change	- /
munication measured temperature. indicator Can be turned off by P5 When heat is needed for the calorifier the text "HEATING" change	he
Indicator Can be turned off by P5 When heat is needed for the calorifier the text "HEATING" change	
When heat is needed for the calorifier the text "HEATING" change	BJ
	es e
When there is no heat demand it always shows heating.	
Display at HOT WATER DEMAND	
Heat demand type: Actual status:	
H O T W A T R : N o d e m a n d	
	C)
temp set point	- í
Communication Thermostat > coil flow measured temperature	
indicator temp. Sensor > water temp.	BJ
when the "Actual status" series	
xplanation "Actual status" screen ctual status:	
/hen boiler is switched off (only text in the display during this status).	
o heat demand signal coming from the room thermostat and calorifier sens	or (open).
t a n d - b y	
oom thermostat & calorifier sensor/thermostat detect heat demand but set	point is
│ r │ e │ - │ p │ u │ r │ g │ e │ │ │ he fan is purging before a burner start attempt.	
r e - i g n i t i o n	
inition starts before opening of the gas valve.	
g n i t i o n	
he ignitor is igniting.	
o s t - p u r g e	
he fan is purging after burner is switched off.	
8 u r n i n g 1 0 0 %	
/hen the burner is firing, also the actual rpm% is shown.	

10.4 Monitor screens

During normal operation and stand-by, the $[\blacktriangleleft]$ and $[\blacktriangleright]$ buttons can be used to show some boiler information, including measured temperatures, settings and data. In the following graphs is explained which values can be shown in the display. When no button is activated for 2 minutes, the display will return to its status display.

Pressing [◀] or [▶] while being at the "operating screen" toggles through the screens below. When pressing [ON/OFF], [RESET], [ENTER] or [MENU] at any time the display returns to the base menu. SCREEN: 1 Т 1 F L ο w 1 2 3 9 ۰ С Measured value by the internal flow sensor. 2 R е t u 2 3 9 0 С Measured value by the internal return sensor. Т 1 r n 0 Shown when controller doesn't detect this sensor. р е n S h ο r t е d Shown when sensor wires or sensor itself is shorted. SCREEN: 2 0 Ε х 2 3 9 С Т 3 t 1 Measured value by the external sensor. е r n а I 2 0 Т 4 С а L ο r i. f i. 1 3 9 С Measured value by the calorifier sensor. 0 Shown when controller doesn't detect this sensor. р е n S ο r d Shown when sensor wires or sensor itself is shorted. h t е SCREEN: 3 Т 5 Ο u t d 1 2 3 9 ۰ С Measured value by the outdoor sensor. ο ο r 0 1 2 3 9 6 F Т u С Measured value by the flue gas sensor. Т е 0 р е n Shown when controller doesn't detect this sensor. S h 0 r t d Shown when the sensor wires or the sensor itself is е shorted. **SCREEN:** 4 Temp. difference between internal flow & return d T F o 2 ο wR t 1 3 9 С sensor. е u r n e R 2 o С Temp. difference between flue gas & internal return d T F L u е t u r n 1 3 9 sensor **SCREEN:** 5 Temp, difference between external & internal return d T E x t R t 2 3 9 ٥ С $(\Delta T LLH).$ е u r n 1 External supplied 0-10 Volt dc signal. S i I n а I Ρ w r g ο е "Power" = power input control or "Setpoi" = set point S е i. t р Ο control. SCREEN: 6 F s d 9 9 9 Actual fan speed in rpm. а n р е е 9 r р m F d n 0 % Actual fan speed % of maximum allowable fan speed. а n S е е р **SCREEN:** 7 F I. a m е s i 1 0 0 Α Flame signal given in µA. g n а I μ Wa t е Ρ r 0 b Shows water pressure when sensor is connected. r е s s u r а r SCREEN: 8 1 Pump 1 (HEATER PUMP) On or Off. Ρ 0 u m р н е а t е r f f Ρ 1 S i. 0 0 % Modulating signal Pump 1 in (%). u m a n а р SCREEN: 9 u m p Ρ 2 С L ο r i 0 f f Shows when the calorifier pump is "ON" or "OF". а Signal to the 3-way valve: "HEATING" or "HOT-3 -V а Т v е н е w а У а n a WATER" SCREEN: 10 Ρ 3 S t m Shows when the system pump is "ON" or "OF". u m р У S е Ο m D MM hh=hour; mm=minutes; DD=day; MM=month; D 1 1 Υ Υ h h : m Υ Υ D а у YYYY=yr; Day o/t week

SCREEN: 11																		
С	а	l	s	C		D	е	s	i	g	n				0			0 = MASTER, 1 11 = SLAVES
С	а	l	s		n	f			0	0 1 2 3 4 5 6 7 8 9 A B Displays number, priority and state of cascade boilers.								

DESCRIPTION "CASCINFO" Screen 11

Shows the number of boilers connected with the cascade. The Master/Lead boiler is designated as 0. Slave/Lag boilers will be designated 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B. When a "-" is used instead of a number, then that boiler is either not connected, or in a lockout mode and not available for the cascade. When an "x" is used instead of a number, then that boiler is connected, but in lockout mode.

When a "d" is displayed instead of a number, then that boiler is handling a DHW demand.

When the number is flashing, then that boiler is providing heat to the cascade. When the leading boiler is changed according to the set priority change time, then that boiler's address will be shown first in the row of numbers.

Example 1: "3 4 5 - - - - 0 1 2"

Six are boilers present and nr. 3 has priority.

Example 2: "3 4 x - - - - - d 1 2"

Six boilers are present and nr. 3 has priority. Boiler 0 is heating up an indirect DHW tank. Boiler 5 is present, but in a lock-out.

C a s c P o w e r 9 9 9 9 % % heat demand of total (cascade) power avail	
	ble (%).
ר D u a I B u r n e r : N o Heat exchanger equipped with two burners: "ע	es" or "No".

SCREEN: 13

	OUNCER. TO											_	-						
Μ	а	x		Т	h	е	r	m					Open S						Status of the maximum thermostat: "Open" or "Closed".
G	е	n		В	-	0	C	k					С	-	ο	s	е	d	Status of the general blocking contact: "Open" or "Closed".

SCREEN: 14

S	i	р	h	ο	n		р	r	е	s	s		С	Ι	0	s	е	d	Status of the siphon pressure switch: "Open" or "Closed".
Ν	R	۷		С	0	n	t	а	С	t			0	р	е	n			Status of the non-return valve contact: "Open" or "Closed".

10.5 Service function

The following graphs describe how to use the service function.

Н	Е	Α	Т	I	Ν	G	: N	0		d	е	m	а	n	d					
>	<	>	:	1	2	3	. 4	•	С	(1	2	3		4	0	С)		
-	Yress [SERVICE] and hold for 3 seconds.																			
Press [SERVICE] and hold for 3 seconds. The burner will start and show the display below.																				
The burner will start and show the display below. ◆																				
Эр	♦ Derating screen:																			
H	Ε	Α	Τ	I	Ν	G	: S	е	r	v	i	С	е			2	6	%		
>	۷	۷		9	0	•	0 °	С		(6	0	•	0	٥	С)		
60	 10,0°C": Max. allowable water temp. during service. 10,0°C": Max. allowable water temp. during service. 10,0°C": Actual measured water temp. (when P5BJ active). Press [SERVICE] to exit. The unit will go to the operate Press 3 s. [ON/OFF] to exit. The unit will be switched By using the [▲] & [▼] buttons the burner firing rate% changed. 															ed c	off.			
			cĥ	ang	jed.			-	-						r fir	ing	Tat	e%		
		→	Pre Pre Us	anç ess ess e [ged. [MI [MI	ENU ENU & [►] to] to] bu	acc retu tton	ess rn te	the o th	e ma le s ows	ain r ervi	ner ce i rou	nu. mei igh	nu. the	e m	oni	tor s	creens. ce mode.	

Maximum RPM table:

	$Model: \to$	S-CB ⁺ 60	S-CB * 80	S-CB [↑] 100	S-CB [↑] 120	S-CB [↑] 150	S-CB [⁺] 180
	Max. set point *	6500	6500	6500	6500	5700	5700
RPM	Max. actual**	6500	6500	6230	6095	5700	5700
	Margin on actual	± 50	± 50	± 175	± 175	± 50	± 50

* The maximum rpm that the controller is to use as a set point.

** The maximum rpm that the fan is actual able to run.

The maximum actual rpm may be lower than the maximum rpm set point. The fan may not be able to reach the maximum rpm set point, because of the unit's resistance, which is still correct according to the design of that specific unit. The relation between the maximum rpm set point and the maximum actual rpm is given in this table. This table applies also to the service and "Schornsteinfeger" function of the boiler.

10.6 Schornsteinfeger function

The following graphs describe how to use the Schornsteinfeger function.

NOTICE: This function is required for Germany and can be activated by parameter (P5 BK). The standard factory setting for this function is "OFF".

The purpose of this function is to have an easy interface for the "Schornsteinfegers" in Germany, to be able to do their required testing on the boiler. This is a simplified function similar to the normal service function of the boiler.

FI	u	е		s	е	r	v	i	С	е		m	0	d	е		
Ρo	w	е	r		:		Μ	i	n	i	m	u	m				
Wher the he In this	eate	r wi	ll fir	e a	t <u>50</u>)%	firir	<u>ng i</u>			ain:						
FI	u	е		s	е	r	v	i	С	е		m	0	d	е		
Ρo	w	е	r				5	0	%								
ΡO	w	е	r		:		Μ	а	x	i	m	u	m				
Wher	n the eate	bu rwi	ttor II re	etur	n tc	the	ed b e nc	rief	ly ag al o	gair per	n: atio	n m	ode				
the n The " NOT I																	

10.7 Programming in standby mode

Standby

Use the standby mode for modifying boiler settings without interaction with the boiler control. Changes are effectuated by leaving standby mode.

Properties of standby mode:

- •Keys are active and the menu is accessible.
- •Burner does NOT respond to an external heat demand.
- •All control functions are active: pumps, fans and cascade are operational, recirculation and frost protection are working.

How to programme the boiler:

- •First disconnect or shut down the room thermostat and/or other external controllers from the boiler. The CH pump and fan will stop after a short delay time.
- •Switch the boiler in standby mode by pressing [ON/OFF] for three seconds.
- •The next display screen should appear:

Display message	Н	Ε	Α	Т	I	Ν	G	:	b	ο	i	I	е	r		0	f	f		
	٨	٧	٨	••	1	2	3	-	4	0	С	(1	2	3	•	4	0	С)

• Program the boiler at the control panel (see the following sections).

- •Terminate programming mode by pressing [MENU], or [ENTER] and NO ◀ or YES ►.
- •Reactivate the boiler by pressing [ON/OFF] for three seconds again.

10.8 Setting the time & date

The following graphs describe how to programme the time and date of the unit.

Н	Ε	Α	Т	I	Ν	G	:	b	ο	i	Ι	е	r		0	f	f		
>	>	>	:	1	2	3	•	4	٥	С	(1	2	3	•	4	٥	С)
D	V	FN 4																	
PI		[M	EIN	υj															
Ma	ain	mei	nu :	scre	een	:													
Μ	а	i	n		Μ	е	n	u											
С	I	ο	с	k															
	¥																		
Τh	e d	ispl	ay	sho	ows	"CL	0	CK.	pre	ess	[E	NTE	R]						
80	▼	а т	im	2 21	- d F	Date													
Se	e	t	line	t				1	d	•	t	е		0	8	•	3	3	
-	-	-		•	1	m	e	-	-	а	-	-		U	0	-	3	3	
							0	1	0		Т	u	е						
3	0 ▼	1	0	3	/	2		-			-								
Th Us	▼ e d	ayi ▲]8	is n & [¶	ow 7] t	o cł	∠ nkin nang elec	g/s ge t	eleo he	cteo val	ue.	nd o	can		cha	nge	ed.			
Th Us Us Pre	▼ ed e[, e[ay i ▲]8 ◀] {	is n & [\ & [I	ow 7]t ▶]	o cł to s	nkin nanę	g/s ge t ct a	eleo he not	cteo val her	ue. val	nd o	can	be		0		nge	es a	Ire
Th Us Us Pre	● d e [e [● e ● ss ne.	ay i ▲]8 ◀] √	is n & [\ & [I	ow 7]t ►]	o cł to s	hkin hang elec the	g/s ge t ct a	eleo he not	cteo val her	ue. val	nd o	can	be		0		nge	es a	Ire
Th Us Us Pre	● d e [e [● e ● ss ne.	ay i ▲]8 ◀] √	is n & [\ & [I	ow 7]t ►]	o cł to s for	hkin hang elec the	g/s ge t ct a	eleo he not	cteo val her	ue. val	nd o	can	be		0		nge	es a	ire
Th Us Us Pro do	e d e [e [e [ess ne. vnfir	ay i ▲]8 ◀] √	is n & [\ & [I	ow 7] tr ►]	o ch to s for	hking nang elec the	g/s ge t ct a	eleo he not	cteo val her ma	ue. val	nd o	can	be		0		nge	es a	ire
Th Us Us Pro Co A < Pro	e d e [e [e [ess ne. ▼ ne. ▼ r C ess era	ay i ▲]& <] ([E1 ma e a [◀ [◀	is n & [1] NTE n] to g so	ow] ti ►] R] R] S C C C C	o ch to s for cree o e ance	hking elect the n: u	g/s ge t ct a co ; e cl	elec he not nfir	u val her u >	ue. val tion r C s m	e ade	rree n	be n af	i i ay ç	all r	cha m s ba	ack	to	-

10.9 Set points

The following graphs describe how to program the heating and hot water set points. NOTICE: The hot water set points are only displayed, when the boiler is programmed as an indirect hot water boiler or direct hot water boiler. See parameter P4 AA for the exact boiler configuration.

		<u> </u>	g so	ree		0	_						-			4	6						
-	E	A >	Т	1 1	N 2	G 3	:	b 4	0 °	i C	1	е 1	r 2	3	0	f 4	f °	С	`				
> ▼	>	/	•	l	2	5	•	4		C	l		2	3	•	4		C)				
Pre	ess	[M	EN	U]																			
•																							
		-		scre	en:		-													-			
M	a	i	n	-		e	n 1	u												-			
S ▼	е	t	р	0	i	n	t	S															
Se	lec	t "S	et p	ooir	nts"	usi	ng	[◀]	& [▶]	an	d p	ress	5 [E	NT	ER				1			
														-				h .			1	1	
													ving ng v										<u></u>
F		-		•	e ch			-	• 1	uie			ng v	vaiu	63			3010	50	ieu	301	ee	
									kit.	The	e ur	nit v	vill r	ese	et a	nd	retu	irn	to	the	ор	era	at-
			ing	g sc	ree	n.	-																
						NTE	R]	for	cor	nfirr	nat	ion	scr	een	wł	nen	all	the	С	han	ges	sa	re
			ma	ade	★																		
					Co	nfir	ma	tion	SC	ree	n:												
					Α	r	е		у	0	u		s	u	r	е							
					<		С	а	n	С	е		;		>		С	ο	n	f	i	r	m
							_	_					han										
					Pre	ess	[▶]	1 to	COI	nfirı	m tl	h	- I		~ 7	- ho	vol		00	ht in	the	· ~ ·	
1																							
					wh	en	pre	ssir	ng e	ente	er w	/ill b	be s	hov	vn f	for	a fe	w s	se	con			
					wh	en	pre	ssir	ng e	ente	er w	/ill b		hov	vn f	for	a fe	w s	se	con			
He	atir	ng s	set	poir	wh	en e dis	pre spla	ssir ıy re	ng e etur	ente ms	er w	/ill b	be s	hov	vn f	for	a fe	w s	se	con			
	atir e	ng s a	set t	poir i	wh the nt no n	en dis orm g	pre spla	ssir ıy re	ng e etur	ente ms	er w	/ill b	be s	hov	vn f	for	a fe	w s	se	con			
Η	е	a 8	t 0	i	wh the nt ne n	en dis orm g C	pre spla al/o	ssir y re day s	ng e etur tim e	ente ms ne: t	er w to t	/ill k	nor i	hov mal	vn f op t	for a	a fe ting	ws sc	se	con			
H Th	e e fl	a 8 ow	t 0 terr	i npe	wh the nt no n ratu	en dis orm g C	pre spla nal/o	ssir y re day s	ng e etur tim e	ente ms ne: t	er w to t	/ill k	oe s nor	hov mal	vn f op t	for a	a fe ting	ws sc	se	con			
H Th	e e fl	a 8 ow	t 0 terr	i npe	wh the nt ne n	en dis orm g C	pre spla nal/o	ssir y re day s	ng e etur tim e	ente ms ne: t	er w to t	/ill k	nor i	hov mal	vn f op t	for a	a fe ting	ws sc	se	con			
H Th prc	e flogra	a 8 ow amr	t 0 tem nec	i npe d Cl	wh the nt no n ratu	en orm g C ire s erio	pre spla al/o set ds.	ssir y re day s poir	tim e	ente ns ne: t hat	er w to t p wil	/ill k he o	nor i	hov mal	vn f op t du	for a era	a fe	ew s	se	con			
H Th prc	e flogra	a 8 ow amr	t 0 tem nec	i npe d Cl	wh the nt no n ratu	en orm g C ire s erio	pre spla al/o set ds.	ssir y re day s poir	tim e	ente ns ne: t hat	er w to t p wil	/ill k he o	i e act	hov mal	vn f op t du	for a era	a fe	ew s	se	con			
H Thi pro ▼ He	e flogra	a 8 ow amr	t o terr nec	i npe d Cl	wh the nt no n ratu H pe	en dis orm g C ire s erio	pre pla al/d set ds.	ssir y re day s poir	ng e etur tim e nt t	ne: t hat	p wil	vill t he o l be	i ay t	hov mal	vn f op t du	for a era	a fe	ew s	se	con			
H Th pro ▼ He C	e fl ogra atir H	a 8 ow amr	t terr nec nigh N 0	i npe d Cl nt sł	wh the nt no ratu H pe nift I g	en dis orm g C erio rela h C	pre pla al/c set ds. ted	ssirreday day point	ng e etur tim e nt t the s	nterns ne: t hat	p wil	vill t he o i be al/d f	i ay t	hov mal tive	vn f op t du	for a era	a fe	e		con			
H Thi pro ▼ He C	e fl ogra atir H e re	amr ow amr ng r 1 edu	terr nec nigh N o utsi	i npe d Cl i t sh i on o	wh the nt no ratu H pe nift 1 g f the	en i orm g C ire s erio rela h C e no	pre pla al/d set ds. ted	day bay bay boin to t	ng e etur tim e nt t the s	ente rns ne: t hat no h	p will rma	vill t he o l be al/d f	i ay t t	hov mal tive	vn f op t du	for a era	a fe	e		con			
H Thi pro ▼ He C	e fl ogra atir H e re	amr ow amr ng r 1 edu	terr nec nigh N 0 ctio	i npe d Cl i t sh i on o	wh the nt no ratu H pe nift 1 g f the	en i orm g C ire s erio rela h C e no	pre pla al/d set ds. ted	day bay bay boin to t	ng e etur tim e nt t the s	ente rns ne: t hat no h	p will rma	vill t he o l be al/d f	i ay t t	hov mal tive	vn f op t du	for a era	a fe	e		con			
H Thi Pro ▼ He C Thi is u Pa	e flo ogra atir H e re use ran	a 8 ow amr ng r 1 edu d o nete	t o terr nec nigh N o ctio utsi er P	i npe d Cl d Cl i t sh i i de 26 E	wh the nt no ratu H pe nift I g of the BB.	en e dis orrm g C erio rela h C e no pro	pre pla al/d set ds. ted	day bay bay boin to t	ng e etur tim e nt t the s	ente rns ne: t hat no h	p will rma	vill t he o l be al/d f	i ay t t	hov mal tive	vn f op t du	for a era	a fe	e		con			
H Thi pro ▼ He C Thi is u Pa He	e fl ogra atir H - use ran atir	a 8 ow amr ng r 1 edu d o nete	t o terr mec nigh N o ctio utsi er P oara	i npe d Cl d Cl i t sh i i de 26 E	wh the nt no ratu ratu f the 3B.	en e dis orm g C irre s erio rela h C pro	pre pla al/d set ds. ted	ssir y re day s poin to t nal/c	ng e etur tim e nt ti s day nec	ente rns ne: t hat no h tim t Cl	p will rma	vill h he o l be al/d f eric	i ay t t	n ime itive	vn f op t du se	for a era	a fe	e		con			
H Thi Pro ▼ He C Thi is u Pa	e flo ogra atir H e re use ran	a 8 ow amr ng r 1 edu d o nete	t o terr mec nigh N 0 ctio utsi er P oara t	i npe d Cl d Cl i t sh i i de 26 E	wh the nt no ratu H pe nift I g of the BB.	en e dis orm g C rela h C e no pro	pre pla al/d set ds. ted	day bay bay boin to t	ng e etur tim e nt t the s	ente rns ne: t hat no h	p will rma	vill t he o l be al/d f	i ay t t	hov mal tive	vn f op t du	for a era	a fe	e		con			
H Thi Pro He C Thi is u Pa He He	e fl ogra atir H e re use ran atir e	a 8 ow amr ng r 1 edu d o nete	t o terr mec nigh N o ctio utsi er P oara t 5	i npe d Cl d Cl i d Cl d f d e d f e d e d e d e d e d e d e d	wh the nt no ratu d pe of the BB.	en orrm g C C e no pro ft: g C	al/o	ssir day s poin to t al/c	tim e tim the s day nec	enterns ne: t hat no h tim I Ch	p will rma i H po	vill he	i ay t t h	hovmal	t du se his	for a era	a fe ting the pint	ew sc g sc e		con			
H Thiorov He C This u Pa He He Se	e floogra atir H e re use ran atir e	a ow amr ng r 1 edu d o nete	t terr meconigh N 0 ctio utsi er P bara t 5 ne p	i npe d Cl i t sl i i de p6 E allel i para	wh the nt no ratu H pe nift I g o f the BB.	en dis orrm g C C rela h C e no pro	prespla al/d set ds. ted t gra	ssir day s poin to t nal/c amn	tim e tim the s day nec	enterns ne: t hat no h tim t Cl r eati	p will rma i ne s H p	vill I he o I be al/d f eric set eric	i ay t t	n iime tive	t du se his	for a era	a fe ting the pint	ew sc g sc e		con			

Dŀ	łW	set	ро	int ı	nor	ma	l/da	ay ti	ime): (p	bara	am	ete	er P	4 /	٩A	= 1	/2)	
D	Н	W		s	е	t	р	ο	i	n	t								
		6	0		0	С													
					uυ	ЯΝ	יע י	CIIC	Jus	(pc	aiai	1101		• •	1 11	· —	1/2	J.	
▼ DI		Ŭ															1/2	<i>)</i> .	
_	IW	set		int ı	red	ucti	on	: (p	ara								1/2).	
♥ Dł D		Ŭ			red		on	: (p).	

10.10 Setting the timer programs

Three different programs can be set with the boiler, these are:
CH program
DHW program
Anti-Legionnaires' disease (pasteurisation) program

HEATING PROGRAM

Three programmed periods each day can be set (period 1, period 2 and period 3). During these periods the unit will use the normal CH and DHW set points. Outside the programmed period(s) the unit will use the reduced temperature as set point. When no time is programmed for a period, it will not be used. (Example: no time programmed in period 3 on Monday > "**Mon 3 -:---**").

Operating screen: H E A T I N G 1 b Ο i. L е r 0 f f ۷ > : 1 2 3 4 0 С 1 23. 4 0 С > Press [MENU] Select "Timer" using [◀] & [▶] and press [ENTER] Main menu screen: M a i n M e n u imer Т Press [ENTER] Setting CH program times: P r o g r a m СН : 2 ο n 0 6 0 0 3 Μ 1 ÷ 0 0 Press [▶] to browse through the values that can be set at the bottom line. The blinking value can be changed. Press [▲] & [▼] to change the selected (blinking) value Press [ENTER] for confirmation screen when all settings are done. Confirmation screen: A r е y o u s u r e Cancel; C o n f i < > r m Press [◀] to cancel the changes made (unit will reset). Press [▶] to confirm the changes. The last alternation will be blinking for a few seconds and return to base menu. Press [MENU] to exit. The boiler will reset and go to the operating screen. Press [] for next SCREEN Copy programmed day for CH: С 0 ру from: CH M o n СН С : 0 p y t o T u e Press [▶] to switch between "Copy from" and "Copy to". The blinking day is selected and can be changed. Press [A] & [V] to change the selected (blinking) value. Press [ENTER] for confirmation screen when all settings are done. Confirmation screen: Ar е y o u s u r e c e I ; C o n f i r m Can > < Press [] to cancel the changes made (unit will reset). Press [>] to confirm the changes. The two days will blink for a moment. Press [MENU] to exit. The boiler will reset and go to the operating screen. Press []] for next SCREEN > > Continue on next page HOT WATER program < < <

HOT WATER PROGRAM



ANTI LEGIONNAIRES' DISEASE PROGRAM

The anti-Legionnaires' disease (pasteurisation) program of the boiler can only be used when the boiler is set as an "indirect" boiler configuration or a "direct" hot water boiler configuration. Only these configurations can activate the day and time program of the anti-Legionnaires' disease function. See the following graphs. The standard factory setting for this function is "OFF".



10.11 Setting the outdoor specifications

PARAMETERS FOR SETTING THE OUTDOOR GRAPH

When using this function the flow temperature is calculated based on the measured outdoor temperature. The relation between the outdoor temperature and the flow temperature can be programmed with the following parameters. This setting creates the so called "heating curve".

The boiler will recognise an outdoor sensor when it is connected. When the sensor is detected the boiler controller will control the flow temperature based on the heating curve that is programmed.

OUTDOOR GRAPH (see also next page)



P5 AC Heat curve minimum outdoor temperature (°C)

This sets the minimum outdoor temperature at which one wants the maximum flow temperature that is set.

P5 AD Heat curve flow temperature at minimum (°C)

This sets the desired maximum flow temperature at the set minimum outdoor temperature.

P5 AE Heat curve maximum outdoor temperature (°C)

This sets the maximum outdoor temperature at which one wants the minimum flow temperature that is set.

P5 AF Heat curve flow temperature at maximum (°C)

This sets the desired minimum flow temperature at the set maximum outdoor temperature.

P6 BC Heat curve parallel shift (°C)

The heating curve is set by the parameters. Next to these setting done by the installer, the end user has the freedom to influence the flow temperature by doing a parallel shift setting. In this parameter the margins are set within which the user can increase and decrease the calculated flow temperature relative to the calculated flow temperature by the heating curve that is set.

The actual parallel shift that is set by the user within the bandwidth allowed according to "P5 AQ Max heat curve parallel shift".

Additional settings of the heating curve p.t.o. \rightarrow



P5 AG Heat curve minimum flow temperature (°C)

The set point will never be lower than the flow temperature set in parameter P5AG. The minimum temperature is limited, even if the calculated set temperature, according to the heating curve, would be lower.

P5 AH Summer outdoor temperature central heating (°C)

If the outdoor temperature is higher than set in P5AH the heat demand for heating will be blocked.

P5AR Outdoor sensor 10K or 12K resistance (1 or 0)

Depending to the used type of sensor this parameter can be set. Set to '0' when using a so called 12k NTC sensor (sensor resistance is 12 k ohm at 25°C) Set to '1' when using a so called 10k NTC sensor (sensor resistance is 10 k ohm at 25°C) Default the parameter = 0, so the used sensor is assumed to be 12 k Ω .

P2 HA Outdoor sensor hysteresis (°C)

If the outdoor temperature reaches the temperature set in P5 AH (warm weather shutdown) the unit won't start for heating. If the measured outdoor temperature drops P5 AH minus P2 HA the boiler can start up for heating again.

P6 BA CH user setting (°C)

The set point will never be higher than the flow temperature set in parameter P6BA. The maximum temperature is limited, even if the calculated set temperature, according to the heating curve, would be higher.

P6 BB Heat curve night shift (°C)

The temperature reduction during the night, relative to the setting determined by the heat curve

DISPLAY

The following graphs describe how to program the outdoor graph settings.

		<i>.</i>																		1		
Op(ting A		ree	n: N	G		b	0	i	I	е	r		0	f	f					
	>		:	1	2	3		4	•	C	(2	3		4	•	С)			
Pre	ess	[M]	EN	JJ									-			•		-]		
					." us	sina	[◄	1&	[▶]	l an	d p	res	s íE	NT	ER1					,]		
Ма								1	<u>.</u>		- 1		- [-							1		
Μ	a	i	n		M		n	u														
0	u	t	d	0	0	r																
														een							ow	
·														e in nd g							ree	en.
ľ														er a								
				Co	onfir	mat	tion	scr	eer	ו:												
				Α	r	e		у	0	u		S	u	r	е							
				< Pre	ess	C [◀]	a l to	n car	cel	the	e ch	; and	ies	> ma	de (C unit	o wil	n I re	f seť).	r	m
				Pre	ess	[►]] to	cor	nfirn	n th	e c	han	ges	s ma	ade.	Th	e tii	ne	anc	d da		
								for scre			sec	onc	ls. /	Afte	r thi	s, tł	ne c	lisp	lay	ret	urn	s to
	0	1	•		•	0	u	t	s	i	d	Ρ	r	е	S					1	Р	5 AA
	-					_					0			_								-
	0	2				Η	С	m	i	n	0	u	Т	m	р					1	Р	5 AC
									-	1	5		0	С								
	0	3				Η	С	m	i	n	F	Ι	Т	m	р						Ρ	5 AD
										8	5		٥	С								
	0	4				Η	С	m	а	X		u	Τ	m	р						Ρ	5 AE
						-				2	0		•	С								
	0	5				Н	С	m	а	x 2	F	I	T	m	р						Ρ	5 AF
				r			r			2	0			С] 1		
	0	6				Н	С	m	i	n 2	F 0		L °	i C	m						P	5 AG
		_									_									1 1		
	0	7				S	u	m	S	h 3	D 0	w	n °	0 C	u						Ρ	5 AH
	0	0								-	-									1]	–	<u> </u>
	0	8				н	С	m	а	x 8	F 5		• •	i C	m						<u>Р</u>	6 BA
						н	С	n	0	h	t	s	h	f	t]	P	6 BB
	0	Q					-		g -	1	ι 0	3	•	C							L,	
	0	9									•											
		_				н	C	р	1			S	h	f	t					,]	Р	6 BC
	0	9 A				Н	С	р	a	r	a 5	S	h °	f C	t						Ρ	6 BC
		_				H	C	p t	1		а	s k			t k							6 BC 5 AR

10.12 Checking the operating history

The following graphs describe how to check the operating history of the boiler.

	٨	>	•••	1	2	3		4	٥	С	(1	2	3		4	0	С)
Pro	255	[M	FN	U1		-		-	-	-	-		-	-	-	-	-	-	-
		-					-												
Se	lec	t "C	pe	rate	e" u	sıng	[•	٥ [Þ	k [▶	▶] a	nd p	ores	s [E	=N I	EF	۲]			
			าน ร	scre	een														
M	-	i	n			е	n	u											
0	р	е	r	а	t	е													
											the								
		-		-	-	ENT	ΈF	R] to) e>	kit. T	The	uni	t wi	ll re	tur	n to	b th	е	
		ting		ree	en.														
		EN	: 1			-				-	-								
0 P		e	r	a	t	i	n	g	h	h	i	S	t	0 1	r 3	y 1	4	0	0
•	o n li	W	e Sh	r	0 s th	n P or)er	atin	h h	r isto	ry n	hen	u ie	•	-	1	•	0	0
									-		s co							upr	olv
		witc									_ 00				- P'		_ 0		y
sc		EN	• 2																
h	r	s	-	h		ſ	Т	0	t	ſ			1	0	0	0	0	0	0
h	r	s			w		T	0	t				1	0	0	0	0	0	0
То	p li	ne:	Tot	tal I	ouri	hing	hc	ours	fo	r he	atin	g.		_					
											doı		stic	hot	wa	ter			
SC	RE	EN	: 3																
h	r	S	С	h				<	5	0	%		1	0	0	0	0	0	0
h	r	s	С	h			=	>	5	0	%		1	0	0	0	0	0	0
	-				ng h	our	s fo	or h	eat	ing	whi	le tl	ne k	ourr	ner	wa	s fi	ring	I
IPS		nan m li			rnir	na h	0111	's fa	or h	eat	ina	whi	le th	ne h	nir	her	wa	\$	
						er tl				icut	ing	••••			Jun		wa	0	
Во																			-
Bo firi	RF															_		0	0
Bo firi <mark>SC</mark>	RE			h	w		<	5	0	%			1	0	0	0	0		—
Bo firi <mark>SC</mark>				h h	w w	=	<	5 5	0	% %		:	1 1	0 0	0 0	0	0 0	0	0
Bo firi SC h h To	r r pli	s s ne:	D D Bu	h rnir	w	=	< > s fo	-	-		er w	: : hile	1 1 the	0 0 bu	0 0	0 0 er w	-	0 firii	0 ng
Bo firi SC h h To les	r pli sth	s s ne: nan	D D Bu 50	h rnir %.	w ng h	= iour		or h	ot v	wate							/as		-
Bo firi SC h h To les Bo	r r p lin s th	s s ne: nan m li	D D 50 ne:	h rnir %. Bu	w ng h rnir	e iour	oui	or h	ot v or h	wate	er w vate						/as		-
Bo firi SC h To les Bo firi	r plin sth ttor	s ne: nan n lii equ	D D Bui 50 ne: al c	h rnir %. Bu	w ng h rnir	= iour	oui	or h	ot v or h	wate							/as		-
Bo firi SC h To les Bo firi SC	r plin sth ttor	s ne: nan n lii equ	D Bui 50 ne: al c	h rnir %. Bu or h	w ng h rnir igh	er tl	oui nar	or h rs fo n 50	ot v or h)%.	wate	vate			the	e bı	urne	vas er v	vas	
Bo firi SC h To les Bo firi SC T	r p lin s th ttor ng c	s ne: nan n lii equ	D Bui 50 ne: al c : 5	h rnir %. Bu or h	w ng h rnir igh 0	er tl	oui nar 0	or h rs fo 50	ot v or h)%.	wate not v	vate a			the 1	e bu	urne 0	vas er v	vas 0	0
Bo firi SC h h To les Bo firi SC T S	r p lin s th ttor ng o RE i s	s ne: nan n lii equ EN a I	D Bui 50 ne: al c 1 1	h rnir %. Bu or h 0 0	w ng h rnir igh 0 0	er tl	oui nar 0 0	or h rs fo 50 0	ot v or h)%.	wate ot v	vate	er W	hile	the 1	e bu 0 0	urne 0 0	vas er v	vas 0 0	0

10.13 Checking the fault history

The following graphs describe how to check the fault history of the boiler.

Η	Е	Α	Т	I		G	:	b	0	i	Ι	е	r		0	f	f		
>	>	>	:	1	2	3	•	4	٥	С	(1	2	3	•	4	٥	С)
Pr	ess	5 [M	IEN	IU]															
_		-	-	-					0.5							-			
Se F			au		st" h	usir i		-	& [►]a	and	pre	ess	[EN	N	_		0	1
<u>г</u> 2	a 1	u /	і 0	t 4	n 7	ו 2	s 0	t 1	0	w	е	d		2	1N 2	0 :	2	0 3	ı A
2	•	'	U	-	'			-	-	alte	-			_	2	•	2	5	~
S	i	р	h	0	n		S		i	t	C	h							
S	v	9	9	9	1	С	U	М	9	9	9	1	R	9	9	9	9	,	5
Pr	ess	5[◀	1] &	.[>	1 to	o br	ow	se t	hro	ugh	the	e la	st te	en fa	ault	s.			
		5 [M	-	-	-														
• •									υе	xit.	The	e un	nt w	ill re	etui	n to	o th	ne	
		ting	g so	cree	en.			-											
Th dis lin lin Or Th S las	ne fa spla e o cur n th ne b	ault ay b f th f th rred ootto The me	g so i me olink e to e to l. op l om tota	creation enuties to pp s pp s line line	en. I sh betv scre scre of e sh	the now	s th n tr sho sho bot	this	ist f wo the the ollo	xit. ten f scree fai e da cree wing ult th y wa	faul een ult r ite, n th g:	ts. s sł num day ne fa	For how ber ault	ead n a d tii typ	ch f bov d th me e is	aul ve. the the aft	t th The pott fa spla	e om ult aye	d.

10.14 Setting the maintenance specifications

The following graphs describe how to check and program the maintenance settings. The standard factory setting for this function is "OFF".

MAINTENANCE SETTINGS

The unit can be programmed in such a way that an automatic maintenance message is displayed.

- There are three options that can be selected. A maintenance message appears after:
- * A programmed date is reached.
- * An amount of burning hours is reached.
- * An amount of ignition cycles is reached.

One single option can be activated or all three options.







BE AWARE: This function is standard turned OFF. We offer this programmable function to the installer to use as a reminder. Because it concerns a free programmable function, the application of it cannot be used as an argument in warranty cases.

Our units must be maintained every twelve months whatever the settings/working of this function.

It is and remains the responsibility of the end user to have the unit maintained every twelve months.

10.15 Setting the user lock

The following graphs describe how to activate the user lock of the display. The standard factory setting for this function is "OFF".

0 = 0 1 = L	s me NLO OCł	C	<e[< th=""><th></th><th>oilei</th><th>r ca</th><th>in b</th><th>e lo</th><th>ock</th><th>ed</th><th>for</th><th>(end</th><th>d-)u</th><th>ISEI</th><th>ſS.</th><th></th><th></th><th></th></e[<>		oilei	r ca	in b	e lo	ock	ed	for	(end	d-)u	ISEI	ſS.			
Wher press																	Ub	y
Wher buttor scree	n to																	u
This f														ess	ible	Э.		
Opera H E > >		-	ree I 1	en: N 2	G 3	:	N 4	0 °	С	d (е 1	m 2	a 3	n	d 4	0	С)
Press	s [M	ΕN	U]															
Selec	t "U	ser	loc	ck"	usiı	ng [[◀]	&	[▶]	an	d pi	ress	s [E	NT	ER]		
User	lock	sc	ree	n:														
S e	t	0	U	S	е	r	Ι	0	С	k	=	0					_	
The " Use [0 = U 1 = U	▲] ser	& [` loc	▼]t k fu	io c Incl	har tion	ige OF	the F				an	be	cha	nge	∋d.			
Use [0 = U	▲] ser ser ser	& [` loc loc NTE	▼] t k fu k fu ER]	to c inct inct for	har tion tion	nge OF ON	the FF N	e va	alue							elec	ctior)
Use [0 = U 1 = U Press	▲] ser ser s [El	& [' loc loc NTE ma	▼] t k fu k fu ER] ade	inci inci inci for	tion tion tion	nge OF ON	the FF N	e va	alue							elec	ctior)
Use [0 = U 1 = U Press has b	▲] ser ser [El een rma	& [' loc loc NTE ma	▼] t k fu k fu ER] ade n sc y	inct inct for cree	tion tion the the en:		the FF N	e va	alue		cree	en a	fter	the	e se)
Use [0 = U 1 = U Press has b Confi A r	ser ser [El rma e C	& [V loc loc NTE ma tior	▼] t k fu k fu ER] ade n so y n	incl incl for c	tion tion the en: u		the FF onfin	e va rma	ation r	e. n so e	cree	en a	fter n	the f	e se	r	m)
Use [0 = U 1 = U Press has b Confi	ser ser [El een rma e C	& [\ loc loc NTE ma tior a] to	▼] t k fu k fu ER] ade n so y n ca	to c incl incl for for c c	tion tion the the en: u el th		the F N onfin s ;	rma u nge	ation r > s (t	e. n so e he	cree C unit	en a	fter n	the f	e se	r	m	
Use [0 = U 1 = U Press has b Confi A r < Press	▲] Ser	& [' loc loc NTE ma tior a] to or a	▼] 1 k fu k fu k fu R] ade n sc y n ca fe	to c incl incl for for c c c c c c nce to t nfir w s	tion tion tion the en: u e el th he m t	I e c	the F N onfin ; har erat cha	e va rma nge ing	ation r s (t scr es.	e n so e he reer Tho	cree C unii ח).	en a o t wil	fter n I re	the f	e se i an	r d th	m ne	
Use [0 = U 1 = U Press has b Confi A r < Press displa Press blinki opera NOTI	▲] Ser	& [' loc loc NTE ma tior a] to etur] to or a j sc	▼] 1 k fu k fu R] ade n sc n n ca ns co a fe ree	to c incl incl for c c c c c c c c c c c c c c c c	tion tion the en: u e the the the the the the the the the the	I e co	the F N onfin s har erat cha s. A	e va rma u ing ango Afte	ation r ss (t scr es. r th	e n so e he eer Tho is, f	cree C unit ח). e ch	en a o t wil disj	fter n I re ged	the f va	e se i an lue	r d th wil	m ne I be o th	
Use [0 = U 1 = U Press has b Confi A r < Press displa Press blinki opera	A] d ser ser s [El been rma e C c c c c c c c c c c c c c c c c c c	& [` loc loc loc NTE ma tior a] to etur] to or a g sc e [N	▼] 1 k fu k fu k fu k fu c R] ade n sc v n c a fe ree	to c incl incl for c c c c c c c nce to t nfir w s n.	tion tion the en: u e el th he m t secc	I Cope be co ope be co ope tond	the F N onfin s har cha s. A du	rma rma ing ango Afte	ation r s (t s cr es. r th	e he reer The is, f	C C unit n). e ch the	en a o t will disj	fter n I re ged olay	f va re	e se i an lue turr	r d th wil	m ne I be o th	

10.16 Setting the parameters at the control panel

The functions of the controller are embedded in de electronics by means of parameters. The values and settings hereof can be programmed by a skilled and trained service engineer with the help of a computer (laptop), the correct software and an interface cable. A selection of these parameters can be programmed at the control panel of the unit itself, without the use of a computer.

The following table gives a list of these last mentioned parameters. NOTICE: Only the password for level 1 is issued in this manual. "More advanced" parameters need to be programmed by a skilled and trained service engineer with access to level 2.

				When 'Modify = no', the parameter can only be pro-	arammo	h ai			2							PASSWORD:
				when mouny – no, the parameter can only be pro-	granne	u a	lie	vei	2							1342
ME	NU		PARA- METER	DESCRIPTION	UNITS			Т	EX.	ΤD	ISF	۲LA	Y			LEVEL 1 Modify
		1	P5BE	Step modulation (1=on 0=off)	-	S	t	е	р		m	0	d	u	I	no
		2	P5AO	Blocking offset flow temperature control	°C	Н	Ε		S		0	f	f	1	3	yes
		3	P5AP	Proportional range temperature control	°C	Н	Ε		s		Ρ	r	b	1	3	no
NG		4	P5AL	Hysteresis CH Flow temperature control	°C	Н	Ε		s	С	D	i	f	1	3	yes
HEATING	Α	5	P2IC	Integration time temperature control	S	Н	Ε		s		I	n	t	1	3	no
IE/		6	P2MI	Blocking offset System CH temperature control	°C	Н	Ε			С	0	f	f		3	yes
-		7	P2MJ	Proportional range System CH temperature control	°C	Н	Ε			С	Ρ	r	b		3	no
		8	P2MK	Integration time CH temperature control	S	Η	Ε			С	Ι	n	t		3	no
		9	P5AB	Timer Contact (1=on)	-	Т	i	m	е	r	С	0	n	t		yes
		1	P4AB	DHW Pump Config 0=Pump 1=TWV	-	D	Н	i	р	m	р	1	t	w	v	yes
		2	P5CB	Flow temperature DHW tank low	°C	D	н	i	f	Ι	0	w		L	0	yes
		3	P5CK	Flow temperature DHW tank hi	°C	D	н	i	f	T	ο	w		н	Т	yes
		4	P5CL	Low Flow temperature time DHW	min	D	н	i		L	0	t	i	m	е	yes
		5	P5CD	Legionella temperature	°C	L	е	g	i	ο		t	е	m		no
		6	P5CI	Legionella hyst DHW tank temperature	°C	L	е	g	i	0		h	У	s	t	no
		7	P5CJ	Legionella hold time (0=off)	min	L	е	g	i	0		h	0	I	d	no
×	-	8	P2KI	CH interrupt by Legionella (0=yes)(1=no)	-	L	е	g	i	0		i	n	t	r	no
DHW	в	9	P2LC	Regulation temperature offset DHWd	°C	D	Н		s	С	0	f	f	2		yes
		Α	P2MN	Proportional range DHWd modulation	°C	D	Н	d	s	С	Ρ	r	b	2	3	no
		В	P2LD	Regulation temperature hysteresis DHWd	°C	D	Н	d	s	С	D	i	f	2		yes
		С	P2MO	integration time DHWd modulation	S	D	Н	d	s	С	I	n	t	2	3	no
		D	P2ML	Sys temp blocking offset DHW tank	°C	D	Н	d	s	С	0	f	f	3		yes
		Ε	P2MM	Sys temp blocking hysteresis DHW tank	°C	D	Н	d	s	С	D	i	f	3		yes
		F	P5CA	Hysteresis DHW tank temperature	°C	D	Η	i	s	С	D	i	f	4		yes
		G	P2KH	Gradient heat demand detect DHW tank temperature	°C	D	Η	i	d	е	t	g	r	а	d	yes
		1	P2MA	Max number extra boilers	-	Μ	а	X	С	а	s	С	U	n	t	no
ш		2	P5DA	Bus address boiler	-	В	u	s		а	d	r	е	s	s	no
DI		3	P5DC	Dhw on entire cascade(0) only master(1)	-	D	Н	i	С	а	s	1	m	а	s	no
CASCADE	С	4	P5DE	Extra Boiler output enable(1)	-	Ε	х	t	r	а		u	n	i	t	yes
AS		5	P5DF	Cascade detection (0=standalone 1=Leader)	-	С	а	s		S	i	1	Μ	а		no
0		6	P5BL	Power off total cascade (1)	-	Ρ	w	r	0	f	f	Н	0	С	а	no
		7	P5DB	Number of boilers with common flue 0=None	-	С	0	m	F	Ι	u	Ν	u	m		no
		1	P5BB	Analogue input Config (0=off 1=temp 2=power)	-	Α	n		Ι	n	р		С	0	n	yes
		2	P5AI	Minimum Temperature 0-10V input	°C	0	-	1	0	Μ		n	Т	m	р	yes
		3	P5BI	Altitude (in amounts of 100 ft.)	100 ft	Α	I	t		*	1	0	0	f	t	yes
٩L		4	P2LK	Max cooling time	min	Μ	а	X	С	0	0	-	Т	i	m	yes
GENERAL		5	P5BJ	Temperature display 1=on	-	Т		m		0	n	D	i	s	р	yes
NE	D	6	P4AA	DHW 0=off 1=Indirect 2=Direct	-	D		W		1	=	ï	2	=	d	no
GE		7	P4AD	pressure 0=off 1=sensor and 2=switch	-	С	ο	n	f	i	g					no
		8	P4BD	Gas type values 0-2	-	g	а	S	t	у	р	е				no
		9	P4BE	Soft start type values 0-2	-	С		n	f	i	g					no
		Α	P5BN	Pump modes 0-3	-	С	0	n	f	i	g					no

For extensive explanation see Ch. 11: 'Controlling options and settings', page 78 ff.

IMPORTANT: Do not change the parameters P2LC, P2LD, P2ML, P2MM and P5BI; they are present in the controller for different purposes than CH control. <u>Changing these parameters may affect boiler operation negatively.</u>

Parameter screens + concise explanation see next pages \rightarrow

_								_	_		_			_		_			
Pr	ess	5 [M	EN	U]															
Se	elec	:t "F	Para	ame	eter	" นร	sing][<	€] 8	k [▶) a	nd p	ores	ss [[ΞN	ΓEF	[א		
Pa	arar	net	er r	ner	าน:														
I	n	S	t	а	Ι	Ι	е	r		С	0	d	е						
								0	0 ▼	0 ▼	0								
bu Th th	uttor ne c <u>e fo</u> OTI	ns a ode llov CE:	and e w ving : Tl	se ill b g pa nes	lect link arai	t [El c a t met code	NT few ers	ER] se wil are	cor II be us	nds <u>e di</u> er l	■] 8 and spla base	l wł iyec ed a	nen d. and	ent giv	ere ve a	ed c	or es	rect	tly,
	elec alle					of	par	am	ete	rs,	whi	ch	can	be	e ch	nan	ge	d (In-
M	enu	A:	He	atir	ng														
	Α	1				S	t	е	р		m	0	d	u	I				
г.	Inot	lan	to	o ot	i voi			tor		o du	1 Jati								
	- ()	n																	
	= O enu	A:	He	atir	ng		F		6		0	f	f	1	2				
M	enu A	A: 2					E re s	sett	s ing.	. Th	o 4 nis p	f	f °	1 C	3 is tl	ne	off:	set	of
M Cl th	enu A	A: 2 Jpp rogr	ly te am	em	per ed C	atu	re s terr		ing.	ire.	4 nis p P		° ime b	C ter		ne	offs	set	of
M Cl th	enu A H su e pr	A: 2 Jpp ogr	ly te am	em	per ed C	atu CH 1	re s terr		ing. ratu		4 nis p		° ime	С	is tl	ne	offs	set	of
Mi Cl th Mi Se th	enu A H si e pi enu A elec e pi	A: 2 Jupp ogr A: 3	ly to ram He ne (em atir CH	per ed (ng su	atu CH t H	re s terr E	mper	ing. ratu s	ure. 2	4 nis p P	ara r	o ime b ol.	C ter 1 C This	3	ara	me	eter	is
Mi Cl th Mi Se th	enu A H su e pr enu A elec e pr	A: 2 Jupp ogr A: 3	ly to ram He ne (em atir CH	per ed (ng su	atu CH t H	re s terr E	mper	ing. ratu s	ure. 2	4 nis p P 5 e co	ara r	• me • ol. I su	C ter This pply	3	ara	me	eter	is
CI the M	enu A H su e pr enu A elec e pr enu A	A: Jpp rogr A: 3 et th ropo	He He	em ime atir CH ona	per ed (ng su il ra	H	re s terr E y te e of	emper the	ing. ratu sera e se	2 atur elec 1	4 nis p P 5 e cc tted D 0	r ontr CH	° me ⁰ ol. I su f	C ter This pply	3 3 7 7 8 9 7 1 8	ara		eter atur	is
M CI th M Se th	enu A H su e pr enu A enu A enu	A: Jpp ogr A: 3 A: A: A: 4 t th	Iy to ram He ortio	em ime atir CH chatir	per ed (ng su il ra	H Ppply	E terr terr E terr	emper the	ing. ratu s erat s erat	2 tture c 1 ure	4 nis p P 5 e cc tted	r para para pontr CH	● me ol. I su I. TI	C ter This pply	3 3 y te 3	ara	me	eter atur	is
CI the M Set is	enu A enu A enu A enu A elec the	A: Jpp ogr A: 3 A: 4 A: 4 A: 4	He He He Cortic	em atir CH chatir	per ed (ng su il ra	H Ppply f th	E terr terr E ter e so	emper the	ing. ratu s erat s erat	2 tture c 1 ure	4 iis p 5 e cc tted 0 cor	r para para pontr CH	● me ol. I su I. TI	C ter 1 C This pply	3 3 3 y te 3 oara	ara	me	eter atur	is
CI the M Set is	enu H su e pr enu A elec the	A: 2 Jpp ogr A: 3 A: 4 A: 4	He He He Cortic	em atir CH chatir	per ed (ng su il ra	H Ppply	E terr terr E terr	emper the	ing. ratu s erat s erat	re. 2 tture elec c 1 ure d C	4 his p P 5 e cc tted D 0 cor H su	r para para pontr CH	 me b ol. l su f n I t 	C ter 1 C This pply 1 C	3 3 3 3 3 0 2 3	ara	me	eter atur	is
M Cl th M Set is M	enu H su e pr enu A elec e pr enu A	A: 2 Jpp ogr A: 3 A: 4 A: 5 5	He He He He He He	atir CH CH atir atir atir	per ed (ng su il ra su su g	H Poply f th	E E E E E E E		s s s s s s s s s s s	2 atur elec d d C d C	4 his p P 5 e cc tted 0 cor H su I 0	r para pontr CH i ntro upp	 me b ol. l su f l. Tl ly te t S 	C ter 1 C This pply 1 C nis emp	3 3 3 3 7 7 8 9 7 7 8 9 9 9 9 9 9 9 9 9 9 9 9 9	ara mp am	ete	eter atur	e.
Mi Cl th Mi Seth Seth Seth	enu A enu A enu A enu A enu A enu A	A: A: A: A: A: A: A: Copies A: A: A: A: A: A: A: A: A: A:	He e Cortio	em atir CH ch atir cesi atir CH ch ch	per ed (ng su ll ra ng su ng su ng su ra	H H H Pply f th Pply	E E E E E E		s s s s s s s s erat cteo	c 1 ure d C 6	4 his p P 5 e cc tted D 0 cor H su	r para r pontr CH i n tro upp	 me b ol. f ol. t S ol. 	C ter 1 C This pply 1 C nis emp	3 3 3 7 7 8 9 7 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	ara mp am atur	ete	eter atur	e.
Mi Cl th Mi Seth Seth Seth	enu H su e pr enu A elec e pr enu A	A: A: A: A: A: A: A: Copies A: A: A: A: A: A: A: A: A: A:	He e Cortio	em atir CH ch atir cesi atir CH ch ch	per ed (ng su ll ra ng su ng su ng su ra	H H Ppply f the Ppply e of	E E E E E E		s s s s s s s s erat cteo	c 1 ure d C 6	4 iis p P 5 e cc tted 0 cor H su I 0 e cc	r para r pontr CH i n tro upp	 me b ol. f ol. t S ol. 	C ter 1 C This pply 1 C nis emp	3 3 3 7 7 8 9 7 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	ara mp am atur	ete	eter atur	e.

	Α	7	-		-	Η	Ε			С	Ρ	r	b		3					
										2	5		٥	С						
Th su	is (ppl	par y te	am emp	ete bera	r is atu	s th re c	ie p of E	orop AC	orti H b	ona	y tei al ra er of	Inge	е о	f th	e s	ele	эс	cte		
the	e ex	kter	na	l (c	asc	ade	e) s	ens	sor.											
Me	enu		He	ati	ng						_					_	_			1
	Α	8				Н	Ε			С		n	t		3					
										8	0 y tei		S	е	С					
ply	/ te	mp	era	atur	е	of E	EAC		boil		ime of tl									
Me	enu	A:	He	ati	ng															
	Α	9				Т	i	m	е	r	С	0	n	t						
											0									
Co Co	onta enu	act B:						ne s	setti	ng.										
Me	enu B	B:	Hc	ot w	ate	er D	Н	i	р	m	р 1	1	t	W	V					
Cc Cc Me Hc 0 = 1 =	enu B	B: 1 vate	Hc er fu o y v	ot w unc alv	tior	er D	Н		р	m	р 1	1	t	W	V					
Cc Cc Me Hc 0 = 1 =	enu enu bt w = pu = 3-	B: 1 vate	Hc er fu o y v	ot w unc alv	tior	er D	H the	i	р	m by:	p 1	/ 			v 0					
C c C c M e H c 0 = 1 = M e	enu B ot w = pi = 3-	B: 1 vate ump wa B: 2	Hc er fu p y v Hc	ot w unc alv	tior e	er D n of er D	H the H	i bo	p iler	m by:	р 1 		0	L C	0					
Cc Cc Me Hc O = 1 = Me Hc su ma	onta enu B ot w = pu = 3- enu B ot v ppl	B: B: Date Date Um Swa B: D Date Um Swa Dato Swa D Swa Dato Swa D Swa Dato Swa D Swa D Swa Dato Swa D Swa Dato Swa Dato Swa Dato Swa Dato S Dato S Da Swa D S Swa D Swa D S D S S D S S D S S S S S D S S S S	Hc er fu y v Hc er f	alv alv	tior e ctic atu	er D on of P re	H the H	i bo i	p iiler f	m by: ler.	p 1	is p	°	L C amo	O					
Cc Cc Me Hc O = 1 = Me Hc su ma	enu B Dt w = pi = 3- Dt v ppl and	B: B: act B: act act act act b: act b: act b: act b: act b: b: b: b: b: b: b: b: b: b:	Hc er fu y v Hc er f	alv alv	tior e ctic atu	er D on of D re	H the H LOV	i bo i	p iiler f boi	m by: ler.	p 1 5 Th ith a	is p an i	°	L C amo rec	O eter t hc					
Cc Cc Me Hc O = 1 = Me Hc su ma	enu B Dt w = pi = 3- Dt v ppl and	B: B: Date Date Um Swa B: D Date Um Swa Dato Swa D Swa Dato Swa D Swa Dato Swa D Swa D Swa Dato Swa D Swa Dato Swa Dato Swa Dato Swa Dato S Dato S Da Swa D S Swa D Swa D S D S S D S S D S S S S S D S S S S	Hc er fu y v Hc er f	alv alv	tior e ctic atu	er D on of P re	H the H LOV	i bo i	p iler f	m by: l ler. l w	p 1 5 Th ith a	is p	° Dara ndi	L C amo rec	O					
Cc Cc Me Hc O = 1 = Hc su ma	onta enu B ot w = pi = 3- enu B ot v ppl and enu B	B: act B: vate J wate B: B: B: B: B: B: B: B: B: B:	Ho Pr fu Py V Ho Pr fu Pr fu f	alv alv fun per	rate tior e rate ctic atu	er D on of P re D on o re	H the h LOV	i e bo	p iiler f boi	m by: ler. ler. l w	p 1 5 Th ith a	is p an i w	° Dara ndi	L C amo rec H C	O eter t hc	ot v	Na	ate	er c	de-
Co Co Me Ho O = Ho Su Me Ho Su	bonta enu B bot w = pot w = 3- enu B ot v ppli and enu B	B: act B: yate J wate B: B: B: B: B: B: B: Complete Solution B: Complete Solution B: Complete Solution So	Ho er fu y v Ho er f	alv alv ot w fun per	rate tior e rate ctic atu	er D on of er D er D	H the H LOV	i bo i he W le	p iller boi	m by: ler. l wi ler. l wi ler.	p 1 5 Th ith a	is p an i w	o o ara ndi	L C rec H C amo	O eter t ho	r is		the	er c	le-
Co Co Me Ho O = 1 = Ho su ma Ho su ma	bot w anu bot w anu bot w anu bot w ppl and bot w ppl bot w ppl	B: B: B: B: B: B: B: B: B: B: S Vate Vate	Ho er fu y v Ho er f em Ho	ot w alv alv fun per	rate tior e vate ctic atu	er D on of er D on o re	H the H LOV	i bo i he W le	p iller boi	m by: ler. l wi ler. l wi ler.	p 1 5 Th ith a 0 5 Th	is p an i w	o o ara ndi	L C rec H C amo	O eter t ho	r is		the	er c	le-
Co Co Me Ho O = 1 = Ho su ma Ho su ma	bonta enu B enu B ot v ppl and bt v ppl and bt v ppl and	B: B: B: B: B: B: B: B: B: B: S Vate Vate	Ho er fu y v Ho er f em Ho	ot w alv alv fun per	rate tior e vate ctic atu	er D on of er D on o re	H the H LOV	i bo i he W le	p iller boi	m by: ler. l wi ler. l wi ler.	p 1 5 Th ith a 5 Th ith a	is p an i w	opara ndi	L C rec H C amo	O eter t ho	r is		the	er c	le-
Co Co Me Ho O = 1 = Ho su ma Ho su ma	bonta enu B ot w enu enu B ot v ppli and ot v ppli and enu B ot v ppli and enu b ot v enu enu enu enu enu enu enu enu	B: B: B: B: B: B: B: B: B: B: B: B: B:	Ho er fu y v Ho er f em Ho	ot w alv alv fun per	rate tior e vate ctic atu	er D on of er D on o re	H the H LOV	i bo he W le	p iller boi	m by: ler. l wi ler. l wi ler.	p 1 5 Th ith a 5 Th ith a	w is p is p an i	opara ndi	L C amo rec H C amo rec	O eter t hc eter t hc	r is		the	er c	le-
Co Co Me Ho O = 1 Ho Su Me Ho Su Me	enu enu B ot w enu B ot v ppl and enu B ot v ppl and enu B ot v ppl and enu B ot v ppl and enu b t v ppl and enu enu enu enu enu enu enu enu	B: B: B: B: B: B: B: B: B: C	Hc Pr fu Py V Hc Pr fu Py V Hc Pr fu Pr fu	ot w alv ot w fun per ot w	rate tior e rate ctic atu ctic atu	Professional Control of the second se	H the of the H LOV H HIC	i i he W le	p iiler f boi eve	m by: ler. ler. l wi ler. el w	p 1 5 Th ith <i>a</i> 5 Th ith <i>a</i> 0 0	w is p is p an i t	oara ndi oara indi	L C amo rec H C amo rec	O eter t ho eter t ho eter t ho			the		CH



	В	С				D	н	d	s 2	с 0	1 0	n	t S	2 e	3 C		-		
Γ.		ion	for	the	a di	roo	+ h c	4			-	~	Э	е	C				
	-	para	-										of	the	SA	ماد	nte	ЧЬ	-
		erat							gra				01						
Me	enu B	B:	Ho	t w	ate	_	11	4		•	0	2	2	2			1	1	
	в	D				D	н	d	S	С	0 4	f	f °	3 C					
Fu	incl	ion	for	the		280	ade	d c	liro	∖ ∼th		vat	or h		are				
		para															pe	rat	ure
		ca														-			
N 4 -		. D.	11-	4	-1-														
IVIE	enu B	B:	H0	ίW	ate		Ц	Ы	S	C	D	i	f	3					
	0	-				0		u	3		8		•	C					
Fu	Incl	ion	for	the	- C2	asc	ade	ed c	dire	ct h	•	vat	er h		ers				
	-	par	-						-					-			HW	/ te	m-
		ure																	
ΝΛ.	201	B:	<u>ل</u> ام	+	0+0														
IVIE	B		011	ιw	aie	D	н	i	S	С	D	i	f	4					
	5							-	3	Ū	5		•	ч С					
Fu	Incl	ion	for	the	in a	dire		hot	w/2	ter	-	nl	/ of	the	h	nile	r (†	anl	0
									tere										
										ະບາບ		- 61 15	ິ່	2101			ייער		
																	100	le	-111
pe	rat	ure	of	the	ca	lorif											100		;111-
pe	erat enu	ure B:	of	the	ca	lorif r	ier/	tan	k.										;111-
pe	erat enu	ure	of	the	ca	lorif		tan		е	t	g	r	а	d				
pe Me	erati enu B	B:	of 1 Ho	the tw	cal ate	r D	ier/	tan	k.	е	t 3	g	r °	a C	d				
pe Me Fu	erati enu B	B: G	of t Ho for	the tw	cal ate	r D dire	H ect	i hot	k. d	e ter	t 3 sup	g oply	r ° ⁄ of	a C	d bo	oile	r (t	anł	().
pe Me Fu Th	erati enu B Incl	B: G tion	of t Ho for am	the tw the ete	cal ate e in r d	r D dire	H ect cts	i hot	d wa	e ter	t 3 sup	g oply	r ° ⁄ of	a C the ed)	d bo	oile t w	r (t	anł	().
pe Me Fu Th	erati enu B Incl	B: G	of t Ho for am	the tw the ete	cal ate e in r d	r D dire	H ect cts	i hot	d wa	e ter	t 3 sup	g oply	r ° ⁄ of	a C the ed)	d bo	oile t w	r (t	anł	().
pe Me Fu Th	erati enu B Incl nis and	B: G tion	of t Ho for am	t w t w the ete	cal ate e in r d larç	dire ger	H ect cts	i hot	d wa	e ter	t 3 sup	g oply	r ° ⁄ of	a C the ed)	d bo	oile t w	r (t	anł	().
pe Me Fu Th ma	erati enu B Incl nis and	B: G ion par	of t Ho for am	t w t w the ete	cal ate e in r d larç	r dire dete ger	H ect cts	i hot	d wa	e ter	t 3 sup	g oply	r ° ⁄ of	a C the ed)	d bo	oile t w	r (t	anł	().
Pe Me Fu Th Me	erati enu B incl nis and enu C	B: G ion para l, wl C: 1	of t Ho for am her	the tw the ete asca	cal ate e in r d larç	r D dire ete ger	H ect (wa	i hot ar ter	k. d wa (a) ar	e ter n a nou a	t 3 sup acco unt 5 1	g oply eler is b	r of rate pein	a C the d) g u	d bo	oile t w	r (t	anł	().
Pe Me Fu Me Fu	enu B Incl iis and C Incl	B: B: G ion par l, wl C: 1	of t Ho for am her Ca	the t w the ete a sca	cal ate e in r d larç ade	dire dire ete ger	H H cts (wa adir	i hot ar ter	k. d wan (a) ar C	e ter n a nou a 1	t 3 sup acce unt 5 1	g oply eler is b c er(s	r of rate pein U	a C the ed) g u n	d bc ho sec	bile t w d.	r (t	anł er (().
Pe Me Fu Th Me Fu Th	erati enu B incl is and enu C	in the second se	of t Ho for am for	the t w t w the eten a sca	cal ate ate in r d larç ade ade	dire dire ete ger	H H cts (wa adir	i hot ar ter	k. d wan (a) ar C	e ter n a nou a 1	t 3 sup acce unt 5 1	g oply eler is b c er(s	r of rate pein U	a C the ed) g u n	d bc ho sec	bile t w d.	r (t	anł er (().
Pe Me Fu Th Me Fu Th	erati enu B incl is and enu C	B: B: G ion par l, wl C: 1	of t Ho for am for	the t w t w the eten a sca	cal ate ate in r d larç ade ade	dire dire ete ger	H H cts (wa adir	i hot ar ter	k. d wan (a) ar C	e ter n a nou a 1	t 3 sup acce unt 5 1	g oply eler is b c er(s	r of rate pein U	a C the ed) g u n	d bc ho sec	bile t w d.	r (t	anł er (().
Pe Me Fu Th Me Fu Th (M	B Incl iis and C Incl iis p Incl iis p Iax.	B: G G C : 1 C : 1 1 1 1 1 1 1 1	of t Ho for am for am for bo	the t w the eten sca	cal ate ate in r d larç ade ca r se s).	dire dire dete ger M	H H cts (wa adir	i hot ar ter	k. d wan (a) ar C	e ter n a nou a 1	t 3 sup acce unt 5 1	g oply eler is b c er(s	r of rate pein U	a C the ed) g u n	d bc ho sec	bile t w d.	r (t	anł er (().
Pe Me Fu Th Me Fu Th (M	B Incl iis and C Incl iis p Incl iis p Iax.	in B: G G ition par: , wl C: 1 c: 12	of t Ho for am for am for bo	the t w the eten sca	cal ate ate in r d larç ade ca r se s).	dire dire dete ger M	H H cts (wa adir	i hot ar ter	k. d wan (a) ar C	e ter n a nou a 1	t 3 sup acco unt 5 1 Doill unt	g oply eler is b c er(s	r of rate pein U	a C the ed) g u n	d bo ho sec t	bile t w d. bo	r (t vate	anł er (().
Fu Fu Fu Fu Fu Me	eration enu B Incl iis and C Incl iis p Incl iis p Incl iis p Incl C Incl Incl C Incl Incl Incl Incl Incl Incl Incl Incl	B: G C: I, wl C: I C: I C: I C: C: C: C: C: C: C: C: C: C:	of the for a me for a	the tw the ete asca	cal ate ate in r d larc se ca r se s).	M B B	H ect (wa adir he u	hot ar ater s	k. d wa (a) ar C C	e ter n a nou 1 ne l mo	t 3 sup acco unt 5 1 poile unt d 0	g oply eler is b er(s of o	r of rate pein U s). cas	a C the d) g u n cac	d bo ho sec t	bile t w d. bo	r (t vate	anł er (().
Further Furthe	eration enu B Inct iis and enu C Inct Inct Inct Inct Inct Inct	B: G J J C: C: 10 C: 12 C: 2 C: 2	of the Hole of the	the t w the eten a sca	cal ate ate in r d larg ade ca s).	M B B A A A A A A A A A A A A A A A A A	H ect (wa adir he u	i hot ar tota	k. d wan (ar) ar C C of th al ar	e ter n a ne l mo	t 3 sup acco unt 5 1 Dooile unt d 0 Dooile	g oply eler is b c er(s of c d er(s	r of rate pein U S). cas r s).	a C the d) g u n cac	d bo sec t	bollen t w d. bo	r (t vate	anl er ((). de-
Fu Fu Fu Fu Fu Fu Fu	eration enu B unct iis and C lax. enu C	B: G G iion para 1, wl C: 1 C: 12 C: 2 iion para 12 c: c: c: c: c: c: c: c: c: c:	of t Ho for am her Ca bo Ca	the t w the eten a sca the eten iler	cal ate ate in r d larg ade s).	M B B A A A A A A A A A A A A A A A A A	H ect (wa adir he u	i hot ar tota	k. d wan (ar) ar C C of th al ar	e ter n a ne l mo	t 3 sup acco unt 5 1 Dooile unt d 0 Dooile	g oply eler is b c er(s of c d er(s	r of rate pein U S). cas r s).	a C the d) g u n cac	d bo sec t	bollen t w d. bo	r (t vate	anl er ((). de-
Furna Furna Furna Furna Furna Furna Furna Furna Furna	enu B Inct is and C Inct is lax. C	B: G C: C: C: C: C: C: C: C: C: C:	of t Ho for am her Ca for am ca for am cad	the t w the eten a sca sca sca sca sca the eten iler	cal ate ate in r d larc ade s).	M B B B B B B B C C C C C C C C C C C C	H ect (wa adir he u u adir mir ol.	i hot ar ter tota s	d wan (a) ar C Of that at	e ter n a ne l mo	t 3 sup acco unt 5 1 Dooile unt d 0 Dooile	g oply eler is b c er(s of c d er(s	r of rate pein U S). cas r s).	a C the d) g u n cac	d bo sec t	bollen t w d. bo	r (t vate	anl er ((). de-
Function Function Function	enu B Inct is and C Inct is lax. C	B: G G iion para 1, wl C: 1 C: 12 C: 2 iion para 12 c: c: c: c: c: c: c: c: c: c:	of t Ho for am her Ca for am ca for am cad	the t w the eten a sca sca sca sca sca the eten iler	cal ate ate in r d larc ade s).	M B B B B B B B C C C C C C C C C C C C	H ect (wa adir he u u adir mir ol.	i hot ar ter tota s	d wan (a) ar C Of that at	e ter n a ne l mo	t 3 sup acco unt 5 1 Dooile unt d 0 Dooile	g oply eler is b c er(s of c d er(s	r of rate pein U S). cas r s).	a C the d) g u n cac	d bo sec t	bollen t w d. bo	r (t vate	anl er ((). de-
Fu Fu Fu Fu Fu Fu Fu Fu Fu	erati enu B unct iis and enu C unct iis p ial (aste	B: G C: C: C: C: C: C: C: C: C: C:	for am for am for ame cad for amo	the t w the ete a sca the ete ling Sla	cal ate ate in r d larc ade ca s).	Image: state of the state o	H ect (wa adir he u u adir mir ol.	i hot ar ter tota s	d wan (a) ar C Of that at	e ter n a ne l mo	t 3 sup acco unt 5 1 Dooile unt d 0 Dooile	g oply eler is b c er(s of c d er(s	r of rate pein U S). cas r s).	a C the d) g u n cac	d bo sec t	bollen t w d. bo	r (t vate	anl er ((). de-
Fu Fu Fu Fu Fu Fu Fu Fu Fu	erati enu B unct iis and enu C unct iis p ial (aste	ure B: G iion para iion C: 1 iion cara iion cara iion cara cara iion para caso cara iion para caso cara iion	for am for am for ame cad for amo	the t w the ete a sca the ete ling Sla	cal ate ate in r d larc ade ca s).	Image: state of the state o	H ect (wa adir he u u adir mir ol.	i hot ar ter tota s	d wan (a) ar C Of that at	e ter n a ne l mo	t 3 sup acco unt 5 1 Dooile unt d 0 Dooile	g oply eler is b c er(s of c d er(s	r of rate pein U S). cas r s).	a C the d) g u n cac	d bc ho sec t led	boile t w d. bo	r (t vate	anl er ((). de-
Further Further Me	rati enu B inct is and c inct is lax. c inct is c c c c	B: G C: C: C: C: C: C: C: C: C: C:	for ame for ame for ame bo Ca for ame cad o, Ca	the tw tw the eten a sca the eten iler sca sca	cal ate ate ate ate ate ate ate ade s).	Image: state of the state o	H H cts (wa adir he u u H	i hot ar ater tota s etc.	k. d wa (a) ar C C the d the the	e ter n a 1 ne t mo	t 3 sup acce unt 5 0 0 0 0	g poply eler is b c of c er(s ess	r of dein U s). cas r s).	a C the d) g u n cac	d bc ho sec t led	boile t w d. bo	r (t vate	anl er ((). de-
Futhors Futhor	B Inclais and C C Inclais Inclas Inclas C C C C C C C C	B: G C: C: C: C: C: C: C: C: C: C:	for ame for ame for ame bo Ca for ame cad cad for ame for ame for ame for ame for ame	the tw tw the eten a sca the eten iller sca sca sca sca sca	cal ate ate in r d larc ade s).	Image: state of the state o	H H cts (wa adir he u u H H	i hottar x ng o tota s setc. i	d wan (a) ar C Of the of the the	e ter n a 1 ne t mo a a a a	t 3 sup acce unt 5 1 boild dunt d d d d d d d d d d d d d d d d d d d	g poply eler is b c c er(s of c d er(s ess	r of cate bein U S). cas	a C the d) g u n cac	d bo sec t led	boile boile boile	ille	anl er ((). de-
Futher Fu	B Inclais and C C Inclais Inclais Inclais Inclais Inclais Inclais Inclais Inclais	B: G C: C: C: C: C: C: C: C: C: C:	for ame for ame for ame cad for ame cad for ame cad for ame	the tw tw the ete a sca the ete ling Sla sca sca the ete	cal ate ate in r d lar(ade s). ade ca s). ade ca r de r de r de r d ade	Image: state of the state o	H H cts (wa adir he u u H H adir rmir ol. 1 e	i hottar s i i s i i ng c i i	d wan (a) ar C C of th al al of the the of th	e ter n a 1 ne t mo a a a a a a	t 3 sup acce unt 5 1 boild unt d d d d d d d d d d d d d d d d d d d	g oply eleris b er(s of d er(s ess	r of rate ein U S). cas r of m	a C the d) g u n cac the the	d bo sec it ied sec is is is is is is is is	boile boile	ille	anl er ((). de-

	С	4				Ε	Х	t	r	а		u	n	i	t					
											0									
Tł co	nis (oar ecte	am ed	ete to 1	r is the	ac	tiva	ng c ited er b	wh	en	an	ex	tern							
M	enu		Са	asca	ade															
	С	5				С	а	S		S	i 0	1	Μ	а						
Th ali 0 :		bara ner ingl	am nt le /	ete Sla	r se ave	ets	the	ng c fund						r at	a c	aso	cad	е		
M	enu	C:	Са	asca	ade	;														
_	С					Ρ	W	r	0	f	f	Τ	0	С	а					
_						-		ng c			0									
	enu C	7				С	0	m ng c	F	1	u 0	Ν	u	m						
Tł	nis p	bara	am	ete	r de	eter	mir	ies t th a	the	nuı	nb	er o	of ca			d b	oile	ers		
	enu D	D:			ral	0	-	1	0	V	c	0	n	t	r					
M	enu D	D: 1	Ge	ene		-		-	0	V	с 0	0	n	t	r					
M Fu V 0 :: 2 ::	enu D Inct olt s = N = C	D: ion ign o e ont ont	Ge for al (xte rol rol	the Co rna bas	e e nne Il co sed	xte ecti ontr	rnal ons ol ter	1 cor 15 npe wer	0 htro -16) ratu	V I of ure	c 0 the	o e bo	n Diler	t	r	ng	a 0)-1()	
M Fu V 0 :: 2 ::	enu D Inct olt s = N = C	D: ion ign o e ont ont	Ge for al (xte rol rol	the Co rna bas	e e nne Il co sed	xte ecti ontr	rnal ons ol ter	cor 15	0 htro -16) ratu	V I of ure tting	c 0 the set	o e bo	n piler	t by	r	ng	a 0)-1()	
M Fu V 0 := 2 := M	D Inct blt s = N = C = C	D: 1 iion iign o e ont ont D: 2	for al (xte rol Ge	r the CO rna bas	e e nne Il co sed sed	xte ecti ontr on 0	rnal ons ol ter po	cor 15 mpe wer	0 -16) ratu set	V I of ure tting M 2	c 0 the set	o e bc ting	n biler	t by m C	r usi					
	enu D Inct blt s = C = C enu D Inct blt s	D: ion ign o e ont D: D: 2 ion ign ol t	Ge for al (xte rol Ge for al (bas mu	ene Co Co bas bas ene Co Co ed im	e e e e e e e e e nne e e e on e e e (de	xte ecti ontr on on 0 xte ecti ten	rnal ons ol ter po rnal ons	cor 15 npe wer	0 -16) ratu set 0 -16) -16)	V I of ting M 2 I of Set	c 0 the set	o = bc ting n = bc (1)	n Diler T Diler	t by m C by	r usi usi	ng	a 0)-1()	
	D Inct blt s = C = C enu D Inct blt s pontr ne n 1.4	D: ion ign o e ont ont D: 2 ion ign ol t nini Vo 3	Ge for al (xte rol rol Ge for al (pas mu It si	ene Co rna bas bas ene Co ed igna	e e e e e e nne on e e e ral	ontronomotion on o	rnal ons ol ter po rnal ons ed) (cor 15- mpe wer 1 cor 15- ratu	0 -16) ratu set 0 -16) rre (wat	V I of ting M 2 I of set er t	c 0 the set 1 0 the em	o e bc ting n e bc g 1) per	n piler T o Diler ratu	t by m C by re w	r usi usi usi	ng n s	a 0)-1() ng	
-	D	4				Μ	а	X	С	0	0	Ι	Т	i	m					
---	---	--	---	---	---	---	------------------------------------	---	---	--	----------------------------	-----------------------	--------------	-------	-------	----	-----	----	----	--
_											2		Μ	i	n					
(m	inct naxi = S	mu	m ′	10 I				nax	IMU	ım o	ove	rrur	n tin	ne c	of th	eı	an	1		
Μ	enu	D:	Ge	ene	ral															
	D	5				Т	е	m	р	0	n 1	D	i	S	р					
	inct e di			sho	SW	the	(m	eas	ure	d) te	emp	bera	atur	e o	f the	b	oil	er	at	
M	enu	D:	Ge	ene	ral															
	D	6				D	Η	۷	V	1	=	i	2	=	d					
_										HW	1									
0 1	= C = C = H	H c H/H	nly I W	′ (d fur	irec nctio	:t) on (
M	enu	D:	Ge	ne	ral															
	D	7				С	0	n	f	i	g									
0 = 1 =	= of = se = sv	ens	or	u	GIIS		15 U	seu	, up	o to	6 b	ar a	a sv	vitcl	า.					
0 = 1 = 2 =	= se	ens vitc	or h				.s u	seu	, ur	o to	6 b	ar a	a sv	vitc	n.					
0 = 1 = 2 =	= SE = SV	ensovitc D:	or h			g		seu				e e	a sv		n.					
0 = 1 = 2 =	= Se = Sv enu D	enso vitc D: 8	or h Ge	ene	ral	g	a	S	t	У			a sv		n.					
0 : 1 : 2 : M(F(0 : 1 :	= se = sv enu D	D: B ion 20, 31	or h Ge to	ene	ral	g the for	a ga Po	s ty	t pe*	У	p G2	e .35	0		n.					
0 : 1 : 2 : M(0 : 1 : 2 :	= se = sv enu D inct = G	ensovitc D: 8 ion 20, 31 (P	or h Ge to	sel 25 a	ral ect	g the for	a ga Po	s ty	t pe*	y 27,	p G2	e .35	0		n.					
0: 1: 2: Mo Fu 0: 1: 2:	= Se = sv enu D Inct = G = G	ensovitc D: 8 ion 20, 31 (P	or h Ge to	sel 25 a	ral ect	g the for	a ga Po	s ty	t pe*	y 27,	p G2	e .35	0		n.					
0 : 1 : 2 : Mo 1 : 2 : Mo 1 : 2 : Mo	= se = sv = sv = nu = G = G = B/	vitc D: 8 ion 20, 31 (P D: 9	or h Ge G2	sel 25 a	ral ect and	g the for	a ga Po *Ac	s ty land	t pe* d G	y 27, g to	p G2 EN	e .35	0		n.					
0:1:2: Min Fu 0:1:2: Min Fu 0:1:2: Min Fu 0:1:1:1:1:1:1:1:1:1:1:1:1:1:1:1:1:1:1:1	= see = sv = sv = nu = G = G = B/ = B/ = nu = nu = nu = re	D: 8 20, 31 P 0: 9 ion orm dua	or h Ge to : G2 Ge for al s	sel 25 a ene stai	ral ect and ral ttin	g the for	a ga Po *Ac	s ty land corr	t pe* d G ding	y 27, i rt' o	p G2 EN	e .35	0		n.					
0: 1: 2: Mo Fu 0: 1: 2: Mo 1: 2: Mo 1: 2:	= se = sv = sv = nu = G = G = G = G = B/ = G = B/	D: 8 20, 31 (P 9 0 0 0 0 0 0 0 0 0 0 0 0 0	or h Ge to G2 Ge	sel sel 25 a ene star far far	ral ect and ral ttin rt-up n ra n ra	g the for	a ga Po *Ac	s ty land corr	t pe* d G ding	y 27, g to i	p G2 EN	e .35	0		n.					
0: 1: 2: Mo Fu 0: 1: 2: Mo 1: 2: Mo 1: 2:	= se = sv = nu D Inct = G = B/ = B/ D Inct = nc = re = re	D: 8 20, 31 P 9 J: orm dua dua D:	or h Ge to G2 Ge	sel sel 25 a ene star far far	ral ect and ral ttin rt-up n ra n ra	g the mp	a ga Po *Ac	s ty land corr soft spo	t ding f sta	y 27, i (1) (1) (1)	p G2 EN ptic	e .35	0		n.					
0: 1: 2: Mo Fu 0: 1: 2: Mo 1: 2: Mo 1: 2:	= se = sv = nu D Inct = G = B/ = B/ D Inct = nc = re = re	D: 8 20, 31 (P 9 0 0 0 0 0 0 0 0 0 0 0 0 0	or h Ge to G2 Ge	sel sel 25 a ene star far far	ral ect and ral ttin rt-up n ra n ra	g the for	a ga Po *Ac	s ty land corr	t pe* d G ding	y 27, i rt' o	p G2 EN	e .35	0		n.					
0: 1: 2: Mo Fu 0: 1: 2: Mo 1: 2: Mo	= see = sv enu D inct = G = G = G = B/ D inct = nc = re = re = re	D: 8 100 20, 31	Ge Ge Ge for al s ced Ce	ene sel 25 a sea fai fai	ral ect and tting t-up n ran ral	g th mp mp	a ga Po *Ac	s ty land corr soft spo	t ding f sta	y 27, i (1) (1) (1)	p G2 EN ptic	e .35	0		n.					
0::2: Mi Fu 1::2: Mi Fu 1::2: Mi Fu 1::2: Mi Fu Fu 1::2: Mi Fu Fu Fu Fu Fu Fu Fu Fu Fu Fu	= se = sv = nu D Inct = G = B/ = B/ D Inct = nc = re = re	D: 8 100 100 100 100 100 100 100	or h Ge to Ge for al s ced ced	ene sel 25 a sea fai fai	ral ect and tting t-up n ran ral	g th mp mp	a ga Po *Ac	s ty land corr soft spo	t ding f sta	y 27, i (1) (1) (1)	p G2 EN ptic	e .35	0		n.					
0::2 1::2 Mi Fu 1::2 Fu 1::2 Mi Fu 1:2 Mi Fu 1::2 1::1 Co 1::2 CO 1::2	= se = sv = nu D Inct = G = B/ = B/ = B/ D Inct = nc = re = re = re = nu = nc = re	D: 8 100 20, 31 7 D: 100 20, 31 7 D: 100 000 000 000 000 000 000 00	or h Ge to : G2 for al s ced Ge Ge Ge	sel 25 a sel 25 a sel 25 a	ral ect and ral ttin rt-up n ra n ra ral p m	g the mp mp c c c c c c c c c c c c c c c c c	a ga Po *Ac • up up	s ty land corr soft spi spi n	t pe* d G ding f sta eed eed	y 27, i (1) (1) (1)	P G2 EN g ptic	e .35 I43 Dn	0 7 t)							

10.17 Fault codes display

The following graphs describe the lock out codes of the boiler. A lock out code can only be removed by a manual resetting of the boiler.

NOTICE: Before resetting the boiler always check the boiler, central heating system and all components corresponding to the related lock out description. Never just reset the boiler, before analysing the possible cause of failure.

10.17.1 LOCK-OUT CODES

Having a lockout means that the boiler needs a manual reset to start operating again. When the boiler is in lockout the backlight of the display is blinking on and off.

Explanation > 9 9	9	, !	5	: ł	וו	r s	;	= tir	ne e	elap	sed	aft	er fa	ault	& n	nes	sage	ə.		
Explanation > P u	m) (1	(o r	١	:	= st	atus	s of	the	pur	np	duri	ng f	ault	-			
Display message	F	I	0	w		S	е	n	S	0	r		е	r	r	ο	r			
F0	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason Flow sensor	not	det	ecte	d b	y th	e bo	biler	ca	use	d by	/ fai	ulty	con	nec	tion	/se	nso	r.		
Display message	F	Ι	0	w		h	i	g	h		Т	е	m	р						
F1	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason Flow temper	atur	e e>	cee	eds	the	limi	t wł	hich	has	s be	en	set	in tł	ne p	ara	met	ers.			
Display message	R	е	t	u	r	n		h	i	g	h		Т	е	m	р				
F1	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason The maximu	m re	eturi	n tei	mpe	eratu	ure	as s	set i	n th	e pa	arar	net	ers	is e	xce	ede	d.			
Display message	L	а	С	k		0	f		¥	а	t	e	r							
F2	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason The general	requ	uire	d gr	adie	ent v	wate	er la	ack	has	fail	ed.									
Display message	R	е	t	u	r	n		S	е	n	S	0	r		е	r	r	0	r	
F3	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason Return sense	or no	ot d	etec	ted	by	the	boil	er c	aus	ed	by f	ault	y c	onn	ectio	on/s	sens	sor.		
Display message	F	Ι	u	е		S	е	n	S	0	r		е	r	r	0	r			
F6	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason Flue gas ser	sor	not	det	ecte	ed b	y th	e b	oile	r ca	use	d by	y fa	ulty	cor	nec	tior	n/se	nso	r.	
Display message	F	I	u	е		t	е	m	р		t	0	0		h	i	g	h		
F7	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason Flue gas tem	per	atur	e ex	kcee	eds	the	lim	it wl	nich	ha	s be	en	set	in tl	ne p	ara	me	ters		
Display message	F	а	i	I	е	d		b	u	r	n	е	r		S	t	а	r	t	
F8	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason Boiler is not		ina	afte	-		roar	am	mo	l eta	artin	0.0	tton	ants	<u> </u>					_	

Reason Boiler is not starting after the programmed starting attempts.

Display m	essage	F	Ι	а	m	е		Ι	0	S	t									
F9		р	u	m	р		0	n				9	9	9	,	5		h	r	S
Deces			اير . او						-			4				~	-	-		

Reason Flame detected during normal operation, but was lost while running.

Display me	essage	F	а	I	s	е		f	I	а	m	е		s	i	g	n	а	Ι		
F10		р	u	m	р		0	n					9	9	9	,	5		h	r	S
Deeee		1.0.0				11.4	4								-	-	-	-			

Reason Flame signal is detected while it cannot be expected.

Display message	F	а	n		s	р	е	e	d		n	С	0	r	r	е	С	t	
F11	р	u	m	р		0	n				9	9	9	,	5		h	r	S

Reason The controller does not detect a correct fan speed.

Display me	essage	р	r	0	g	r	а	m	m	i	n	g		е	n	d				
F12		р	u	m	р		0	n					9	9	9	,	5	h	r	S
Reason	Software par	amo	tor	c ha		hoo	n n	roar	- 	mod	4		-	-	-	-	-		-	

Reason Software parameters have been programmed.

Display message	Ρ	а	r	а	m	1	Η	а	r	d	w		f	а	u	-	t			
F13	р	u	m	р		0	n					9	9	9	,	5		h	r	S

Reason Fault during programming of the boiler software parameters.

Display message	С	I	i	X	0	n		F	а	u	I	t								
F15	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Decem Ilists share		٢.		L .			1						•		- 11		.1			

Reason Heat exchanger fuse or burner door clixon exceeded maximum allowed value.

Display m	essage	F	I	0	w	R	е	t	u	r	n	d	t		f	а	u	I	t	
F16		р	u	m	р		0	n				9	9	9	,	5		h	r	s
Passan	Tomporatura	dif	foro	nco	Τ1	тο	hac			٩٥٩	the	oki	0.0.1		<u> </u>	oro	tho	n th	roo	

Reason Temperature difference T1-T2 has exceeded the blocking value more than three times.

Display message	W	а	t	е	r		h	i	g	h	I		m		t			
F17	р	u	m	р		0	n				9	9	9	,	5	h	r	S

Reason Maximum thermostat (clixon) measured a too high flow temperature.

Display message	S	i	р	h	0	n		S	w	i	t	С	h						
F19	р	u	m	р		0	n					9	9	9	,	5	h	r	S

Reason The pressure switch detects a high pressure in the flue/siphon system.

10.17.2 BLOCKING CODES

The following graphs describe the blocking codes of the boiler. A blocking code is only a temporary blocking of the boiler, because of an extraordinary situation. The boiler will continue to operate after stabilisation of this situation.

The display is not blinking, but is lightened up during the blocking period.

The boiler is blocking an action because of an extraordinary situation. This action will be continued after elimination of the extraordinary situation.

Display message						1	1													
· · ·	Α	n	t	i	С	У	С	Ι	е		t	i	m	е						
												9	9	9	,	5		h	r	s
Reason The con	troller	rece	iveo	dar	new	hea	t de	mar	nd to	o qi	uick	afte	er th	e las	st er	ndeo	d de	mar	nd.	•
Display message	F	T	u	е		t	е	m	р		h	i	g	h						
												9	9	9	,	5		h	r	s
Reason Flue gas	s tempe	eratu	ure	has	exc	eed	ed tl	ne li	mit,	as s	set i	n th	e pa	ram	eter	S.				
Display message	F	I	0	w		t	е	m	р		h	i	g	h						
												9	9	9	,	5		h	r	s
Reason Flow ter	nperat	ure l	has	exc	eed	ed t	he b	lock	king	tem	pera	ature	e, as	s se	t in t	he	para	met	ers	
Display message	F	Ι	ο	w		t	е	m	р		h	i	g	h						
												9	9	9	,	5		h	r	s
Reason Flow ter	mperat	ure l	has	exc	eed	ed t	he b	lock	king	tem	pera	atur	e, w	hich	is s	et i	n the	9		
Display message	R	е	t																	
		•	L	u	r	n		t	е	m	р		h		g	h				
		•	·	u	r	n		t	е	m	р	9	n 9	1 9	g ,	n 5		h	r	s
Reason Return t rameter		ature	e ha	is ex	kcee	edec		blo	ckin	g te	mpe	erati	9 ure,	whie	, ch is	5 set				S
		ature	e ha	is ex	kcee	edec		blo	ckin	g te	mpe	erati	9 ure,	whie	, ch is	5 set				S
rameter	s, but t	ature he re	e ha	is ex n te	kcee mpe	edec	ure h	blo	ckin not e	ig te exce	mpe	erati	9 ure,	whie	, ch is	5 set				s s
rameter	s, but t	ature he ro 2	e ha etur	n te	kcee mpe	edec eratu	ure h	e blo nas r i	ckin not e g	g te exce	mpe	eratu ed th 9	9 ure, ne lo 9	whic ck-c 9	, ch is out v	5 s set alue 5	ə.	he p h)a-	S
rameter Display message Reason Temper	s, but t	ature he ro 2	e ha etur	n te	kcee mpe	edec eratu	ure h	e blo nas r i	ckin not e g	g te exce	mpe	eratu ed th 9	9 ure, ne lo 9	whic ck-c 9	, ch is out v	5 s set alue 5	ə.	he p h)a-	S
rameter: Display message Reason Temper ters.	s, but t T ature d	ature he ro 2	e ha etur -	n te	kcee mpe	edec eratu has	ne h	e blo nas r i	ckin not e g	ng te exce h the	mpe	eratu ed th 9	9 ure, ne lo 9	whic ck-c 9	, ch is out v	5 s set alue 5	ə.	he p h)a-	s e-
rameterDisplay messageReasonTemper ters.	s, but t T ature d D er start	ature he ro 2 iffer e	e ha etur - enc a	n te n te T e T2 i	ccee mpe 1 2-T1 r atio	edec eratu has a	h h s exc t	i i i cceec i	ckin not e g ded o nd a	g te exce h the n	mpe	eratu ed th 9 king	9 Jre, ne lo 9 y val	whic ck-c 9 ue a 9	, ch is out v , as s	5 s set zalue 5 et in 5	e.	he par	r ram	S ⊖-

Display mes	ssage	G	а	S		р	r	е	S	S	u	r	е		I	ο	w				
													9	9	9	,	5		h	r	S
Reason	Gas supply			iro ie	e (to	<u>م) ار</u>	2							-	-	-	-	-	-	-	

Reason Gas supply pressure is (too) low.

				_																
Display message	W	а	t	е	r	р	r	е	S	S	u	r	е		f	а	u	Ι	t	
												9	9	9	,	5		h	r	s
Reason Water pre	essu	re is	too	low	or t	ioo ł	high			•				-	•	-	-		•	
Display message	0	u	t	d	0	0	r		s	е	n	s	0	r		f	а	ï	I	
												9	9	9	,	5		h	r	S
Reason Outdoor t rameters		erat	ure	has	exc	eed	ed t	he b	lock	king	tem	pera	ature	e wh	ich	is se	et in	the	ра-	
Display message	d	Τ		В	Ι	0	С	k												
												9	9	9	,	5		h	r	s
Reason Tempera the lock of				ce b	etwo	en	flow	anc	d ret	urn	exce	eeds	s the	blo	ckin	ig va	alue	but	not	
Display message	С	а	S	С	а	d	е		В	I	0	С	k							
												9	9	9	,	5		h	r	s
Reason One of th	e ca	scad	ded	boile	erso	caus	ses a	an e	rror,	bec	caus	e of	a lo	ock d	out.					
Display message	Α	Ρ	S		f	а	u	I	t											
												9	9	9	,	5		h	r	s
Reason Activation	n of t	he a	ir p	ress	ure	swit	ch.													
Display message	Ν	R	V		0	r		F	а	n		f	а	u	I	t				
												9	9	9	,	5		h	r	s
Reason Non retur	n va	lve	cont	act	sign	al a	ctiva	ated,	> 1	5 se	econ	ids v	vill c	aus	e a	lock	-out			
Display message	L	i	n	е		f	а	u	-	t										
												9	9	9	,	5		h	r	s
Reason Wrong el	ectri	cal p	owe	er su	lqqu	y is	coni	nect	ed (not	50 o	or 60	Hz	220)-24	0 V	olt).			
Display message	G	е	n		В	Ι	0	С	k											
												9	9	9	,	5		h	r	s
Reason The gene	ral b	lock	king	circ	uit is	act	ivat	ed d	lurin	g op	bera	tion	= co	onta	ct 7	-8	_		-	

ison The general blocking circuit is activated during operation = con

10.17.3 Messages

The following graphs describe the messages at the boiler display. Depending on the selected and activated options for the boiler, it is possible that some messages will show up at the display of the boiler. For example a maintenance message after a certain programmed date has been reached. The boiler will operate independently of these messages.

MAINTENANCE ATTENTION FUNCTION

The display shows alternating the base screen and this message, while the backlight is blinking. The boiler is operating, but will count the exceeding hours. A parameter must be changed, after service, to remove this message.

Display message	Ν	е	е	d	s		Μ	а	i	n	t	е	n	а	n			0		0
	I	g	n	i	t	i	0	n		С	У	С	I	е	S		h	r	S	
Reason Mainter	nano	ce o	ptic	on o	f to	tal a	amo	ount	t of	igni	tior	і су	cles	s ha	ıs b	een	n rea	ach	ed.	_
Display message	Ν	е	е	d	S		Μ	а	i	n	t	е	n	а	n			0	•	0
	D	а	t	е													h	r	S	
Reason Mainter	and	ce o	ptic	on o	f th	e d	ate	has	be	en	read	che	d.							
Display message	Ν	е	е	d	s		Μ	а	i	n	t	е	n	а	n			0	-	0
	В	u	r	n	i	n	g		h	0	u	r	s				h	r	S	
Reason Mainter	and	ce o	ptic	on o	f to	tal a	amo	ount	t of	bur	ning	g ho	ours	s ha	s b	een	rea	ache	ed.	
Display message	Ν	е	е	d	S		Μ	а	i	n	t	е	n	а	n			0	-	0
	Α	I	I														h	r	S	
Reason One of	the	abc	over	ner	tior	hed	ma	inte	nar	nce	ont	ion	s ha	as h		n ro	ach	۵d		

11 CONTROLLING OPTIONS AND SETTINGS

11.1 General

The following paragraphs describe some general functions of the boiler and their possible use.

11.1.1 EXTRA BOILER CONTROL

When all units (cascaded) are firing at their maximum it is possible to start an extra "external" heating source. This unit can be connected to the "Burner Burning" contacts (connection 21-22).

P5DE Extra Boiler output enable (1) (display C4)

When this parameter is set 1, the contact "Burner Burning" will close, but only when all units are firing at a certain (programmable) input percentage. The standard factory setting for this function is "OFF".

11.1.2 MAX COOLING TIME

The fan will cool down the heat exchanger according to the temperature settings (parameters) of the software. With this cooling parameter the maximum run time of the fan can be programmed.

P2LK Max cooling time (display D4)

This function is not used for central heating boilers.

11.1.3 TEMPERATURE DISPLAY ON/OFF

Selection for showing the measured temperatures at the operation display of the boiler.

P5BJ Temperature display 1=on (display D5)

The measured temperature at the operation display.

0 = not visible

1 = visible

11.1.4 WATER PRESSURE

P4AD pressure 0=off, 1=sensor, 2=switch.

When the water pressure exceeds 4 bar a pressure switch must be used instead of the sensor (suitable till 4 bar). With the switch, pressure can go up to 6 bar.

In this case, remove the pressure sensor and replace it by the pressure switch. Now set the parameter at the control panel by changing "D7 config" from 1 into 2.

11.1.5 GAS TYPE SELECTION

Settings for gas types: natural gas, propane or butane-propane mixture (B/P).

P4 BD Gas type (0=standard, 1=propane, 2=B/P) (display D8)

This parameter is set 0 for the common used gas types such as natural gas G20 or G25. By setting this parameter 1 for propane, fan speed is reduced. Set this parameter 2 for B/P.

- 0 = standard gas (e.g.: natural gas), Lw, Ls (Lw and Ls only for Poland)
- 1 = propane
- 2 = B/P

By each setting, the relevant Soft start settings are automatically adjusted, depending on its main setting P4BE, see next section § 11.1.6.



In case of gas conversion, paste the corresponding sticker at the appropriate position in the boiler and mark the square for the used gas type. Also mark the square, indicating that the correct value has been set for parameter P4BD.

(In the example on the right, 'propane' and 'P4BD = 1' have been marked).

	PROPANE	
G31 P	PROPAN	P4BD = 1
	PROPANO	
	PROPAAN	
	BUTANE/PROPANE	
G30/G31 B/P	BUTAN/PROPAN	P4BD = 2
	BUTANO/PROPANO	
	BUTAAN/PROPAAN	



11.1.6 SOFT START OPTION

Start parameters can be modified to achieve better start behaviour, in case of noise or other difficulties. This is done by reducing the fan ramp-up speed. Two reduced settings are available (I and II).

P4 BE Soft start (0=normal, 1=reduced fan ramp-up speed (I), 2=reduced fan speed ramp-up (II)) (display D9).

- 0 = normal start-up
- 1 = reduced fan ramp-up speed (I)
- 2 = reduced fan ramp-up speed (II)

11.1.7 PUMP MODE (EC TECHNOLOGY)

When using a pump with Electronic Commutation technology and start-stop function, with a separate control connection, this parameter determines the relay for switching the pump on and off.

P5 BN Pump mode (0=modulating, 1=relay1, 2= relay2, 3= relay3) (display DA)



Do not use the 230 Vac relay for the main power supply of the pump, but directly connect the pump to an external power supply.

A modulating pump with PWM control: the power supply is directly connected to the mains, the PWM connection is connected to CN10, contacts 9 and 18.

Pumps with an on/off control can be switched by one of the relay connections "lock-out", "burner burning" or "heat demand". Choose a connection which is not yet used.

- 0 = PWM 0-100% modulating pump, connection **CN10**, connectors 9 and 18
- 1 = Start-stop through relay **1**, connectors 19 and 20 (lock-out)
- 2 = Start-stop through relay **2**, connectors 21 and 22 (burner burning)
- 3 = Start-stop through relay **3**, connectors 23 and 24 (heat demand)

11.2 Heating

The following paragraphs describe the different functions of the boiler and their related "controlling behaviour settings" as a central heating boiler.

11.2.1 CONTROLLING BEHAVIOUR SETTINGS

The factory settings for all heating applications are working fine and it is therefore advised not to change these settings. Always consult the manufacturer for advice if changes to parameter settings are needed.

P5 AO Blocking offset flow temperature control (display A2)

The amount of degrees the measured temperature exceeds the active flow temperature set point before the heat demand stops. Only active when the unit is controlled by the internal flow sensor (S1) and used for single unit control.

P5 AL Hysteresis CH flow temperature control (display A4)

The amount of degrees that the measured temperature must drop, relative to the active flow temperature set point + Offset (Parameter **P5 AO**), before the heat demand starts. This function is active when the unit is controlled by the internal flow sensor (S1) and used for single units. When controlling cascaded units with an external flow sensor (S3), this sensor will be used.

P5 AP Proportional range single heating boiler (display A3)

The proportional range for controlling the flow temperature of the boiler. This function is active when the unit is controlled by the internal flow sensor (S1) and used for single units. When controlling cascaded units with an external flow sensor (S3), this sensor will be used.

P2 MI Blocking offset system CH temperature control (display A6)

The amount of degrees the measured temperature exceeds the active flow temperature set point before heat demand stops. Only active when the unit is controlled by an external flow sensor (S3).

The following graph shows the relation between the several parameters.



11.2.2 ROOM THERMOSTAT ON/OFF

A room thermostat with a fixed set point and using an ON/OFF control can be connected to the boiler (Connections 13-14). Changing the flow temperature set point and activation of a timer program can be done by this room thermostat or by programming the boiler settings. See chapter 10.10

11.2.3 ROOM THERMOSTAT OPEN-THERM

An RC Open Therm controller can be connected to the boiler for temperature reading(s) and remote programming (connections 13-14).

11.2.4 OUTDOOR TEMPERATURE RELATED FLOW CONTROL

The flow temperature can be calculated by using the measured outdoor temperature for controlling the boiler. See for detailed information § 10.11.

11.2.5 0-10 VDC REMOTE FLOW TEMPERATURE SET POINT

The flow temperature is controlled by connecting an external 0-10 Vdc signal to the boiler (connections 15-16).

P5 BB Analogue input config (0=off 1=temperature 2=power) (display D1)

This parameter must be set at "1" so the supplied 0-10 Vdc signal will control the temperature set point. Possible settings are:

- 0 = 0-10 V control off
- 1 = 0-10 V temperature set point control active
- 2 = 0-10 V burner input control active

P5 AI Minimum temperature 0-10V input (display D2)

The standard starting temperature of the heat demand, when the minimum voltage signal is sent to the boiler. The factory settings for all heating applications are working fine and it is therefore advised not to change these settings. Always consult the manufacturer for advice if parameter changes are needed.

See also the following graph for the relation between the temperature and the control signal



11.2.6 0-10 VDC REMOTE BURNER INPUT CONTROL

The burner input is controlled by connecting an external 0-10 Vdc signal to the boiler (connections 15-16).

P5 BB Analogue input config (0=off 1=temperature 2=power) (display D1)

This parameter must be set at "2" so the supplied 0-10V dc signal will control the burner input. The standard factory setting is "1", temperature set point control. Possible settings are:

- 0 = 0-10V control off
- 1 = 0-10V temperature set point control active
- 2 = 0-10V burner input control active

See also the following graph for the relation between the burner input and the control signal.



11.2.7 TIMER CONTACT FUNCTION

This function can be activated when using an external night reduction timer for heating. This timer contact can be connected to the thermostat terminals (connections 13-14).

P5 AB Timer contact (1=on) (display A9)

When this parameter is activated and...

- ...the thermostat terminals are bridged (timer contact closed), the normal daytime temperature is used as set point.
- ...the thermostat terminals are not bridged (timer contact open), the night reduced temperature is used as set point.

11.3 Indirect hot water/calorifier

The following paragraphs describe the different functions of the boiler and their related "controlling behaviour settings" as a central heating boiler with an indirect hot water function.

11.3.1 PUMP AND 3-WAY VALVE CONTROL

See chapter 19 for several installation examples of the boiler and the preferred functions. When the boiler is used as an indirect boiler for both central heating and hot water function, this hot water function can be activated by using a DHW pump (calorifier pump (pump 2)) or a 3-way valve.

P4 AB DHW Pump config 0=Pump 1=TWV (display B1)

With this parameter it is programmed if the flow to the indirect water tank (calorifier) is controlled by a pump (0 = pump) or a 3-way valve (1 = TWV).

11.3.2 TANK THERMOSTAT

An external thermostat can be connected to the boiler (connections 5-6). When there is a hot water demand and the tank thermostat closes, the boiler will start for the hot water demand. The calorifier/tank pump will be activated or in case of a 3-way valve, this valve will turn to the position to supply heat to the tank coil(s). In case of a heat demand and hot water demand, the (central) heating pump will switch off until the hot water demand ends.

P4 AB DHW pump Config 0=Pump 1=TWV (display B1)

With this parameter it is programmed if the flow to the indirect water tank (calorifier) is controlled by a pump (0 = pump) or a 3-way valve (1 = TWV).

11.3.3 TANK SENSOR

A tank sensor can be connected to the boiler. The tank (hot water) set point and related controlling parameters are set in the boiler controller. A hot water demand is detected by the boiler, when the sensor (water) temperature drops below the set point. The calorifier/tank pump will be activated or in case of a 3-way valve, this valve will turn to the position to supply heat to the tank coil(s). In case of a heat and hot water demand at the same time, the heating pump will switch off until the hot water demand is stopped (water temperature is reached).

P5 CA Hysteresis DHW tank temperature (display BF)

The amount of degrees that the hot water temperature in the indirect water tank/calorifier needs to drop relative to the hot water set point, before the heat demand is send to the boiler.

11.3.4 LOW/HIGH FLOW TEMPERATURE TO TANK COIL

This function can only be used for an "indirect" programmed boiler (parameter **P4 AA** = 1). Normally for a regular calorifier a fixed flow temperature of 85° C is supplied to the calorifier heat exchanger in case of a heat demand. This hot water flow will indirectly heat up the water in the calorifier tank.

The parameters for this function can be configured for both low and high calorifier operation.

This function operates as follows:

When there is a heat demand, the boiler supplies water to the heat exchanger of the calorifier, according to the flow temperature set in parameter **P5 CB**. When the heat demand remains for the period set in parameter **P5 CL**, the flow temperature set point will change to a higher temperature, which is set in parameter **P5 CK**. This situation continues until the heat demand ends.



The reason for this function is that the boiler by supplying a lower flow temperature to the heat exchanger of the calorifier, can stay in its condensing mode (if the temperature is low enough) and thus operate at a higher efficiency level. When it takes too long (> P5 CL) to heat up the tank with this low temperature mode, the flow temperature set point will change to a higher setting to make sure that the hot water set point is reached.

P5 CB Flow temperature DHW tank low (display B2)

The low level flow temperature to the tank coil(s) in case of a calorifier/indirect hot water demand. This "two staged" function is added to keep the boiler in the condensing mode as long as possible.

P5 CK Flow temperature DHW tank high (display B3)

The high level flow temperature to the tank coil(s) in case of a calorifier/indirect hot water demand.

P5 CL Low flow temperature time DHW (display B4)

The programmed period for changing the set point of the water flow temperature from low to high. The standard factory setting for this function is "OFF".

11.3.5 HEATING AND HOT WATER SWITCHING TIME

This function can only be used for an "indirect" programmed boiler (parameter P4 AA = 1).

In case there is a heating demand and the unit is operating for this heating demand, also a hot water demand can be activated. A hot water demand always has priority, this means that the unit will switch to hot water operation. When the hot water demand remains for a longer period, there will be no heat supply for/to the central heating system during this period. Not supplying any heat for/to the central heating system might cause undesirable temperature fluctuations. The following parameters can be used to program the preferred settings.

P5 CL Low flow temperature time DHW (display B4)

The period during which the set point of the water flow temperature (to the heating coil(s) of the calorifier) will switch from "low" to "high".

P5 CF Max runtime DHW during CH demand

The programmed period for the boiler to operate for DHW demand in case of a CH demand. After this period the boiler will switch to operate for CH demand, even when there is still a DHW demand.

P5 CM Max runtime CH during DHW demand

The programmed period for the boiler to operate for CH demand in case of a DHW demand. After this period the boiler will switch to operate for DHW demand, even when there is still a CH demand.

The standard factory setting for this function is that the hot water demand always has priority and that no switching between the heat and hot water demand happens, when both are active.

11.3.6 HEATING AND HOT WATER SWITCHING AT SUDDEN TEMPERATURE DROP

This function can be used to detect indirect water tank/calorifier heat demand in case of a sudden temperature drop within the range between the set point and the (minimum) value at which the boiler is normally switched on. For this parameter is chosen the value of the temperature drop detected within one second, at which an immediate indirect hot water demand is activated.





11.3.7 ANTI-LEGIONNAIRES' DISEASE FUNCTION (PASTEURISATION)

This function can only be used for an "indirect" programmed boiler (parameter P4 AA = 1), on which a DHW program is active.

To prevent Legionnaires' disease the boiler (software) provides a function for heating up the hot water storage tank (once a week) to a higher water temperature then the normal active hot water set point. Also the period, that this "higher" water temperature function must be active, can be programmed.

NOTICE: The standard factory setting for this Legionnaires' disease (pasteurisation) function is "OFF". To activate this Legionnaires' disease function some parameters must be programmed by the manufacturer/supplier. The starting day and time of this Legionnaires' disease function can be programmed at the control panel of the boiler.

There are several parameters being used for this function. Three of these parameters are shown in the following graph.

With parameter P2 KI the heating (CH) demand can be interrupted to provide heat for the anti-Legionnaires' disease demand. When no interruption is activated the boiler will wait for the end of the heat demand before the anti-Legionnaires' disease function starts. The standard factory setting for this function is "OFF".



The settings of these parameters **P5 CI**, **P5 CJ** and **P5 CD** must be programmed according to the national and/or local anti-Legionnaires' disease preventing regulations.

The setting of these parameters can only be done by the manufacturer/supplier of the boiler or by a technician with access to programming level 2, at the control panel of the unit without the use of a computer.



NOTICE: The use and activation of this function won't guarantee a Legionnaires' disease free installation. The responsibility for a Legionnaires' disease free installation remains at the end-user/owner.

11.4 Cascade control

 \rightarrow

The following information is also found in the specific cascade manual, supplied standardly with Strebel cascade accessories or on request.

Before commissioning a cascade installation, a number of parameters have to be changed. These parameters can be programmed on the unit itself, without the use of a computer.



Changes in parameter may only be carried out by a skilled commissioning/service engineer, who has had specific training for setting up the Ambassador⁺ range boilers. He will be able to check whether the installation functions correctly after the parameter change has been done.

For programming **all parameters** of the boilers one needs to have a laptop with the appropriate EHS software and an interface cable for connecting the laptop to the boiler control (one order no.: S04.016.586). This software is used for programming but also shows all measured temperatures and cascade behaviour during operation and service/fault history.

11.4.1 PARAMETER SETTINGS FOR CASCADED BOILERS

Before programming the cascaded boilers, make sure that all boilers are connected (wire) with each other. Use connection 17 and 18 of each boiler.

Remind: do not alternate these connections, so always connect 17 to 17 and 18 to 18.

After connection every boiler must be programmed. This can be done at the control panel. Press the [MENU] button and select the [PARAMETER] menu. See graphics below.

Ор	era	ting	g so	cree	en:					-		_		_	_				
Н	Ε	Α	Т		Ν	G	1	S	Т	Α	Ν	D	•	В	Υ				
٧	٨	٨	•••	1	2	3	-	4	0	С	(1	2	3		4	0	С)
▼																			
Pre	ess	[M	ΕN	U]															
+		•																	
Ма	ain I	mei	าน เ	scre	een	:													
Μ	а	i	n		Μ	е	n	u											
S	е	t	р	0	i	n	t	s											
T																			
									1.0] ar								

After this, use the password for installer's level 2.

Pa	Iran	net	er r	ner	nu:				_				_			_	_	
	n	S	t	а			е	r		С	Ο	d	е					
								0	0	0	0							
		♦						♦	•	•	•							
									ne [anc	l th	е			
									t [E									
Th	e c	ode	e wi	ll b	link	a f	ew	sec	con	ds a	and	wh	nen	en	tere	ed		
со	rrea	ctly.	, the	e fo	llov	ving	g pa	arar	net	ers	wil	l be	dis	spla	aye	d.		



Now for every single boiler of the cascade the following two parameters must be selected and programmed according to the above drawing.

Master:	M	enu	C:	Ca	SCa	ade														
C5 P5 DF 1		С	5				С	а	s		S	i	1	Μ	а					
C2 P5 DA 0												0								
Slave 1: C5 P5 DF 0 C2 P5 DA 1	Th ca 0 :		oara de ngl	ame aliq le /	etei gnn Sla	r se nen ave	ets 1 It	he		of t nctio						ata	a			
Slave 2:		- 101	uoi		arm															
C5 P5 DF 0																				
C2 P5 DA 2 And so on.	M	enu	C:	Са	ISCa	ade														
		С	2				В	u	s		а	d	d	r	е	s	s			
												0								
	Th fo		oara e to	ame tal	ete cas	r de sca	eter din	mir g c	nes ont					• •		e bo	oile	r	-	

When the correct parameter is set, this must be confirmed at the confirmation screen. After activation, the value will blink for a few seconds while the parameter is programmed into the boiler.

When cascade connection is programmed correctly the boiler display will show the following.

Explanation "Cascade communication indicator" NO CASCADE COMMUNICATION



Always showing the fixed ">>>"

CORRECT CASCADE COMMUNICATION



Showing alternating no.1 & no.2 with 1 second interval.

11.4.2 MONITOR SCREENS

To obtain cascade information, see § 10.4 on page 47.

11.4.3 OUTPUT CONTROL AND BOILER SEQUENCE

The total cascade set-up will act as one single big boiler, switching on- and off boilers, depending on the total load necessary to adjust and keep the flow temperature at the calculated value.

When the heat demand rises, more boilers are switched on, and when heat demand falls, one or more boilers will be switched off. The boiler that was switched on last, will be switched off first, see table below.

To distribute operating hours equally over all boilers, the working sequence of the boilers will change every two hours.

Hour	Switching ON sequence	Switching OFF sequence
х	Master – Slave 1 – Slave 2 – Slave 3 – Slave 4 – Slave 5 – Slave 6 – Slave 7	Slave 7 – Slave 6 – Slave 5 – Slave 4 – Slave 3 – Slave 2 – Slave 1 – Master
X+2	Slave 7 – Master – Slave 1 – Slave 2 – Slave 3 – Slave 4 – Slave 5 – Slave 6	Slave 6 – Slave 5 – Slave 4 – Slave 3 – Slave 2 – Slave 1 – Master – Slave 7
X+4	Slave 6 – Slave 7 – Master – Slave 1 – Slave 2 – Slave 3 – Slave 4 – Slave 5	Slave 5 – Slave 4 – Slave 3 – Slave 2 – Slave 1 – Master – Slave 7 – Slave 6
X+6	Slave 5 – Slave 6 – Slave 7 – Master – Slave 1 – Slave 2 – Slave 3 – Slave 4	Slave 4 – Slave 3 – Slave 2 – Slave 1 – Master – Slave 7 – Slave 6 – Slave 5

Table: boiler sequence example of an eight boiler cascade.

In this table a total of eight boilers (one master, seven slaves) is mentioned as an example, in practice the maximum number in a cascade, without extra (external) control, is twelve boilers.

12 COMMISSIONING THE BOILER

12.1 First: flushing the boiler with water

After installation of the boiler the first step, before commissioning, is to flush the boiler and the whole heating installation with fresh water to remove pollution, debris and other materials that might cause a blocking. This must also be done with heating installations, where only the boiler is replaced.

12.2 Second: filling & venting the boiler and the system

After flushing the boiler and the installation the system can be filled with fresh water. Fill the boiler and the heating system by using the appropriate filling valve. The water pressure of the system normally lies between 1,5 and 2,0 bar – see § 6.14 'Water pressure' on page 20.

NOTICE: Use the following aspects to prevent corrosion of the central heating system:

- Filling water: Do not use any additives for the water of the central heating system. The pH value of the water should be more than 5 (If this pH value is less, please contact the supplier).
- Ensure that any used "plastic" pipes are oxygen diffusion-proof in accordance with DIN 4726/4729. If not, make sure that the boiler circuit is separated from the heating circuit by a plate heat exchanger. This way no oxygen that entered the heating system through these pipes can reach the boiler.
- Check the total heating system for any leaks. This to prevent oxygen entering the system through these leaks.

The boiler has an automatic air vent situated on top. This vent must be opened during the filling of the boiler and the heating system to make sure that no air/oxygen is trapped in the heat exchanger of the boiler. NOTICE: Check that the screw cap has been loosened at least one twist. Shortly after putting the boiler into operation, check the water pressure and add or lose some water to obtain the required pressure.

During these proceedings, make sure that no water can enter the boiler and make contact with the electrical parts.

12.3 Third: check the water flow

Before the boiler will be started it must be sure that the boiler pump is functioning and that there is a water flow over the heat exchanger. Check the electrical power supply of the boiler; if this is connected correctly, the display will show:

Display mess	age	В	0	i	Ι	е	r		0	f	f										
Reason	Boiler i	is r	not	act	ive.	То	ac	tiva	te t	he	boil	err	ores	s [()NC	/OF	F1	butt	on	for	six
	second											- r									<u></u>

Display messa	ge	Н	Ε	Α	Т	Ι	Ν	G	:	b	0	i	I	е	r		0	f	f			
		>	٨	>	:	1	2	3	-	4	0	С	(1	2	3	-	4	0	С)	
Reason	Boiler	is :	star	ndby	<u>у</u> . Т	o a	ctiv	ate	the	bo	biler	pre	ess	10]	<u> </u> /0	FF]	bu	tton	for	th	ree	

seconds.

Activate the boiler by pressing the [ON/OFF] button for six resp. three seconds. After this the following display will appear:

Display message	Н	Ε	Α	Т	I	Ν	G	:	Ν	0		d	е	m	а	n	d			
	>	>	>	:	1	2	3	-	4	0	С	(1	2	3	-	4	0	С)
Reason Bo	iler is a	activ	ve, I	but	the	re is	s no	he	at c	dem	and	ł.								

When no water is present in the boiler or the water pressure is too low or high, the boiler will go into lock-out and will show a corresponding message in the display.

By pressing the [SERVICE] button of the boiler, the boiler can be started without a heating demand. The boiler will start to fire and also the pump will start to run. Firing of the boiler without water flow (but filled with water!) will cause the so called "boiling noises". Check during this "service function" operation also the flow and return temperatures of the boiler by pressing the [**4**] button once. The temperature difference of the flow and return must be between 13°C and 25°C at high fire. This temperature difference indicates that there is a sufficient water flow over the boiler; this water flow protects the heat exchanger against possible damage caused by a thermal overload.

Another safety feature of the boiler, to make sure that there is enough water flow over the boiler, is the monitoring of the flow and return temperatures (T1 and T2). When the temperature difference (delta T) between the flow and return exceeds a certain (set) value, the following warning messages will be shown in the display.

9	I U I	 I U	9	9 9),	5	h	r	s

Reason Temperature difference T2-T1 has exceeded the blocking value, as set in the parameters.

Display messa	age	d	Т		В	I	0	С	k												
													9	9	9	,	5		h	r	s
Reason	Temp	erat	ure	dif	fere	ence	• T1	-T2	2 ha	s e	xce	ede	d th	ne b	loc	king	j va	lue			

When the T1-T2 value exceeds the lock-out setting, the boiler will switch off and the following lock out code will be shown at the display.

Display message	F	I	ο	w	R	е	t	u	r	n	d	t		f	а	u	Ι	t	
F16	р	u	m	р		0	n				9	9	9	,	5		h	r	s

Reason Temperature difference T1-T2 has exceeded the blocking value more than three times.

When these messages appear and/or the boiler will lock out, it means that there is not enough flow over the boiler. In this case check the functioning of the pump.

The boiler has no built in water-flow switch. If there is the possible risk of a water-flow blockage of the (external) heating system, the following pre-cautions can be taken to ensure a water flow over the boiler:

• Separate the boiler circuit from the (external) heating circuit by using a low loss header or plate heat exchanger.

During and after the commissioning of the boiler, the operation of the boiler pump must be checked, before leaving the installation room.

NOTICE: Always check the running of the pump before firing the boiler.

STARTING THE BOILER 13

13.1 General

Check the gas pressure available at the gas connection pipe of the boiler. Use the pressure nipple (3) of the gas safety valve for this measurement.

The graphs on page 95 show the position of the pressure nipple (3) for the complete boiler range.

The gas input pressure for the boiler to operate properly under the correct load must be more than 20 mbar at high fire.



For Ls gas G2.350, used in parts of Poland, a B+J gas valve must be installed in the A⁺80, A⁺100, $A^{+}150$ and $A^{+}180$ boilers. See also page 93 ff. and page 96.

13.2 Firing for the first time

After the commissioning of the boiler and the described previous actions, the boiler display will show the following graph.

Display message	Н	Ε	Α	Т	I	Ν	G	:	Ν	ο		d	е	m	а	n	d			
	>	۷	>	:	1	2	3	-	4	0	С	(1	2	3		4	0	С)
Reason	Bc	iler	is a	activ	∕e,∣	but	the	re is	s no	he he	at o	dem	and	J.	_	-	-			

Boiler is active, but there is no heat demand.

The display describes:

- The actual operation for heating or hot water
- If there is a heat demand activated
- The temperature setting •
- The temperature measured

When mounting the bottom part of the siphon, before commissioning the boiler and/or after maintenance, it must ALWAYS be completely filled with water.



This is a safety measure: the water in the siphon keeps the flue gases from leaking out of the heat exchanger via the condensate drain.



When the boiler receives a heat demand the electronics will start the operation of the boiler. Before the boiler is used, the boiler burner must be adjusted and set at the minimum and maximum load.

ADJUSTING AND SETTING THE BURNER 14



Before carrying out any adjusting of the burner, carefully read this complete chapter.

14.1 Introduction

The burner must <u>always</u> be adjusted in the next situations:

- A new boiler is installed Α.
 - As part of a service/maintenance check, in case the CO₂ values turn out to be incorrect

Adjustment procedures for situation A are described in § 14.2.

- B. The gas control safety valve has been (re)placed
 - Another type of gas is applied: gas conversion

Adjustment procedures for situation B are described in § 14.3.

In either of the four cases described in **A** and **B**, always check the gas/air ratio of the combustion figure (CO₂) at maximum and minimum input. First set the boiler at maximum load and subsequently at minimum load, and repeat if necessary.

Gas types and valves

The right type of valve must be selected, depending on the gas type. Gas types G20, G25 and G31 are commonly used; the boilers are standard equipped with the A+C-class valves required for these types of gas.

Poland

Gas types G27 and G2.350 are Lw and Ls gases, used in some parts of Poland. For Ls gas G2.350, the boilers S-CB *80, S-CB *100, S-CB *150 and S-CB *180 must be equipped with B+J-class valves, see table 3 and see the pictures on page 96.

Set-up of this chapter:

First, all necessary values are given in three tables in § 14.1.1. A drawing of the gas valve(s) and setting screws is given in § 14.1.2 on the next page. In § 14.1.4 a general scheme, conform which the adjustments must be carried out, is presented in table form. After that, in §§ 14.2 and 14.3, a thorough description is given of how to proceed in cases A and B respectively. In § 14.4, finally, two main procedures used in the previous sections are described in detail.

14.1.1 ADJUSTMENT TABLES

Tablad

Table 1				gas type:	
boiler type	load	output	G20 ¹ , G25 ¹ , G27 ¹ , G2.350 ¹	propane ³ G31 ¹	butane (B/P) ³ G30 ¹ /G31 ¹
	max. load	CO ₂ (%)	9,0	10,3	10,4
S-CB⁺ 60-120 ²	max. ioau	O ₂ (%)	4,8	5,2	5,3
3-CB 00-120	min. load	CO ₂ (%)	8,7	9,3	9,3
	min. Ioau	O ₂ (%)	5,3	6,7	6,9
	max. load	CO ₂ (%)	9,0	10,4	10,5
S-CB ⁺ 150 ²	max. ioau	O ₂ (%)	4,8	5,0	5,2
3-08 130	min. load	CO ₂ (%)	8,7	9,3	9,3
	min. Ioau	O ₂ (%)	5,3	6,7	6,9
	max. load	CO ₂ (%)	9,0	10,5	10,6
S-CB ⁺ 180 ²	max. ioau	O ₂ (%)	4,8	4,7	4,9
3-08 100	min. load	CO ₂ (%)	8,7	9,3	9,3
	nini. Ioau	O ₂ (%)	5,3	6,7	6,9
4					

Cf. EN437. (G27 and G2.350 for Poland)

 2 All values are measured without boiler door

³ Fan settings must be changed by altering parameter P4BD (display D8) (only by a skilled mechanic)

For <u>adjustment</u> use CO₂ tolerance of $\pm 0,1\%$ (for O₂ this is $\pm 0,2\%$).



For Ls gas G2.350, used in parts of Poland, a B+J valve must be installed in the S-CB⁺ 80, S-CB⁺ 100, S-CB⁺ 150 and S-CB⁺ 180 boiler. See also page 96.

Table 2

pre adjustment settings gas valves

(G27 for Poland)

boiler	number	r of turns open (counter cl	ockwise)
type	nat. gas G20 / G25 / G27	propane G31	butane G30 (B/P)
S-CB ⁺ 60	1	0,5	0,25
S-CB ⁺ 80	1,5	0,75	0,5
S-CB ⁺ 100	3,5	1,5	1,25
S-CB ⁺ 120	2,25 *	1 *	0,75 *
S-CB ⁺ 150	2,25 *	1 *	0,75 *
S-CB ⁺ 180	4,25 *	2,25 *	2 *

* Both gas valves must be opened this number of turns.

Table 3

Gas valve settings for Ls gas G2.350 (for Poland)

	number	r of turns open (counter clo	ckwise)
boiler type	natural gas Ls G2.350	gas valve class	gas valve part n°:
S-CB ⁺ 60	1,25	A + C	No replacement
S-CB ⁺ 80	1,75	B + J	S04.000.393
S-CB ⁺ 100	4	B + J	S04.000.393
S-CB ⁺ 120	*2,5	A + C	No replacement
S-CB ⁺ 150	*2,5	B + J	S04.000.393
S-CB ⁺ 180	*4,5	B + J	S04.000.393

* Both gas valves must be opened this number of turns.

Table 4

Contact you boiler supplier for the right settings when converting to a not mentioned type of gas

Pressure adjustment settings LEFT valve

boiler		"p-out" pressure at gas valve	
type	nat. gas G20 / G25	propane G31	butane G30 (B/P)
S-CB ⁺ 120	-2 to 0 Pa	-4 to -2 Pa	-5 to -3 Pa
S-CB ⁺ 150	-2 to 0 Pa	-7 to -5 Pa	-8 to -6 Pa
S-CB ⁺ 180	-2 to 0 Pa	-7 to -5 Pa	-8 to -6 Pa



Maximum fan speed has to be reduced to convert the boiler into a propane or B/P appliance. Setting of parameter P4BD.

A sticker has to be pasted after converting the boiler into a propane or B/P appliance. Mark the used gas and the parameter setting on this sticker.

G31 P	PROPANE PROPAN PROPANO PROPAAN	P4BD = 1	
G30/G31 B/P	BUTANE/PROPANE BUTAN/PROPAN BUTANO/PROPANO BUTAAN/PROPAAN	P4BD = 2	

See § 14.3 on page 98.

14.1.2 SETTING SCREWS GAS VALVE(S): DRAWINGS

^•••

NOTICE: Do NOT mistake the screw marked 'PILOT' for screw 2. \rightarrow Screw 2 is the SMALL screw <u>immediately next to</u> the pilot screw.



14.1.3 Gas value classes A+C and B+J (B+J only for Poland)



These pictures show the difference between an A+C and a B+J valve. Notice the class being denoted on the ID plate of the valve.

14.1.4 ADJUSTMENT ACTIONS: GENERAL SCHEME

General scheme for adjustment of the gas valve(s). Check this scheme for an overview. To complete all necessary adjustments in right order, follow case **A** <u>or</u> **B** top-down through the scheme (**B** involves a few extra steps (grey text blocks)):

	GENERAL SCHEM	E SETTING S	STEPS
	case A new boiler or service check		case B valve replacement or gas conversion
	continue ↓		oth*) screw(s) [2], then set ordance with table 2
	SWITCH TO SI	ERVICE MOD	θE
	continue ↓	If burner doe screw[2] ¼ t	esn't start, open (RIGHT*) urn extra
	setting at ma	aximum load	
	[▲] set burner a	t maximum lo	ad
procedure 1	measure CO₂ at use (RIGHT* match value co2↓ co2↑) screw [2] to with table 1	et;
	setting at m	inimum load	
	continue ↓	<u>only</u> → S-CB ⁺ 120, ⁺ 150, ⁺ 180	[▼] set burner at minimum load use LEFT screw [1] to match "p-out" with table 4
	[▼] set burner at minimum load		
procedure 2	measure CO₂ at use (RIGHT* match value co2↓ co2↑) screw [1] to	et;
	1	dure 1	
	repeat proce		
	repeat proce repeat proce	edure 2	
		edure 2	alues best

* in case of a double valve (S-CB⁺120, S-CB⁺150 and S-CB⁺180)

For an extensive description consult the next two sections (choose which is applicable, **A** or **B**):

14.2 Adjusting in case of a new boiler, or after maintenance (case A)

14.2.1 GENERAL REMARK

For all adjusting steps under **A** the following must be applied: as long as measured CO₂ values differ less than 0,3% from the table values, no adjustment is necessary, because this deviation is typical for the process (O₂ values: \pm 0,5%). If, however, larger deviations are measured, adjustment now must be made until the table value is reached within max. 0,1% deviation (O₂: \pm 0,2%).

14.2.2 CHECKING AND ADJUSTING AT MAXIMUM LOAD

Adjust at maximum load by carrying out procedure 1 on p.100.

14.2.3 CHECKING AND ADJUSTING AT MINIMUM LOAD

Adjust at minimum load by carrying out procedure 2 on p.100.

14.3 Adjusting in case of valve replacement or gas conversion (case B)



Maximum fan speed has to be reduced to convert the boiler into a propane or B/P appliance. Setting parameter P4BD.

14.3.1 GENERAL REMARKS

In case **B**, a distinction is made between the setting of boilers containing a single valve (S-CB⁺60 to S-CB⁺100) and boilers with a double valve (S-CB⁺120 to S-CB⁺180).

All adjustments must result in CO₂ percentages within a bandwidth of max. \pm 0,1% deviation from the table values (O₂: \pm 0,2%).

14.3.2 CHECKING AND ADJUSTING AT MAXIMUM LOAD S-CB⁺60 / S-CB⁺80 / S-CB⁺100

The boilers S-CB⁺60, S-CB⁺80 and S-CB⁺100 all have single gas valves, see the drawings on page 94.

- First, turn setting screw [2] of the gas valve clockwise until you feel resistance. This means that the valve is closed, do not try to tighten the screw any further.
- Now turn screw [2] counter clockwise (open), according to the number of turns in table 2 or 3 for the used boiler and gas type.

After this, adjust at maximum load by carrying out procedure 1 on page 100. If the burner doesn't start up in service mode, turn screw [2] a quarter turn counter clockwise further open, and try again.

14.3.3 CHECKING AND ADJUSTING AT MINIMUM LOAD S-CB⁺60 / S-CB⁺80 / S-CB⁺100

Adjust at minimum load by carrying out procedure 2 on page 100.

IMPORTANT: Toggle between high fire and low fire to make fine-tuning adjustments (adjusting the minimum setting affects the maximum setting and contrariwise).



In case of gas conversion, paste the corresponding sticker at the appropriate position in the boiler and mark the square for the used gas type. Also mark the square, indicating that the correct value has been set for parameter P4BD.

(In the example on the right, 'propane' and 'P4BD = 1' have been marked).



For adjusting double gas valves S-CB⁺120 / S-CB⁺150 / S-CB⁺180 see next page \rightarrow

14.3.4 CHECKING AND ADJUSTING AT MAXIMUM LOAD S-CB⁺120 / S-CB⁺150 / S-CB⁺180

The boilers S-CB⁺120, S-CB⁺150 and S-CB⁺180 all have double gas valves, see the drawings on page 94.

First connect a manometer to "p-out" = measuring point [4] of the left gas valve (see drawing).

- Now, turn setting screws [2] of <u>both gas valves</u> clockwise until you feel resistance. This means that the valves are closed, do not try to tighten the screws any further in the closed position.
- After this, turn screws [2] of <u>both left and right hand gas valve</u> counter clockwise (open), according to the number of turns in table 2 or 3 for the used boiler and gas type.

From now on only use the right hand gas valve for adjustments on high fire.

Adjust the right value at maximum load by carrying out procedure 1 on page 100. If the burner doesn't start up in service mode, turn screw [2] a quarter turn counter clockwise further open, and try again.

14.3.5 CHECKING AND ADJUSTING AT MINIMUM LOAD S-CB⁺120 / S-CB⁺150 / S-CB⁺180

Adjusting these boilers at minimum load in case B involves extra measurements, to get both valves balanced:

Use the $[\mathbf{V}]$ button to decrease the actual load of the service (percentage) to the minimum. The following screen will appear:

Display message	Η	Ε	Α	Τ	I	Ν	G	:	S	е	r	v	i	С	е			2	6	%
	٨	۸	٨		1	2	3	•	4	0	С	(1	2	3	•	4	0	С)

Boiler is activated and operates at service mode at 26% (minimum).

See table 4 for pressure settings "p-out" gas valve for the used boiler and gas type. Use screw [1] on the **left hand** gas valve to adjust the measured pressure at "p-out" to the right value according to table 4. Be sure the manometer has been zeroed out prior to making this setting.

Below, the influence of turning screw [1] is described.

Turning counter clockwise	\rightarrow	less gas	\rightarrow	a drop in CO ₂	\rightarrow	a drop in measured pressure at "p-out"
Turning clockwise	\rightarrow	more gas	\rightarrow	a rise in CO ₂	\rightarrow	a rise in measured pressure at "p-out"

After "p-out" has been set cf. table 4, use only the **right hand** screw [1] for setting the CO₂ at low fire.

Adjust the **right hand** valve at minimum load by carrying out procedure 2 on page 100.

Again, toggle between high fire and low fire to make fine-tuning adjustments (adjusting the minimum setting affects the maximum setting and contrariwise).

If the valves have been set correctly, "p-out" left should equal "p-out" right. As an additional test, one could check this by measuring "p-out" at the RIGHT valve, i.e. at measuring point 4 on the right valve (not denoted in the drawings on page 95).

This pressure should be in the same range of pressure as the left valve, so in accordance with table 4 again.

If, after all setting steps have been carried out properly, the values of left and right "p-out" are still very different, contact your supplier.

14.4 Adjusting procedures

Procedures 1 and 2, referred to in the previous sections 14.2 and 14.3, are described here:

Procedure 1: adjust at maximum load

In case **B** (replacement of gas valve or gas conversion): consult § 14.3. before starting procedure 1 below.

Carry out the next 4 steps:

1. Press [SERVICE] button for about 3 seconds.

Display message	Н	Ε	Α	Т	Ι	Ν	G	:	S	е	r	v	i	С	е			2	6	%
	٨	٨	٨		1	2	3	•	4	0	С	(1	2	3	•	4	0	С)

Boiler is activated and operates at service mode at 26% (minimum). (example)

2. Press [▲] button until maximum load is reached:

Display message	Н	Ε	Α	Т	Ι	Ν	G	:	S	е	r	v	i	С	е		1	0	0	%
	>	۷	۷		1	2	3	•	4	0	С	(1	2	3	-	4	0	S)

Boiler is activated and operates at service mode at 100% (maximum). (example)

- 3. Measure the CO_2 percentage at the flue gas outlet.
- 4. By setting screw [2], adjust the gas valve to obtain the CO₂ value of table 1.
 - NOTICE: For the A⁺120, 150 and 180 boilers use only the RIGHT side gas valve for adjusting.

Decrease CO₂ percentage



Turn screw [2] right (clockwise)

Increase CO₂ percentage

Turn screw [2] left (counter clockwise)

The service operation of the boiler will be active for 40 minutes. After this period the boiler will return to normal operation.

Procedure 2: adjust at minimum load

In case **B** (gas conversion or replacement of gas valve): consult § 14.3. before starting procedure 2 below.

Carry out the next three steps:

1. Press [▼] button until minimum load is reached.

Display message	Н	Ε	Α	Т	Ι	Ν	G	:	S	е	r	v	i	С	е		2	6	%
	٨	>	٧		1	2	3	•	4	0	С	(1	2	3	4	0	С)

Boiler is activated and operates at service mode at 26% (minimum).

- 2. Measure the CO_2 percentage at the flue gas outlet.
- 3. By setting screw [1], adjust the gas valve to obtain the CO₂ value of table 1. NOTICE: For the S-CB⁺120, 150 and 180 boilers use only the RIGHT side gas valve for adjusting.

Decrease CO₂ percentage

Increase CO₂ percentage



Turn screw [1] left (counter clockwise)

Turn screw [1] right (clockwise)

The service operation of the boiler will be active for 40 minutes. After this period the boiler will return to normal operation.

15 PUTTING THE BOILER OUT OF OPERATION

It is recommended to have the boiler operational all year round to prevent any frost damage during the winter and/or rotating parts getting jammed during other times of the year (built in boiler safety features).

15.1 Out of operation: on/off function

To be used when the appliance must be put out of operation for a long period because of a defect or another safety risk.

Act as follows:

- Disconnect or switch off the room thermostat and/or other external controllers from the boiler. The CH pump and fan will stop after a short time.
- Switch off the boiler by pressing the [ON/OFF] button for six seconds.
- Make sure that the following display screen is visible.

Display message	В	0	i	I	е	r	0	f	f					

Properties of the 'off' function:

- •The keys do NOT respond and the menu is NOT accessible.
- •The burner does NOT respond to an external heat demand.
- •The boiler CAN, however, be switched on again by pressing the [ON/OFF] button.
- •Pumps, fans and cascade (if applicable) are operational, and so are both recirculation protection (if applicable) and frost protection.
- •NOTICE: Pump 3 (CH pump) is switched OFF, but this is NOT the case when the boiler is in a cascade.
- •To reactivate the boiler, switch on the burner by pressing [ON/OFF] for six seconds again.



The frost protection module can still activate the burner.

To prevent this, switch off this protection or put the boiler in 'power off' mode.

15.2 Out of operation: power off

To assure that the boiler cannot become active at all anymore, power should be cut off completely.

Act as follows:

- Disconnect or switch off the room thermostat and/or other external controllers from the boiler. The CH pump and fan will stop after a short time.
- Switch off the boiler by pressing the [ON/OFF] button for six seconds.
- Make sure that the following display screen is visible.

Display message	В	0	i	I	е	r	ο	f	f					

- Switch off the electrical power supply of the boiler (remove connection from the wall socket, or switch off the main power).
- Close the gas valve / gas supply.
- In case of possible frost damage: drain both the boiler and the heating system.

NOTICE: Before starting to drain the boiler, first start draining the heating system and subsequently open also the two drains of the boiler.

16 FAULT CODES. BLOCKING CODES

16.1 Fault codes

IMPORTANT:

To avoid electric shocks, disconnect electrical supply before performing troubleshooting. To avoid burns, allow the unit to cool before performing troubleshooting.

Be aware that a fault code is an indication that the unit or the system needs attention. When repeatedly having faults these should not be neglected.

The first step is to check if the unit is installed according to the instructions. If not, first make sure the installation complies with the installation manual.

Always check the fuses on the control board before replacing any major components. A blown fuse can prevent the controller or other components from operating.

Most faults can also be caused by a bad wiring and/or connections, even if it is not specifically mentioned. With every fault it is wise to check wiring and connections (at both ends) that connect to the safety device/component that generates the fault.

LOCK-OUT CODES:

Having a lockout means that the boiler needs a manual reset to start operating again. When the boiler is in lockout the backlight of the display is blinking on and off.



Display message	F	Ι	ο	w		s	е	n	S	0	r		е	r	r	0	r			
F0	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason:	Flo	ow s	sens	sor	is n	ot c	dete	cte	d.											

Cause:

Bad wiring/connection in the flow sensor circuit.

Corrective action:

Check for loose wiring/connections in the flow sensor circuit.

Cause:

Bad temperature sensor causing a fault signal.

Corrective action:

Replace flow sensor.

Display message	F	I	ο	w		h	i	g	h		Т	е	m	р						
F1	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason:	Ma	ax. I	flow	ter	npe	rati	lre	exc	eec	ls li	mita	atio	n (lo	ock-	out	.) va	alue			

Cause:

The water flow is restricted. **Corrective action:** Check functioning of the pump. Check/open all valves that might restrict the water flow through the unit. Check for an external system pump that influences flow through the unit.

Check if the system resistance exceeds the spare capacity of the unit pump.

Display message	R	е	t	u	r	n		h	i	g	h		Т	е	m	р			
F1	р	u	m	р		ο	n					9	9	9	,	5	h	r	S
Reason:	Ма	axin	num	n ret	turn	ter	npe	ratu	ıre	exc	eec	ls li	mit	valu	ue.				

Systems that pre-heats the boiler return temperature too much/high.

Corrective action:

Reduce pre heat temperature of external heat source.

Cause:

The need for heat in the system suddenly drops causing hot return water to the boiler. **Corrective action:**

Dampen external heating system control to prevent sudden boiler temperature rise.

Display message	L	а	С	k		ο	f		w	а	t	е	r						
F2	р	u	m	р		0	n					9	9	9	,	5	h	r	s
Reason	No	o ter	npe	erat	ure	rise	e me	eas	ure	d du	urin	a fir	ina.						

Cause:

When the unit starts firing it expects to measure a temperature rise. If this temperature rise is not detected, there is suspicion that there is no medium (water) present, to transfer heat from combustion to the sensor.

The lack of water can cause this fault when the unit is firing.

Corrective action:

Make sure there is water present in the unit before firing.

Display message	R	е	t	u	r	n		s	е	n	s	0	r		е	r	r	0	r	
F3	р	u	m	р		ο	n					9	9	9	,	5		h	r	s
Reason	Re	etur	n se	enso	or is	s no	t de	etec	ted	bv '	the	boi	ler	PCE	3.					

Cause:

Bad wiring/connection in the return sensor circuit.

Corrective action:

Check for loose wiring/connections in the return sensor circuit.

Cause:

Bad temperature sensor causing a fault signal.

Corrective action:

Replace return sensor.

Display message	F	I	u	е		s	е	n	s	ο	r		е	r	r	0	r			
F6	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason	FΙι	le s	ens	sor i	is n	ot d	ete	cteo	d by	/ the	e bo	biler	PC	B.		_	_	_	_	

Cause:

Bad wiring/connection in the flue gas sensor circuit.

Corrective action:

Check for loose wiring/connections in the flue gas sensor circuit.

Cause:

Bad temperature sensor causing a fault signal.

Corrective action:

Replace flue gas sensor.

Display message	F	I	u	е		t	е	m	р		t	0	0		h	i	g	h		
F7	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason	Flu	le c	jas	tem	nper	atu	re e	exce	ede	ed 3	3 tin	nes	lim	itati	on	valu	le v	vith	in	
	аc	cert	ain	per	iod.															

Heat exchanger polluted and not able to transfer enough heat to system water.

Corrective action:

Check and clean heat exchanger.

Cause:

Bad flue gas sensor or sensor connection (partly shorted).

Corrective action:

The sensor is of the type NTC. This means if the temperature rises, the resistance lowers. A partly shorted sensor will drop its resistance and therefore 'measure' a raise in temperature when actually there is none.

Check for moist in the sensor connections or replace sensor.

Cause:

There is no water in the unit while firing.

Corrective action:

This is an unlikely situation while all the safeties for checking the water presence didn't detect anything. Only a lot of air in the system/unit (under pressure) can cause the water pressure switch to switch while no water is present. Also the water leak detection did not react. Bleed all air from the unit so the heat from combustion can be transferred to the water and won't disappear through the flue system.

Cause:

Heat exchanger failure.

Corrective action:

This is an unlikely situation but when there is severe damage to the heat exchanger, the combustion product will not be able to transfer all heat to the system water. The heat that is not transferred will convert to an increased flue gas temperature.

Display message	F	а	i	I	е	d		b	u	r	n	е	r		s	t	а	r	t	
F8	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason	Во	iler	not	ор	era	tion	al a	fter	fou	ır st	tarti	ng	atte	mp	ts.					

Cause:

No spark.

Corrective action:

Check the ignitor/ignition electrode and replace/clean if necessary.

Check the state of the ceramic insulator. A small crack can prevent the spark to form at the end of the electrode.

Check the distance between the electrode pin, earth pin and burner.

Check the state of the ignition cable and replace if necessary.

Check the state of the earth wire/connection of the ignitor and replace if necessary.

Check the state of the sparkplug cap and replace if necessary.

Check power supply. Voltage must be 230 Vac nom.

Check for proper electrical grounding of unit.

Bad ignition transformer. Replace the burner control of the unit.

 $F8 \rightarrow$ Cause:

Ignition spark is present, but no flame results.

Corrective action:

Check if all gas valves in the supply line are completely open.

Check if there is no air in the gas supply (start-up new systems).

Check if the gas valve opens. When there is power supply to the gas valve, but the valve does not open, the gas valve must be replaced.

Check if the gas valve opens. When there is no power supply to the gas valve check the gas valve wiring/connections.

Check if the gas valve settings are correct and adjust if necessary.

Check if the gas pressure is correct and sufficient.

Check if the air supply is open/not blocked.

Cause:

Flame, but not enough ionisation to establish the flame.

Corrective action:

Check the ignitor/ignition electrode and replace/clean if necessary.

Check the state of the ceramic insulator.

Check the distance between the electrode pin, earth pin and burner.

Check the state of the ignition wire (also the ionisation wire) and replace if necessary.

Check the state of the earth wire/connection of the ignitor and replace if necessary.

Check for proper electrical grounding of unit.

Check power supply. Voltage must be 230 Vac nom.

Check the state of the sparkplug cap and replace if necessary.

Display message	F	I	а	m	е		Ι	0	s	t									
F9	р	u	m	р		ο	n					9	9	9	,	5	h	r	s
Reason	Fla	ame	sic	nal	los	t du	irin	a or	bera	atior	า.	-	-	_	_	-	 _		

Cause:

Bad gas supply pressure.

Corrective action:

Be aware that the specified gas pressure must be met during all operation conditions. Check if all gas valves in the supply line are completely open.

Check if the dirt filters mesh in the gas valve inlet is clean.

Check if the external dirt filter in the gas supply line is not blocked.

Check if an external gas pressure regulator is selected/installed correctly.

Check the gas pressure that is supplied to the building > call the supplier if necessary.

Cause:

Bad gas valve or gas valve settings.

Corrective action:

Check and set gas valve settings.

Cause:

Bad electrode, electrode wiring/connection (bad ionisation signal).

Corrective action:

Check ionisation signal.

Check the ignitor/ignition electrode and replace/clean if necessary.

Check the state of the ceramic insulator.

Check the distance between the electrode pin, earth pin and burner.

Check the state of the ignition wire (is also ionisation wire), and replace if necessary

Check the state of the ignitor earth wire/connection and replace if necessary.

Check for proper electrical grounding of unit.

Bad flue gas and/or air supply system.

Corrective action:

Check if the design of the flue gas and air supply system complies with the max. combined resistance as specified.

Check if the flue gas and air supply system is installed according a good installation practice by a skilled installer.

Check all seals in the flue gas and air supply system.

Cause:

External factors.

Corrective action:

Check if there were extreme weather/wind conditions when the fault occurred.

Check if the boiler room pressure is equal to the pressure at the position of the flue gas outlet (when combustion air is drawn from the boiler room).

Display message	F	а	Ι	s	е		f	Ι	а	m	е		S	i	g	n	а	I		
F10	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason	Fla for		-			tect	ed,	wh	ile k	ooile	er s	hou	ld r	not f	fire					

Cause:

The flame detection circuit detects a flame which is not supposed to be present.

Corrective action:

Check the ignition/ionisation electrode and make sure it is clean (or replace it).

Check the power supply voltage for a correct polarity.

Check the power supply for bad frequency or voltage peaks.

Check external wiring for voltage feedback.

Check the internal wiring for bad connections.

Check if the gas valve is closing correctly.

Replace the burner control.

Display message	F	а	n		s	р	е	е	d		i	n	С	0	r	r	е	С	t	
F11	р	u	m	р		0	n					9	9	9	,	5		h	r	S
Reason	Ac	tua	l far	n sp	eed	d dif	fers	s fro	om t	he	unit	t rpr	n s	et p	oin	t.				-

Cause:

An incorrect fan speed is detected.

Corrective action:

Check the 4 wired wiring and connections at the fan and at the main control board. Check the 3 wired power supply wiring and connections at both ends. Replace the fan.

Replace the main control board.

Display message	р	r	ο	g	r	а	m	m	i	n	g		е	n	d					
F12	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason	Pr	ogra	amr	ning	g of	the	e pa	ram	nete	ers o	com	ple	ted	suc	ces	ssfu	lly.			

Cause:

Programming of the parameters completed successfully.

Corrective action:

This message occurs to confirm the end of programming. Pressing RESET will return the unit in normal operating status.

Display message	Ρ	а	r	а	m	1	Η	а	r	d	w		f	а	u	I	t			
F13	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason	Fa	ilure	e du	Irin	g pi	rogr	am	min	g o	f the	e pa	arar	net	ers.			-	_	_	
Cause:	parameters NOT successfully completed.																			
Programming of the parameters NOT successfully completed.																				
Programming of the parameters NOT successfully completed. Corrective action:																				
Unit is not in standby n Check programming w Check if the software of Replace the programm Replace the display PO	ire : com ning	and plie	coi s w	nne	ctic	ns	and					nmi	ng)							

Display message	С	I	i	x	0	n		F	а	u	I	t								
F15	р	u	m	р		0	n					9	9	9	,	5		h	r	s
Reason				han 'alu	0	fus	e o	r bu	irne	er do	oor	clix	on e	exce	eed	ed i	max	kimu	JM	

The thermal fuse of the heat exchanger has opened permanently.

Corrective action:

Switch off the electrical power and gas supply and contact supplier.

Cause:

The burner door clixon has opened.

Corrective action:

Remove the burner door of the heat exchanger and check the burner door gasket for leakage.

Check the burner door for deformation; when it deforms it must be replaced.

Check the heat exchanger for dirt and check that the flue is not blocked.

If heat exchanger is clean, reset manually the clixon itself and reset the boiler.

Display message	F	I	0	w	R	е	t	u	r	n		d	t		f	а	u	I	t	
F16	р	u	m	р		0	n					9	9	9	,	5		h	r	S
											flo\ Risł								ni-	

Cause:

The water flow through the unit is too low.

Corrective Action:

Check functioning of the pump.

Check/open all valves that might restrict the water flow through the unit. Check for an external system pump that influences the flow through the unit. Check if the system resistance exceeds the spare capacity of the unit pump. Make sure the heat exchanger is clean. Heat exchanger fouling (partly blockage) will increase the resistance causing the water flow to drop.

Display message	W	а	t	е	r		h	i	g	h		I	i	m	i	t			
F17	р	u	m	р		0	n					9	9	9	,	5	h	r	s
Reason	Ma	axin	num	n the	erm	osta	at e	xce	eds	s lim	nitat	ion	val	ue.					

Cause:

The water flow is restricted.

Corrective action:

Check functioning of the pump.

Check/open all valves that might restrict the water flow through the unit. Check for an external system pump that influences the flow through the unit. Check if the system resistance exceeds the spare capacity of the unit pump.

Display message	S	i	р	h	0	n		S	w	i	t	С	h						
F19	р	u	m	р		0	n					9	9	9	,	5	h	r	s
Reason			n pr flue						tec	ts h	igh	pre	ssu	re					

There is too much resistance in the flue gas circuit causing high pressure in the heat exchanger at the flue gas side.

Corrective action:

Check if the flue gas system is blocked.

Extreme failing of the heat exchanger also causes the resistance to rise. Check the state of the heat exchanger and clean if necessary.

Check the flue gas system diameter & length (most likely in a new system).

Cause:

The condensate drain system is blocked. The condensate will build up above the measuring point of the pressure switch and creates a static pressure larger than the measuring point.

Corrective action:

Check if the condensate drain hose between the heat exchanger and the siphon is open, so the condensate can flow freely to the siphon.

Check if the siphon is free of debris that might block the condensate flow and clean the siphon if necessary.

Check the condensate drain hose between the siphon and the condensate drain point in the external installation. Condensate must be able to flow freely.

Cause:

The condensate drain hose must have an open connection to the external system. If not, pressure fluctuations in the building drainage system can have effect on the pressure in the heat exchanger of the boiler.

Corrective action:

Make sure that there is an open connection between the siphon hose and the drainage system of the building installation. The condensate should flow in the drainage system through a freely "breathing" connection, so pressure fluctuations of the external drainage system cannot affect the pressure in the heat exchanger of the boiler.

Cause:

Blockage of the pressure signal hose going to the pressure switch.

Corrective action:

Check the pressure signal hose and clean or replace if necessary.

Cause:

Bad pressure switch causing a fault signal.

Corrective action:

Replace the pressure switch.

Cause:

Bad wiring/connection in the pressure switch circuit.

Corrective action:

Check for loose wiring/connections in the pressure switch circuit.
16.2 Blocking codes:

The display is not blinking, but is lightened up during the blocking period. The boiler is blocking an action, because of an extraordinary situation. This action will be continued after stabilisation of this situation.

Display message	F	I	ο	w	t	е	m	р	h	i	g	h						
										9	9	9	,	5		h	r	s
Reason:				•			exce ock				ckin	ig te	emp	bera	ture	ə, b	ut it	1

Cause:																				
The water flow is restri	cte	d.																		
Corrective action:																				
Check functioning of th Check/open all valves Check for an external s Check if the system re	tha syst	t mi em	ght pu	mp	that	t inf	lue	nce	s th	e fl	ow	thro	ugł	n th	e ui	nit. np.				
Display message	R	е	t	u	r	n		t	е	m	р		h	i	g	h				
												9	9	9	,	5		h	r	S
Reason											d th lue.		locl	king	j ter	npe	erati	ure,	bu	ut it
Cause:																				
Systems that pre-heats	s th	e bo	oile	r ret	turn	ter	npe	erati	Jre	too	mu	ch/l	nigh	۱.						
Corrective action:																				
Reduce pre heat temp	erat	ture	e of	exte	erna	al h	eat	sou	rce											
Cause:																				
The need for heat in th	e s	yste	m	sud	den	ily c	lrop	S C	aus	ing	hot	ret	urn	wa	ter	to th	ne b	oile	er.	
Corrective action:																				
Dampen external heat	ing	sys	terr	n co	ntrc	ol to	pre	ever	nt si	udd	len l	boil	er t	em	pera	atur	e ri	se.		
		_									_	_		_						_
Display message	F		u	е		t	е	m	р		h	i	g	h						
												9	9	9	,	5		h	r	S
Reason	FΙι	le č	jas	tem	per	ratu	re h	nas	exc	eed	ded	the	lim	it.						
Cause:																				
Heat exchanger pollute	ed a	and	not	abl	le to	o tra	ansf	er e	enou	Jgh	hea	at to	b th	e sy	/ste	m v	vate	er.		
Corrective action:															·					
Check and clean heat	exc	har	ngei	r.																
Cause:																				
Bad flue gas sensor or	sei	nso	r cc	nne	ectio	on (par	tly s	shor	ted	l.)									
Corrective action:																				

The sensor is of the type NTC. This means when the temperature rises, its resistance decreases. A partly shorted sensor will drop its resistance and therefore 'measure' a raise in temperature when actually there is none.

Check for moist in the sensor connections or replace the sensor.

Cause:

There is no water in the unit while firing.

Corrective action:

This is an unlikely situation while all the safeties for checking the water presence didn't detect anything. Only a lot of air in the system/unit (under pressure) can cause the water pressure switch to switch while no water is present. Also the water leak detection did not react. Bleed all air from the unit so the heat from combustion can be transferred to the water and won't leave through the flue system.

Cause:

Heat exchanger failure.

Corrective action:

This is an unlikely situation but when there is severe damage to the heat exchanger, the combustion product will not be able to transfer all heat to the system water. The heat that is not transferred will convert to an increased flue gas temperature.

Display message	Α	n	t	i	С	у	С	I	е		t	i	m	е						
												9	9	9	,	5		h	r	S
Reason			ontr I de			cei	ved	ar	new	hea	at d	em	and	too	o fa	st a	fter	the	las	t

Cause:

Opening and immediately thereafter closing of the external thermostat.

Corrective action:

Controlled water flow cools down too quickly after loss of heat demand.

Controlled water flow heats up too quickly after start of heat demand.

Immediately opening and closing of the external thermostat. Check switching differential of the ON/OFF thermostat.

Controller settings need to be changed. Be aware that the standard settings work fine for all common systems. When anti-cycling is active, because of immediate heating or cooling of the controlled water flow/temperature, it concerns an unconventional system.

Display message	W	а	t	е	r	р	r	е	s	s	u	r	е		f	а	u		t	
												9	9	9	,	5		h	r	s
Reason	Wa	ater	pre	อรรเ	ıre	is to	oo l	ow	or h	igh										

Cause:

The water pressure in the system is too high.

Corrective action:

Check if the system pressure is too high after (re)filling.

Make sure that there is a pressure relief valve and expansion vessel installed in the system, according to the applicable standards.

Check if there is an open connection between the unit and the relief valve plus expansion vessel.

Be aware that if the unit is installed in the basement of a tall building, only the static pressure of the water column above the units can raise above the maximum allowable limits. Make sure that this is not the case.

Cause:

The water pressure in the system is too low.

Corrective action:

Check if there is no leakage in the system that causes the pressure to drop. Fix any leakage and fill the system.

Check if there is an external system pump that sucks water through the boiler, causing an under pressure (bad installation design).

Display message	L	i	n	е		f	а	u		t									
	р	u	m	р		ο	n					9	9	9	,	5	h	r	s
Reason	Ba	id p	owe	er s	upp	ly	-					-	-	-		-			
Cause:																			
The supplied power do	bes	not	cor	npl	y wi	th t	he s	spe	cific	atic	ons.								

Corrective action:

Check if the power supply is connected correctly to the unit.

Check the voltage and frequency (should be Life Neutral, Gnd > 230 Vac / 50 Hz). Make sure there is no signal failing or voltage peaks in the power supply.

Marce Sure there is ne	, sigi		ann	ing c		ona	gc .	pca	1.0 1		ic p	0,00	51.5	upp	iy.			
Display message	0	u	t	d	0	0	r		s	е	n	s	0	r		f	а	i

Display message	0	u	t	d	ο	ο	r		s	е	n	s	0	r		f	а	i	I	
												9	9	9	,	5		h	r	s
Reason	No	o ou	tdo	or s	ens	sor (dete	ecte	d.											

Cause:

The unit is programmed to check if an outdoor sensor is present and does not detect an outdoor sensor.

Corrective action:

Check for loose wiring/connections in the outdoor sensor circuit. Check the state of the outdoor sensor and replace if necessary.

Display message	d	Т	b	I	ο	С	k										
									9	9	9	,	5		h	r	s
Reason									v ar out v			rn h	as	exc	eed	ed	

Cause:

The water flow through the unit is too low.

Corrective action:

Check functioning of the pump.

Check/open all valves that might restrict the water flow through the unit.

Check for an external system pump that influences the flow through the unit.

Check if the system resistance exceeds the spare capacity of the unit pump.

Make sure the heat exchanger is clean. Heat exchanger fouling (partly blockage) will increase the resistance causing the water flow to drop.

Display message	G	е	n		В	I	0	С	k											
												9	9	9	,	5		h	r	s
Reason				oloc con		•		t is	acti	vat	ed o	duri	ng d	оре	rati	on (ger	nera	d	

Cause:

The circuit connected to the general blocking terminals is not closed.

Corrective action:

Check all external components that are connected to the general blocking terminals and check why the contact is not closing during heat demand.

Cause: if used in combination with flow switch:

The water flow through the unit is too low.

Corrective action:

Check functioning of the pump and the flow switch.

Check/open all valves that might restrict the water flow through the unit.

Check for an external system pump that influences flow through the unit.

Check if the system resistance exceeds the spare capacity of the unit pump.

Make sure the heat exchanger is clean. Heat exchanger fouling (partly blockage) will increase the resistance causing the water flow to drop.

Display message	С	а	s	С	а	d	е		В	T	ο	С	k							
												9	9	9	,	5		h	r	s
Reason	Or	ne c	of th	e b	oile	rs c	f th	e ca	asca	ade	is i	n a	loc	k-o	ut.					
Cause:																				
The unit is programm	ed ir	ı su	ch a	a wa	ay t	hat	nor	ne c	of th	e b	oile	rs i	n a	cas	cad	le w	/ill fi	ire,	if oı	ne
has a lockout. One ur	nit ha	is a	loc	kou	it ar	nd t	here	efor	e th	ie v	vho	le c	asc	ade	is l	bloc	ked	d.		
Corrective action:																				
Troubleshoot the fault	t of t	he ı	unit	in l	ock	-ou	t.													

16.3 Maintenance attention function

The display shows alternately the base screen and this message, while backlight is blinking.

The boiler is operating, but will count the exceeding hours.

A parameter must be changed, after service, to remove this message.

Display message	Ν	е	е	d	S		Μ	а	i	n	t	е	n	а	n			0	-	0
	I	g	n	i	t	i	0	n		C	у	С	-	е	s		h	r	S	
Reason		ainte ach		nce	ор	tion	of	tota	l ar	nou	int o	of ig	Initi	on d	cycl	es l	nas	bee	en	
Display message	Ν	е	е	d	s		Μ	а	i	n	t	е	n	а	n			0	•	0
	D	а	t	е													h	r	s	
Reason	Ma	ainte	ena	nce	ор	tion	of	the	dat	e h	as b	bee	n re	each	ned.					
Display message	Ν	е	е	d	s		Μ	а	i	n	t	е	n	а	n			0		0
	В	u	r	n	i	n	g		h	0	u	r	S				h	r	S	
Reason		ainte ach		nce	ор	tion	of	tota	l ar	nou	int c	of b	urni	ng	hou	rs h	nas	bee	en	
Display message	Ν	е	е	d	s		Μ	а	i	n	t	е	n	а	n			0		0
	Α	I	I														h	r	s	
Reason		ne o ach		e al	voc	em	enti	one	d n	hair	iten	anc	e o	ptio	ns	has	be	en		



This function/message is standard not activated, but can be activated/set by a trained engineer. This function does not overrule the need for annual maintenance. The end user is always responsible for arranging annual maintenance.

17 MAINTENANCE

17.1 General

For a good, safe and long-time operation of the boiler it is advised to carry out maintenance and service on the boiler at least once a year.

Maintenance and inspection of the boiler should be carried out at the following occasions:

- When a number of similar error codes and/or lock-outs appear.
- At least every twelve months maintenance must be done to ensure safe and efficient operation. Damage caused by the lack of maintenance will not be covered under warranty

MAINTENANCE REMINDER FUNCTION.

← See previous page.

BE AWARE : This function is standard turned off. We offer this programmable function to the installer to use as a reminder. Because it concerns a free programmable function the use of it cannot be used as an argument in warranty cases. Our units must be maintained every twelve months whatever the settings/working of this function. It is and remains the responsibly of the end user to have the unit maintained every twelve months.

For more information about this maintenance mode see section 10.14, 'Setting the maintenance specifications', page 62.

Service intervals

The normal service frequency for the boiler is once a year. Every year the boiler should be cleaned and checked, according to the maintenance procedures. If there is doubt whether the boiler is operating with the correct water and/or combustion air quality, it is advised that a first check is already executed after six months. This check serves to determine the frequency of the future services. The maximum interval between two services is a year.



INSPECTION AND MAINTENANCE MUST BE EXECUTED FOR A SAFE AND EFFICIENT OPERATION OF THE BOILER.

17.2 Inspection & maintenance

Inspection, maintenance and the replacement of boiler parts should only be done by a skilled service engineer. Apart from the maintenance proceedings it is advised to have a log chart for every boiler that describes the following aspects:

- Serial number
- Date and time of maintenance
- Name of maintenance engineer
- Which parts were exchanged during maintenance
- Which settings (software) were changed during maintenance
- Special remarks / findings
- Future aspects that need extra attention
- Additional aspects: measurement reports, complaints by the (end)-user, lock-out codes, etc.

During maintenance the following parts and aspects of the boiler should be checked and inspected. NOTICE: Before starting to work on the boiler:

- Switch off the electrical power to the boiler (service switch and/or unplug boiler)
- Close the gas valve to block gas supply to the boiler

Customer comments

Comments and remarks from the customer should be analysed and used to find possible causes for any occurring problems and complaints.

Service history

The operational and fault history (total amount and since the last service) of the boiler can be retrieved with the help of a computer, correct software and an interface cable. This information can be used to specify the maintenance and service proceedings in relation to the boiler (parts).

Water leakage

The water pressure of the heating installation should be more than 1.0 bar and at a maximum of 2.0 bar in normal operation. When the water pressure drops below the minimum occasionally, there might be a water leak. Check the boiler and the complete heating installation for any water leakages and have these repaired.

Flue gas & air supply

The flue gas pipes and the air supply pipes must be checked for gas tightness. Also check if the mounting of these pipes is correct, safe and not damaged. Check the rooftop of the boiler housing for signs of water leakage and traces of water coming from the air supply pipe, the air vent or any condensate coming from the flue gas pipes.

Gas supply & safeties

The gas pipes must be checked for gas tightness. Also check if the mounting of these pipes is correct, safe and not damaged. Any built in safeties should be checked for a correct functioning.

Remove complete burner unit

The complete burner unit consists of the fan, the burner plate and the internal burner. To remove this part for an internal heat exchanger check: remove the six M6 nuts, the ignition cable and the thermal fuse cables. After this, take out the complete burner unit by moving it forward out of the boiler housing. NOTICE: Watch out not to damage the burner plate insulation during this operation. While removing the complete burner unplug both of the electrical and controlling cables of the fan. After all this dismantle the air gas mixing box on the suction side of the fan and check the blade wheel of the fan.

Burner

Check the burner surface to see if it has damages, signs of rust and/or cracks. When the burner surface is damaged the burner must be replaced. The burner can be cleaned by using a soft (non-metallic) brush. The dust can be removed with a vacuum cleaner or pressurized air.

Ignition / ionisation electrode

When the complete burner is removed, it is very easy to check the ignition electrode. First check if the distances between the electrodes and between the electrode and the burner are according to the graph below. When these are not correct, try to bend the electrodes in the right position. Notice: the electrodes undergo high temperatures, therefore the electrodes become hard and are difficult to bend. While bending used electrodes they might break or burst. Check the electrode, after bending, for any tear/crack and signs of rust. When they are burst/cracked or rusty, replace the electrode. Also replace the electrode when there is a crack in the ceramic insulation of the electrode. When the electrode is replaced, also the gasket should be renewed.



Burner door gaskets

When these gaskets have changed colours at some parts, the rubber has cured and/or has damages, these gaskets must be replaced. Notice: only use the gaskets that are supplied by the boiler manufacturer.

Fan

When the fan blades are polluted and dirty, carefully clean the blades with a soft brush. Notice: do not use too much force on the blades or else the fan might be out of balance and run irregularly, causing noises and fan failures. Check the fan also for any water damages. In doubt always replace the fan of the boiler.

Insulation

The insulation of the heat exchanger (located on the rear wall inside the heat exchanger and burner door) must be inspected. If this insulation disk shows any signs of (water) damage or degradation it should be exchanged. Also check if there are any indications in the burner room of a high condensate level (caused by a blocked siphon) that might have wetted the rear wall insulation. When this has happened the rear wall insulation should also be replaced.

Only use the insulation disk that is supplied by the boiler manufacturer.

The same procedure must be applied on the insulation and gaskets fitted on the burner door.

Siphon

Disassemble the siphon and clean every part of it. Check the siphon connection of the heat exchanger for any blocking or pollution and clean it (if necessary). Check the functioning of the siphon by pouring clean tap water in the burner room (when burner door is removed). This water will exit the heat exchanger by the siphon. Notice: don't wet the rear wall insulation.



When mounting the bottom part of the siphon, before commissioning the boiler and/or after maintenance, the siphon must **ALWAYS** be <u>completely</u> filled with water.

This is a safety measure: the water in the siphon keeps the flue gases from leaking out of the heat exchanger via the condensate drain.



Heat exchanger and burner room

After the removal of the complete burner unit check if there is any debris and dirt in the heat exchanger. The coils of the heat exchanger can be cleaned by using a **non-metallic** brush. After this the dirt and dust can be removed with a vacuum cleaner and by flushing the burner room with water. Don't forget afterwards to clean the siphon once again.

Gas/air ratio

With every service check and/or maintenance of the boiler always check the gas/air ratio by measuring the CO_2 percentage (flue gas) at the maximum and minimum load of the boiler. If necessary adjust these values. See for information chapter 14 "Adjusting and setting the burner".

Pump

Check the electrical parts and the motor of the pump for a correct functioning. The pump must generate a sufficient water flow over the (heat exchanger of) the boiler. When the pump produces noise, is operational for more than five years or has signs of water leakage it is recommended to replace the pump as a precaution.



When defects and abnormalities are found by the service engineer during service and maintenance and these are not repairable, this information should be reported to the owner/end-user of the installation. Also the owner/end-user should be advised how to fix these defects and these defects should be reported in the service report / log file of the boiler.



During service and maintenance the gas, supply air, flue gas and condensate connections are disconnected, checked and replaced. Make sure that all these components are mounted correctly before commissioning the boiler again.



Cleaning the burner room with acid or alkali products is prohibited.

Mounting the burner door correctly back onto the heat exchanger:

IMPORTANT:

Before mounting the burner door, make sure that its gaskets and insulation are in excellent shape.

If any signs of damage or ageing are present, these parts must be replaced.

The burner door must be mounted back on the heat exchanger as follows:

- Place the burner door with its holes over the six threaded studs.

Careful! When handling too rough or misplacing the holes over the threaded studs, the burner door insulation and/or gaskets can be damaged.

Assure yourself that the door is well positioned with respect to the threaded studs, before pushing it onto the exchanger.

- Now keep the burner door firmly in place by pushing the gas/air nose with one hand at the middle at point A.
- Then turn-tighten the flange nuts with the other hand as far as possible onto the threaded studs.

Now the burner door is in place and the nuts can be tightened with a torque key.

- Tighten the nuts in the order given in the picture
- The specified torque value for tightening the burner door flange nuts is **8 Nm**

tighten in given order.

torque value = 8 Nm



18 USER INSTRUCTIONS

After installing and commissioning of the boiler, demonstrate the operation of the entire central heating system to the end-user. The user should be made familiar with all safety precautions of the boiler and the installation. The user should be instructed that service and maintenance of the boiler is required every twelve months. Regular service and maintenance is essential for a safe and proper operation of the boiler. Hand over the documents supplied with the boiler.

19 INSTALLATION EXAMPLES

The following schematics present several ways of mounting the heating installation:



All schematics are purely functional. Safety components must be added conform all applicable standards and regulations.

System Type 1



Code 1	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
No parame	eter change needed		

System Type 2



Code 2	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
	place bridge	13-14	
OS	outdoor temperature sensor	1-2	E04.016.585
No parameter change required			



Code 3	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
OS	outdoor temperature sensor	1-2	E04.016.585
No parameter change required			

System Type 4



Code 4	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
Т	calorifier		
ST	calorifier thermostat or tank sensor	5-6	S04.016.303
OS	outdoor temperature sensor	1-2	E04.016.585
DV	diverter valve (3-way-valve)	28-29-30-31	
Parameter change required			

System Type 5



Code 5	Name	Wire terminal	Order nr.
P1	Built-in Boiler Pump		
P3	Optional Heating Pump	25-26-27	
RT	Modulating Room unit with timer	13-14	S04.016.355
Т	Calorifier		
ST	Calorifier thermostat or tank sensor	5-6	S04.016.303
P2	HWS Primary Pump	29-30-31	
OS	Outdoor temperature sensor	1-2	E04.016.585
SNV	Non Return Valve		
Parameter	Parameter change required		



Code 6	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
FS	flow temperature sensor	3-4	E04.016.304
ОН	low loss header		
OS	outdoor temperature sen- sor	1-2	E04.016.585
No parameter change required			

System Type 7

System Type 8



Code 7 Name Wire terminal Order nr. P1 built-in boiler pump P3 optional heating pump 25-26-27 modulating room unit with timer RT 13-14 S04.016.355 т calorifier calorifier thermostat S04.016.303 ST 5-6 or tank sensor ОН low loss header FS flow temperature sensor 3-4 E04.016.304 diverter valve DV 28-29-30-31 (3-way-valve) outdoor temperature E04.016.585 os 1-2 sensor Parameter change required

RT os ٦٢ HEATING BOILER ZONE P1 (OH FS _ P3 т &snv L_ - P2 ST

Code 8	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
т	calorifier		
P2	HWS primary pump	29-30-31	
ST	calorifier thermostat or tank sensor	5-6	S04.016.303
ОН	low loss header		
FS	flow temperature sensor	3-4	E04.016.304
SNV	non return valve (low resistance type)		
OS	outdoor temperature sen- sor	1-2	E04.016.585
Parameter change required			



Code 9	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
P2	HWS primary pump	29-30-31	
Т	calorifier		
ST	calorifier thermostat or tank sensor	5-6	S04.016.303
ОН	low loss header		
FS	flow temperature sensor	3-4	E04.016.304
SNV	non return valve (low resistance type)		
OS	outdoor temperature sensor	1-2	E04.016.585
Parameter change required.			

For the cascade installations see the special Cascade Manual.



Code 10	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
SNV	non return valve (low resistance type)		
ОН	low loss header		
FS	flow temperature sensor	3-4	E04.016.304
OS	outdoor temperature sensor	1-2	E04.016.585
Parameter	Parameter change required		



Code 11	Name	Wire terminal	Order nr.
P1	built-in boiler pump		
P3	optional heating pump	25-26-27	
RT	modulating room unit with timer	13-14	S04.016.355
SNV	non return valve (low resistance type)		
P2	HWS primary pump	29-30-31	
Т	calorifier		
ST	calorifier thermostat or sensor	5-6	S04.016.303
ОН	low loss header		
FS	flow temperature sensor	3-4	E04.016.304
OS	outdoor temperature sensor	1-2	E04.016.585
Parameter change required.			

20 INDEX

0-10 vdc remote burner input control. 82 0-10 vdc remote flow temperature set point, 81 3-way valve (diverter valve), 9, 37, 83 accessories, 14 accessories and unpacking, 12 adjusting and setting the burner, 93 air separator, 21 ff. air supply, 15, 28 air venting, 19, 20 Ambassador⁺ 60-120, 12 Ambassador⁺ 150-180, 13 anti-Legionnaires' disease (pasteurisation) function, 85 article numbers, 14 automatic air vent, 20 automatic water filling systems, 20 B23P boilers, 29 blocking, 19, 37, 74, 80, 90, 102, 113 boiler connections, 17 boiler room, 15 by-pass, 18 C63 boilers, 29 checking the fault history, 61 checking the operating history, 60 cleaning of the burner, 113 closed boiler, 15, 28 combustion air quality, 28 commissioning the boiler, 87 connections electric, 37 ff. connections gases miscellaneous, 26 ff. connections water miscellaneous, 17 ff. control panel / display unit, 43 control panel menu structure, 44 controlling behaviour settings, 80 controlling options and settings, 78 dimensions, 12 dirt filter, 21 ff. dirt separator, 21 ff. display during operation, 46 diverter valve (3-way valve), 9, 37, 83 e-bus interface, 14 efficiency, 9 electrical connections, 37 electrical installation, 37 electrical schematics, 39 expansion vessel, 18 extra boiler control, 78

fan, 15, 49, 78, 101, 113

fault checking, 61, 74 fault codes display, 74 fault codes. blocking codes, 102 firing for the first time, 92 flue gas and air supply examples, 29 flue gas and air supply systems, 26 flue gas duct, 28 flushing with clean water, 21 frame, 16 frost protection, 19 gas conversion, 98 gas valve, 14, 93 ff, 101, 113 hanging level, 16 heat exchanger, 9, 84 ff, 113 heating, 78 ff. heating and hot water switching at sudden temperature drop, 85 heating and hot water switching time, 85 hydraulic graphs, 24 hysteresis, 80 ignition, 113 indirect hot water / calorifier, 83 inspection & maintenance, 113 installation examples, 21, 118 ff. installation of the Ambassador⁺, 15 installing a strainer and/or dirt separator, 19 introduction, 9 legonnaires' disease, 53, 85 low loss header, 18, 21, 90 low/high flow temperature to tank coil, 84 low-water level protection, 15 Ls and Lw gases, 93 ff, 96 maintenance, 113 master, 9, 56 max cooling time, 78 modulation, 14, 118 ff. monitor screens, 47 night shift, 56, 82 non return valve, 118 ff. offset, 80 outdoor graph, 56 outdoor sensor (outdoor temperature), 14, 37, 38, 56 outdoor temperature control, 56 oxygen, 19 ff. oxygen diffusion proof, 90 oxygen tight, 90 password, 67 plastic piping in the heating system, 20

positioning the boiler, 16 power (supply), 9, 18, 37, 90 pressure relief valve, 18 pressure safety valve, 90 printed circuit board, 39 pump, 18 pump and 3-way valve control, 83 putting the boiler out of operation, 101 quality of combustion air, 28 quality of used water, 19 reset. 74 roof mounted duct. 28 room thermostat on/off, 81 room thermostat open therm, 81 safety guidelines, 7 schornsteinfeger function, 48 sensor, 14, 19, 20, 37, 56, 80, 83, 118 ff. sensor values, 38 service function, 49 set points, 52 setting at the maximum load, 93 ff. setting at the minimum load, 93 ff. setting the maintenance specifications, 62 setting the outdoor specifications, 56 setting the parameters with the display menu, 67 setting the time & date, 51 setting the timer programs, 53 starting the boiler, 92 stationing the boiler, 16 status, 46 tank sensor, 83 tank thermostat, 83 technical data Ambassador⁺ boilers, 9 temperature display on/off, 78 timer contact function, 82 under floor heating, 21 unpacking, 14 user instructions, 117 user manual, 9, 15 valve, 92 ff, 93 ff, 113 ventilate, 7, 15 venting, 7, 15, 19, 20, 113

wall mounted duct, 16, 21 water pressure, 20 water pressure switch, 37, 90 water quality, 19 water side connections, 17 water treatment, 21 weather dependent control, 56, 81 Strebel Ltd 1f Albany Park Industrial Estate, Frimley Road, Camberley, Surrey, GU16 7PB.

т	01276 685422
F	01276 685405
E	info@strebel.co.uk
I.	www.strebel.co.uk

CE



Further information on our complete product range is available from our website. CAST IRON – CONDENSING – STEEL SHELL – WATER HEATERS – RENEWABLES FLUES – ACCESSORIES – RADIATORS