## **Ecoblue Faults**

All fault codes are shown as E with number(s) following.

If the code does not have an E prefix it is not a fault, it is an operating status code, boiler on/off or temperature etc. In these cases the user guide should be consulted.

In all cases the user should try to reset the boiler first; power cuts etc. can affect the normal boiler operation.

Fault codes that the end user may be able to clear

Code Possible Fault User Action.

110 Overheat Check radiators are bled.

117 Water pressure too high Bleed water from radiators.

118 Water pressure too low Add water via filling loop.

125 Water circulation fault Bleed radiators, check system water pressure and refill via a filling loop if low.

133 Safety time to establish flame exceeded Check gas is turned on, if prepayment meter check there is credit. If all ok and this fault persists - contact an engineer to visit and investigate.